Draper Inc., Motorized Flexshade Handbook
Table of Contents

1. Introduction To Motorized Shades 2
2. How to Measure, Recommendations and Tips 3
3. Motorized Terms 4

Radio Motor Transmitters 5
- A. Handheld 1 and 4 channel remotes 6
- B. Handheld 20 Channel 7
- C. Wall Switches 1 and 4 Channel 8-9
- D. Motor Programming Instructions 10
- E. Chronis Timer and Lite 11-14
- F. Dry Contact Interface 15
- G. Universal RTS Interface 16-17
- H. RS 232 Interface 18
- I. RTS Repeater 19

5. Radio Motor Accessories 20
   - A. Battery Wand 21
   - B. Plug-IN Transformers 22
   - C. Din Rail, 3, 6, 12 motor, Transformers 23-28
   - D. 10 Motor Power Panel 29
   - E. Centralis Receiver 30
6. Toggle (SP/DT) and DP/DT, Keyed, and Multi-Station Switch 31-33
7. Motor Pigtails and Quick Disconnects 34
8. Isolating Relay Review and Wiring 35-36
9. GC4 Overview and Wiring 37-38
10. SC1 Overview and Wiring 39-40
11. SGC4 Overview and Wiring 41-42
12. SPGC4 Overview and Wiring 43-44
13. IntelliFlex Inputs Overview 45
    - A. Input Device Sample Config 46
    - B. IR and RF Remote Control 47-50
    - C. IntelliFlex Wall Switch Submittal and Instructions 51-54
    - D. RS 232 Interface 55
    - E. Sun Sensor 56-64
    - F. Timer 65-67

G. Dry Contact Convertor 68

14. IntelliFlex Overview and Planning Sheet 69-70
15. IntelliFlex Quick Reference Guide 71-72
16. Intelligent Motor Overview 73
    - A. Limits and ILT Switch 74
    - B. ILT 4 Jack Interface 75
    - C. IP Interface 76
    - D. Draper Digital Network Programming 77-80
17. Explode View of Motorized Flexshade Components 81
18. Motor Quick Reference Sheet 82
19. 506S2RH and 510S2RH- Standard and Heavy Duty Motors 83-84
20. 504S2RH-ST and 506G- Quiet Standard and Heavy Duty Motors 85-86
21. 506S2ILTRH and 504S2ILTRH-ST- Intelligent and Quiet Intelligent Motor 87-88
22. 506S2RH-RTS and 510S2RH-RTS- Standard and Heavy Duty Radio Motors 89-90
23. 504S2RHST-RTS- Quiet Radio Motor 91
24. 506S2PA and 510 S2PA- Standard and Heavy Duty Motors for Flexshade 2 92-93
25. 506S2ILT- Intelligent Motor for Flexshade 2 94
26. 506S2-RTS and 510S2-RTS- Standard and Heavy Duty Radio Motors for Flexshade 2 95-96
27. 506S1RH and 510S1RH- Standard and Heavy Duty Motors, 220V, export 97-98
28. 503S1RH-ST- Quiet Standard Motor, 220V, export 99
29. 506S1PA and 510S1PA- Standard and Heavy Duty Motors for Flexshade 2, 220V, export 100-101
30. 660R2- Colossal Shade Motor 102
31. ST-30, Low Voltage Radio Motor 103
32. BA-RTS, Battery Radio Motor 104
33. Minimum motorized Shade Widths 105-106
34. Motor Flexshade, Flexshade 2, and Colossal Installation Instructions 107-112
35. Scenario: Working Shades from a 12V trigger such as a projector 113
36. Scenario: Working Shades from a Hospital Bed, Motion Sensor, lighting System with Dry contact 114
37. Scenario: Working Shades with Multi-Station High Voltage Switches 115
38. Scenario: Working Shades from a Home Automation System (Crestron, AMX, etc.) via Dry Contact 116
39. Scenario: Working Shades from a Home Automation System (Crestron, AMX, etc.) via RS 232 117
40. SolarFlex- Sun Tracking Automation 118-119
41. Draper, Inc. Contact Information 120

For Order Forms Visit

Introduction to Motorized Shades

Motorized shades can be a big profitable opportunity or a big pain depending on how you go about it. Being educated on the product before handling or installing it will greatly increases your chances at having a successful, profitable install. This is why we at Draper, Inc. have created this motorized document. We hope this gives you more help on understanding and installing your motorized shade jobs.

Motorized shades offer your customer many benefits. These bullets points are important to remember when selling motorized shades.

- Motorized FlexShades are available in any size from 2´ through 14´ wide. Larger sizes are available with FlexShade 2 or Colossal FlexShade.
- Installation choices range from simple mounting brackets, to endcaps and fascia, to complete extruded pockets with bottom closure panels.
- Motorized FlexShades retract completely when not in use for an unobstructed view.
- Choose a glare control fabric—mesh or translucent—or a free-hanging room darkening fabric.
- Depending on size, battens may be used for a smooth, flat surface.
- Compact, tubular gearmotors located within each roller provide smooth, reliable operation.
- Up to five Motorized FlexShades can be coupled to reduce the number of motors.
- A simple wall switch is included with each motorized unit. Or choose the most versatile motor control system: IntelliFlex® offers total flexibility in how you group, sub-group or individually control your shades.

Draper's extensive offering of motorized shades and controls can be difficult to understand so please contact us with any questions or concerns that this document cannot answer or raises.

How to Measure for Draper Shades

FlexShades are custom fabricated for each opening, and must be measured accurately.

Determine the area to be covered, and decide where brackets or endcaps will be attached.

Be careful to allow for any irregularity which will interfere with the proper operation of the unit (i.e. handles, irregular trim, locks or opening not square and plumb).

Inside Mount

1. Measure from six positions at each window—top, center, and bottom for the width; left, center, and right for the height.
2. Measure the width of the opening, providing Draper with the EXACT window opening width at the window's narrowest point. DO NOT MAKE ANY DEDUCTIONS for bracketing or mounting—Draper will make the necessary deductions.
3. Measure the height of the opening, providing Draper with the EXACT window opening height at the window's shortest point. Again, DO NOT MAKE ANY DEDUCTIONS—Draper will take the appropriate deductions.
4. Note for Inside Mount Lightbloc Shade—Draper will take the appropriate deductions from your EXACT OPENING dimensions in both width and height.

Outside Mount

1. Measure the width of the window, specifying the EXACT width and height you want the product to be. Draper will make your product to the exact size you specify. NOTE – adding overlap to a shade increases privacy while decreasing light leaks.
2. Note for the Outside Mount Lightbloc Shade – Draper will fabricate the unit to your EXACT OVERALL dimensions, taking no deductions. Make sure to account for the side and sill channels.

Cloth Measurement: Exact width of cloth. Depending on product, overall width may be wider than fabric.

Pocket: If mounting shade brackets or headbox in a pocket above window opening, give the exact overall height (top of pocket to sill) and the exact width of pocket. Draper will make necessary deductions.

Seams: As standard, shades that are both wider and taller than the maximum available fabric width in any given style will be seamed horizontally ("transversed" or "railroaded") at Draper's discretion with the seam placed as high as possible (from the bottom of the shade up) unless otherwise specified.

Stays: Draper may, at our sole discretion, add stays to the shade in pockets or at seam locations to improve surface flatness and reliable operation. Stays are made of spring steel and measure ¼" wide and are inserted in pockets in the fabric measuring approximately 11/8" wide. Shades over 10' wide OR over 14' in height will have stays placed at intervals of no more than 96" (Colossal shades taller than the widest fabric width have stays at intervals of no more than 63").



Inside Measure



Outside Measure

Note for LightBloc and Skylight Systems:

IM LightBloc—Draper will deduct 1/8" from your exact opening dimensions in both width and length. Be sure several measurements are taken to discover any irregularities in the opening.

IM Skylight—Draper will deduct 3/4" from your exact opening dimensions in both width and length. Draper provides angles to be installed around the opening and the shade rests on the angles. Be sure several measurements are taken to discover any irregularities in the opening.

OM LightBloc and Skylight—Draper will fabricate the unit to your exact dimensions, taking no deductions.

Note which units, if any, abut at mullions.

Installation Tips

Motor Testing

It is recommended to test and set all motor limits prior to electrician wiring motor. Draper sells a test cord, C116.014, for this. Testing and setting limits on all motor types before the electrician wires the motor is helpful in finding problems before the motor has to be disconnected from electricity. Motor can lose their limits in shipping even if they are set at Draper, Inc.

Shimming

This is an installation practice used in the field to correct fabric tracking. Shade fabrics are not smooth surfaces so as they roll on themselves, then they will want to walk left or right. Correcting this tracking can be done through shimming. You increase the diameter of one side of the shade by adding tape which will draw the fabric towards the applied tape. To shim, you will run the fabric down to where it is attached to the roller. You will then apply an 1" square piece of duct tape to the roller with half on the roller and half on the shade cloth to the outside edge of the cloth. You may apply up to three pieces in an overlapping fashion on top of each other to help more severe tracking issues. The larger the piece of duct tape and the more toward the outside of the roller the tape is attached, then the more the fabric will move to that side.

Terms

In trying to understand motorized shades, it is important to know certain terminology. These terms used by Draper, electricians, and others when discussing motorized cover how power brought to the shades, wire size used, control types used, and more.

High Voltage or Line Voltage—These terms refer to 110 or greater voltage. In the US and Canadian markets, most high voltage shades jobs are supplying 110 to 120 VAC to the motors. This type of voltage will most likely be in conduit.

Low Voltage—For Draper shades, this is referring to 24 VDC. Low voltage power comes from a transformer receiving high voltage.

Transformer—For Draper shades, this is an item that changes high voltage to low voltage.

Conduit—This is the metal piping that is used to protect wires in the ceiling or walls.

Gauge—This refers to the diameter of the wires. For Draper high voltage shades, the gauge of wire going from the motor to the controls is typically US 18 gauge. Lower numbers are large diameters.

Pigtail or Motor Lead—This refers to the wires coming off of the motor. The standard length for these is 6', but they can be ordered up to 24'.

Amps or amperage—This is a measurement of power on an electrical circuit. You may be asked the amp draw of a motor so the electrician does not put too many motors on an electrical circuit.

Home run—This refers to a straight line of wires being supplied from a singular motor to a singular controller or singular port on a controller.

Parallel Wiring—This refers to 2 or more motors being wired together to a controller or a port on a controller.

Dry Contact—These are the closures on a controller. There are three ports that make up the closure; up, common, and down. The common port is sending out power. When the common port connects with either the up or down port then the shade will react in that direction. This type of closure allows for low voltage systems to operate shades.

RS 232, RS 485, RS 422—These are computer languages that can be used to operate shades.

Data Cable and CAT 5—These are the low voltage wire used to carry power to low voltage shades or communication signals between low voltage devices.

Radio Motor Transmitters

There are several types of radio motor transmitters, and here is a listing of them and when you need them. A radio motor can learn up to twelve different transmitters.

- **Single Channel Transmitter, C072.011—**This is a one channel remote for operating one shade or one group of shades. It is able to send an up, stop, down, and intermediate stop command.

- **Four Channel Transmitter, C072.012—**This is a four channel remote with a 5th channel that can be used as well for operating up to 5 groups of shades in individually or 4 groups individually and as a group. It is able to send an up, stop, down, and intermediate stop command per channel.

- **Single Channel Wall Switch, C112.074—**This is a one channel wall switch for operating one shade or one group of shades. It is able to send an up, stop, down, and intermediate stop command.

- **Four Channel Wall Switch, C112.076—**This is a four channel remote with a 5th channel that can be used as well for operating up to 5 groups of shades in individually or 4 groups individually and as a group. It is able to send an up, stop, down, and intermediate stop command per channel.

- **20 Channel Transmitter, C072.043—**This is a 20 channel remote which can be used to operate 20 groups of shades. It has timer, vacations, and other user functions that one may enjoy. A single or four channel remote is required to first set the motor limits before using this transmitter.

- **Chronis Timer, C072.033—**This single channel transmitter is used to run radio motors at certain programmed times. A single or four channel remote is required to first set the motor limits before using this transmitter.

- **Chronis Lite Timer and Sun Sensor, C156.099—**This single channel transmitter works as a timer, and it always has an interior sensor which suctions to the glass. The sensor will read light outside the window and operate the shades per the light levels. A single or four channel remote is required to first set the motor limits before using this transmitter.

- **Dry Contact Interface, C156.100—**This single channel transmitter sends out a command based on the connections made on the dry contact inputs. This device is used for interfacing radio motors with low voltage control systems. A single or four channel remote is required to first set the motor limits before using this transmitter.

- **Universal RTS Interface, C156.101—**This is a 16 channel transmitter which sends out commands based on the inputs of IR, RS 232, and RS 485 that it receives. A single or four channel remote is required to first set the motor limits before using this transmitter.

- **RS 232 Interface, C156.102—**This is a 16 channel transmitter which sends out commands based on the RS 232 commands sent to it. A single or four channel remote is required to first set the motor limits before using this transmitter. It is compatible with X-10.

- **RTS Repeater, C072.044—**This repeater plugs into a wall, and it is used to extend range of a transmitter by picking up a signal and re-emitting it.

Telis Transmitters

Telis hand-held radio transmitters are compatible with RTS Motors and external RTS receivers such as Centralis or HRC-RF.

Each Telis transmitter can operate any number of motors or receivers. Each motor or receiver will memorize up to 12 transmitters.

The four channel transmitter can be used for group and individual control of window treatments.

MECHANICAL SPECIFICATIONS

Overall Dimensions: L: 5¼ in. W: 15/8 in. D: 11/16 in.
Operating Temperature: 41 F to 104 F
Typical Range (Optimal Conditions): 65 ft.

ELECTRICAL SPECIFICATIONS

Power: 3V Lithium battery, Cr2430
Frequency: 433.42 Mhz

GENERAL OPERATING INSTRUCTIONS

NOTE: Please Consult RTS Motor or Receiver Instructions for Specific Product Details.

1. Place the RTS Motor or Receiver in Programming Mode as described in the Operating Instructions.
2. Press the programming button on the back of the Telis transmitter to program it in the memory of the RTS Motor or Receiver.
3. Pressing the UP button will raise the window covering, while pressing the DOWN button will lower it. To stop the window covering, simply press the STOP button.
4. Pressing the Channel Selector button on the four channel transmitter will switch between channels 1 through four and the group (or fifth) channel. The corresponding LEDs will light to indicate the channel selected.







Channel selector button on Multi-Channel Transmitter

20-Channel Transmitter

This is a 20-channel, Composio, handheld transmitter for Radio Motors. It has an interactive screen for setting functions. It also has a dock for placing the transmitter on the wall. The Composio gives one greater control over large groupings of Radio Motors than other transmitters.

The Composio cannot be used to program limits like the 1 and 4 channel transmitters.

Programming instruction for the transmitter come packaged with it. It is a fairly large with several options for a user to select.

Remote Size

$6\frac{7}{8}$" H x $2\frac{3}{16}$" W x 1" Thick

Dock Size-screws to wall

3" H x $1\frac{3}{16}$" W

Range

65' under ideal conditions, repeaters can be added.

DECORA RTS SWITCH
Operating Instructions



The Decora RTS Switch (single or four channel) is a wireless radio transmitter compatible with all the RTS MOTORS, and externally mounted RTS receivers.

- Commands are transmitted by radio waves at 433.42 MHz.
- Power: 3V lithium battery, CR 2430 type
- Operating temperature: +5 C/41 F to +40 C/104 F
- Range: Up to 65 Ft.
- Fits into standard Decora Wall Plates

This is a low voltage device which does not need to be mounted inside an electrical box. It can be mounted adjacent to an existing Decora style light switch or, as a stand alone device using the specific low voltage bracket (included).

GROUPING DECORA RTS WALL SWITCHES

1. Set all the receivers/motors you wish to control into PROGRAMMING MODE.
2. Press the programming button (1 sec. max.) on the side of the Decora RTS switch.
3. All the receivers/motors within the transmitted range of the Decora RTS will confirm the addition of the NEW Decora RTS.

REMOVING A DECORA RTS FROM THE RECEIVER'S MEMORY

1. Please refer to section B, "Adding multiple Decora RTS wall switches". The procedure is exactly the same for removing the Decora RTS wall switch. If the Decora RTS was previously recorded it will be deleted. If it was not in memory it will be added to the memory of the receiver/motor.

***NOTE:**

It is possible to activate an external receiver with another Decora Transmitter without having access to the programming button on the PCB of the receiver. Treat the external receiver as you would a motor and press and hold the programming button of the Decora RTS (for 3 sec.) then briefly press the programming button of the Decora RTS switch you wish to add/remove.

FRONT VIEW



Select the Channel

SIDE VIEW



Programming Button

DECORA RTS SWITCH
Mounting Instructions

The special low-voltage bracket is specifically designed to mount the Decora RTS wall switch next to an existing Decora light switch with an electrical box already behind the drywall. This bracket differs from other off the shelf low-voltage brackets because it is offset to one side. This allows a double gang Decora style cover plate to fit over both switches without installing a double gang electrical box behind the drywall. It is also possible to mount this bracket as a stand alone low voltage device.

INSTALLATION PROCEDURE

NOTE: This bracket is designed for an existing electrical box already behind the sheetrock. If a retrofit electrical box was used, it is recommended to remove the single gang and replace it with a double gang retrofit box.

1. Orient the brackets flat side against the wall keeping the thin side closest and centered with the existing electrical switch box.



2. Align the inside edge of the thin side on the bracket with the outside edge of the switch box. Then trace the inside shape (as shown by the dashed line in the diagram) of the bracket. (sheetrock not shown for clarity)



3. Cut traced opening into drywall. Be careful not to make the opening larger than necessary, to ensure a tight fit. Use dimensions in diagram below. Do not exceed these dimensions to ensure a proper fit of the bracket.



4. Insert bracket (as shown) into hole, keeping the thin side closest to the existing switch box, and laying flat on drywall.



5. To keep the bracket in place, bend tabs 90 around drywall, as tightly as possible.



6. Mount low voltage switch into bracket, with its edge flush against electrical switch box.



7. Finish the installation by mounting a standard double gang Decora switch cover plate, over both switches



BATTERY LIFE

The RTS Switches are powered by a 3V battery (type 2430) which provides about 3 years operation assuming 4 operations per day. When the battery becomes discharged, the control LED no longer lights up when a command is sent, and the command is not carried out.

HOW TO REPLACE THE BATTERY

1. Remove the screws on the back cover of the RTS Switch.
2. Slide the battery out of its holder by pushing it with a screwdriver.
3. Insert the new battery, maintaining its correct polarity.

NOTE: Do not throw the battery in the trash, but dispose of it properly.

Radio Remote Control Motor Programming Instructions

When you receive a radio remote control motor from Draper, Inc., the motor has no programming on it so it must be learned and programmed to work on the transmitter that you have at the job. Here are the initial programming instructions.

① Connect power to 1 motor. Select the transmitter/channel to which you plan to learn the motor. Press and hold the UP and DOWN buttons at the same time until the motor jogs, then release.

② Check the motor run direction by press either the UP or DOWN buttons. This is important because if you do step 3 without doing this step, then you will need to reset the motor. If you need to reverse the motor direction, then press the STOP button (middle button which might be labeled MY) for 5 seconds until the motor jogs. Check the direction again to make sure that it works.

③ Move the motor to its upper limit position. Press the STOP and DOWN buttons at the same time until the motor starts to move down, then release. You will stop the motor at its lower limit. You can use the UP and DOWN buttons to adjust the motor to the correct lower limit position if need be.

④ Once the motor is at its lower limit position, then press the UP and STOP buttons at the same time until the motor starts to move up, then release. The motor should move to the upper limit position in step 3 and stop.

⑤ Once the motor has stopped at its upper limit position, then press and hold the STOP button for 5 seconds until the motor jogs.

⑥ Now, you must put the motor into USER mode. Find the programming button which is a small button on the back or side of the transmitter and press it until the motor jogs. Once you have done this, then the motor will operate in normal fashion.

⑦ Disconnect power to this motor and move to the next in your installation and start with step 1. Reconnect motor to power when all motors are programmed.

Reset Motor Instructions

If the motor is not working or responding correctly and you want to reprogram it from the beginning and clear all previous programming, then follow these steps.

① Disconnect the motor from power for 2-5 seconds, reconnect to power for 10-13 seconds, disconnect from power for 2-5 seconds, and reconnect to power. The motor should move down a little after you reconnect to power the last time.

② You will then need to find the programming button which is a small button on the back or side of the transmitter. You will need to depress the button for 10-15 seconds. The motor should jog up and down once then pause and jog a second time during this time period. Once the motor has completed its second jog, then you can start at step 1 of initial programming as the motor is clear.

Setting an Intermediate Stop

This is done once the shade is in USER mode from the initial programming at top.

① Move the motor to the mid-point location that you want the stop located.

② Press and hold the STOP button until the motor jogs.

③ Now, if you hit the STOP button when the motor is standing still, it will move to that intermediate location.

④ If you want to delete the stop, then go to the intermediate stop and press and hold the STOP button until the motor jogs.

Add/Delete a Channel/Transmitter

To add a channel/transmitter, you just need to follow a couple of steps.

① Select the channel/transmitter that is currently operating the motor, then press the programming button until the motor jogs.

② Select the new channel/transmitter that you want to add to the motor, then press the programming button until the motor jogs.

③ The motor should now work on both the old and new channel/transmitter.

To delete a channel/transmitter, you just need to follow a couple of steps.

① Select the channel/transmitter that is currently operating the motor and you want to keep, then press and hold the programming button until the motor jogs.

② Select the channel/transmitter that you want to remove, then press and hold the programming button until the motor jogs.

③ The motor should now only work on the channel/transmitter on step 1.

Adjust Limits in User Mode

If your initial limits have changed or you want to fine tune a motor, you do not need to reset the motor and re-program it. You can just change the limits with these steps.

① Move the motor to the limit (upper or lower) that you want to change.

② Press and hold the UP and DOWN buttons until the motor jogs.

③ Move the motor to its new limit location.

④ Press and hold the STOP button until the shade jogs.

These instructions are different for low voltage and Intelligent motors with radio technology.

Inteo Chronis RTS Timer
Quick Reference Guide

Programming the Chronis: Programming the Chronis depends on the item it will be controlling. For instance: Centralis, Eolis, Altus. Follow the specific programming instructions for each item it will be controlling. The programming button of the Chronis is located under the switch cover, right above the display. "Prog" will appear on the display as you press it.

On/Off: Turn the Chronis **Off** by pressing the **"+"**. You can still use it manually but all automatic functions will be turned off. Press the **"."** to turn it back **On**.

To Set or Reset the Time: Quickly press **"Set"** while the time is displayed. It will begin to flash. Use the **"."** or **"+"** to change the time (military time). Quickly press **"Set"** when done to conflrm it.

To Set or Reset the Day, Month or Year: Quickly press **"Calendar"** and then **"Set"** and the day will begin to flash. Use **"-"** or **"+"** to change the day. When done, press the **"Up"** button and the month will begin to flash. Use the **"."** or **"+"** to change it. When done, press the **"Up"** button and the year will begin to flash. Use **"."** or **"+"** to change it. Quickly press **"Set"** when done to conflrm it.

Timer Settings: This setting allows you to open and close the application at different times each day (**7 day timer**). Press and **hold** "Set" until a second (smaller) time is displayed below the normal time.

Up Times: Quickly press **"Set"** and the time begins to flash. Press the **"Up"** button and the current (smaller) up time flashes along with the up arrow and day **(1 = Monday)**. Press **"Calendar"** to select the day. Use the **"-"** or **"+"** button to change the up time. Setup each day individually or for weekly programming. To turn it **"Off"**, set it between **23:59** and **0:00**. Quickly press **"Set"** when done to confirm it.

Down Times: Quickly press **"Set"** and the time begins to flash. Press the **"Down"** button and the current (smaller) down time flashes along with the down arrow and day. Use the **"-"** or **"+"** button to change the down time. Press **"Calendar"** to select the day. Setup each day individually or for weekly programming. Set it between 23:59 and 0:00 to turn it **"Off"**. Quickly press **"Set"** when done to confirm it.

Vacation Security Setting (SEC): This setting takes the normal **"Timer Settings"** and randomly changes them plus or minus 15 minutes each day to give the appearance that your house is occupied. Press and hold **"Set"** until **"SEC"** appears on the display.

Cosmic 1 Setting (COS1): This setting opens and closes at sunrise and sunset. Press and hold **"Set"** until (**COS1**) appears on the display. You can enter differential and cutoff times to customize this setting.

Differential Times: Allows you to change the **Up (sunrise)** time or **Down (sunset)** time by plus or minus lhr 59mins. Quickly press **"Set"** and the time begins to flash. Press the **"Up"** button to choose the up differential or the **"Down"** to choose the down differential. Use the **"-"** or **"+"** to change the differential time. Quickly press **"Set"** when done to conflrm it. Check and set the cutoff times (see below).

Cutoff Times: Modifies the differential times and limits the earliest it will go up at sunrise or latest it goes down at sunset. Quickly press **"Set"** and the time begins to flash. Press the **"Up"** button twice for the **up** cutoff time or the **"Down"** button twice for the **down** cutoff time. An **(S)** will appear next to the (smaller) cutoff time. Use the **"."** or **"+"** to change it. Set it between **23:59** and **0:00** to turn it **"Off"**.

Cosmic 2 Setting (COS2): This setting opens at the individual **"Timer Settings"** and closes at the **"Cosmic 1"** settings (this includes the differential and cutoff times of **COMS1**). Press and **hold** **"Set"** until (**COS2**) appears on the display.

Important: Please read the complete instructions prior to using this quick reference guide.

Inteo Light Sensor
Installation Guide

Together with the Chronis Uno L, Chronis IB L, Chronis RTS L, Chronis Comfort RTS, Chronis Comfort IB and Chronis Comfort UNO, the brightness sensor can be used to operate your roller shutters and venetian blinds in relation to the amount of light. These control units have an integrated automatic solar control unit (L = light control) that automatically creates shadow if the sunshine is too strong.

In addition, the Chronis Uno L, Chronis IB L, Chronis Comfort IB and Chronis Comfort UNO offer an automatic dusk control unit that operates your roller shutters and venetian blinds in conjunction with the switching time when dusk sets in.

1 Installation

Insert the plug of the brightness transmitter into the socket on the front of the Chronis L (or Chronis Comfort) control unit.



Stick the suction cap of the brightness sensor to the inside of the window pane at the desired shade position of the roller shutter.

2 Programming

2.1 Automatic solar control unit with a Chronis L

Switching the automatic solar control unit on / off.

The automatic solar control is activated when the UP switching time is reached and de-activated when the DOWN switching time is reached. This means the following in normal use: the automatic solar control unit is switched on during the day and off at night. When it is on, a ⧈ is shown in the display. You can switch the automatic solar control unit on or off manually during the day.

To switch the automatic solar control unit off:

① Press set once ❮ the time flashes.
② Press △ until the bar display ▮▮ for the “Sun” reference value is displayed.
③ Press -/+ several times until hOFF is displayed.
④ Press set to store the changes.

To switch the automatic solar control unit back on:

① Press set once ❮ the time flashes.
② Press △ until hOFF is displayed.
③ Press -/+ several times until the desired number of bars for the “Sun” reference value has been set.
④ Press set to store the changes.

Setting the automatic solar control unit

The desired brightness value at which the shutter is to move into the shade position can be selected by entering the “Sun” reference value. The factory setting for the automatic solar control unit is a threshold value of 6 bars (30 kLux approximately). Inputting the “Sun” reference value (can be entered at any time except in the “OFF” position) :

① Press set once ❮ the time flashes.
② Press △ until the bar display ▮▮ for the “Sun” reference value is displayed.
③ The “Sun” reference value can be set by pressing -/+ several times. 1 bar = roller shutter moves into the shade position if sun is weak (10 kLux). 12 bars = roller shutter moves into the shade position if sun is strong (more than 50 kLux).
④ Press set to store the changes.

Tip: it is best to enter data when the sun reaches the intensity at which you wish to move the shutter automatically into the shade position in the future. First set the “Sun” reference value to 12 bars, and then press Minus (-) until the sun symbol (✷) is flashing. This value then corresponds to the current solar intensity.

2.2 Automatic solar control unit with a Chronis Comfort

Switching the automatic solar control unit on / off.

The automatic solar control is activated when the UP switching time is reached and de-activated when the DOWN switching time is reached. This means the following in normal use: the automatic solar control unit is switched on during the day and off at night. When it is on, a ✷ is shown in the display. You can switch the automatic solar control unit on or off manually during the day.

To switch the automatic solar control unit off:



1 Press ⓦ 2 seconds, then 0,5 seconds 6 times, until the “SEnS” screen.
2 Press ▷ once to go to the brightness screen.
3 Press ◁ several times until OFF is displayed.
4 Press ▷ 0,5 seconds, then ⓦ 2 seconds to store the changes.

To switch the automatic solar control unit back on:



1 Press ⓦ 2 seconds, then 0,5 seconds 6 times, until the “SEnS” screen.
2 Press ▷ once to go to the brightness screen.
3 Press ◁ several times to set the brightness reference value.
4 Press ▷ 2 times, then ⓦ 2 seconds to store the changes.
Brightness reference value: “1” = roller shutter moves into the shade position if sun is weak (10 kLux).
“12” = roller shutter moves into the shade position if sun is strong (more than 50 kLux).

Tip: it is best to enter data when the sun reaches the intensity at which you wish to move the shutter automatically into the shade position in the future. First set the “Sun” reference value to 12, and then press Minus (-) until the sun symbol ✷ is flashing. This value then corresponds to the current solar intensity.

2.3 Automatic dusk control unit with a Chronis L (not with Chronis RTS L)

Switching the automatic dusk control unit on / off

You can switch the automatic dusk control unit on or off manually. The factory setting for the automatic dusk control unit is ON.

To switch the automatic dusk control unit off :

1 Press ⓦ 2s.
2 Press ▽ until the bar display for the “Dusk” reference value is displayed.
3 Press ◁ several times until dOFF is displayed.
4 Press set to store the changes.

To switch the automatic dusk control unit back on :

1 Press once set the time flashes.
2 Press ▽ until dOFF is displayed.
3 Press ◁ ▷ several times until the desired number of bars for the “Dusk” reference value has been set.
4 Press set to store the changes.

Setting the automatic dusk control unit

The desired dusk value at which the shutter is to close in conjunction with the switching time can be set by entering the “Dusk” threshold value.
The factory setting for the automatic dusk control unit is pre-set to a mean value of 6 bars (60 Lux approximately).
The “Dusk” reference value can be entered at any time except in the “OFF” position.



1 Press set once ❮ the time flashes.
2 Press ▽ until the bar display for the “Dusk” reference value is displayed.
3 The “Dusk” reference value can be set by pressing ◁ ▷ several times.
1 bar = roller shutter does not close until dusk has set (10 Lux).
12 bars = roller shutter closes as early as the onset of dusk (250 Lux).
4 Press set to store the changes.

Tip: It is best to enter data when the evening dusk reaches the brightness level at which you wish to have the shutter close automatically in the future. To do this, set the “Dusk” reference value to 1 bar, and then press Plus (+) until the moon symbol (◐) is displayed.
This value then corresponds to the current dusk setting.

2.4 Automatic dusk control unit with a Chronis Comfort (not with Chronis Comfort RTS)

Switching the automatic dusk control unit on / off:

You can switch the automatic dusk control unit on or off manually. The factory setting for the automatic dusk control unit is ON.

To switch the automatic dusk control unit off:



1 Press Ⓦ 2 seconds, then 0,5 seconds 6 times, until the “SEnS” screen.
2 Press ▷ twice to go to the darkness screen.
3 Press ◁ several times until OFF is displayed.
4 Press ▷ 0,5 seconds, then Ⓦ 2 seconds to store the changes.

To switch the automatic dusk control unit back on:



1 Press Ⓦ 2 seconds, then 0,5 seconds 6 times, until the “SEnS” screen.
2 Press ▷ twice to go to the darkness screen.
3 Press ◁ several times to set the darkness reference value.
4 Press ▷ 0,5 seconds, then Ⓦ 2 seconds to store the changes.
Darkness reference value :

“1” = roller shutter does not close until dusk has set (10 Lux).
“12” = roller shutter closes as early as the onset of dusk (250 Lux).

Tip: It is best to enter data when the evening dusk reaches the brightness level at which you wish to have the shutter close automatically in the future. To do this, set the “Dusk” reference value to 1, and then press Plus (+) until the moon symbol ◐ is displayed.
This value then corresponds to the current dusk setting.

2.5 Operating the automatic dusk control unit

As soon as the “Dusk” reference value does not meet the selected setting, the moon symbol (◐) is displayed. If the reference value remains below this level for more than 5 minutes approximately and the DOWN switching time has arrived already, the control unit gives a DOWN command. If the DOWN switching time has not been exceeded yet, the control unit waits until this time comes and then moves the shutter down.

Example:

DOWN switching time	**Actual clock time**	**Dusk value**	**Action**
20:00	19:45	reached	☞ The DOWN arrow in the display flashes. ☞ Wait until switching time of 20.00 comes
20:00	20:15	Not reached yet	☞ Display in window changes to next UP switching time, DOWN arrow flashes!
			☞ Wait for as long as “Dusk” reference value is not met.
20:00	20:15	reached	☞ Shutter moves down.

Note: The dusk function can be impaired with strong sources of light in the surroundings of the light sensor.

RTS Dry Contact Interface
Operating Instructions

The RTS Dry Contact Interface can be used to communicate between home automation or other third party systems and RTS Motors and Inteo line of controls.



NOTE: Please consult RTS Motor Instructions for specific product details.

1 Place the RTS Motor in Programming Mode as described in the individual product operating instructions.

2 Press the programming button on the RTS Interface to program it in the memory of the RTS Motor.

3 To activate an UP command, a momentary contact (relay) closure is required between the WHITE and GREEN wires.

4 To activate a DOWN command, a contact closure is required between the BLACK and GREEN wires.

5 To activate a STOP command or Intermediate Position, a contact closure is required between the RED and GREEN wires.

Universal RTS Interface II

DESCRIPTION

Part Number: 1810872

The addressable Universal RTS Interface II (URTSI II) can be used to communicate between home automation or other third party systems and RTS Motors and controls. It is capable of individual or group control, and can be operated via infrared remote, RS232 and RS485 serial communication. Once an input is activated, an RTS radio command is sent to the automated window treatment.

CONNECTION DIAGRAM



NOTE: Do Not remove antenna. If a new antenna is needed, it must be ordered from Somfy to ensure FCC requirements are maintained.

FCC INFORMATION

This device complies with Part 15 of the FCC Results. Operation is subject to the following two conditions:
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including that which may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for CLASS B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and , if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna
2. Increase the separation between the equipment and receiver
3. Connect the equipment into an outlet on a circuit different from that to which receiver is connected
4. Consult the dealer or experienced radio/TV technician for help.

WARNING

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

OPERATION

A. INITIAL SETUP

1. Connect a 9v DC transformer (included) to the receptacle on the back of the control box. The LED will light green to indicate power.
2. Be careful not to mount or enclose Interface on or in metal, as this may effect radio reception.
3. Set the RTS Receiver or motor into its Programming Mode. Refer to the installation instructions of the relevant RTS receiver or motor for this procedure.

NOTE: for initial programming provide power only to the motor or control being programmed.

4. Using the rotary switch, select the channel to be programmed. Letters A through F stand for channels 10 through 15, 0 for 16. Briefly press the programming button (1 sec. max), the window treatment will jog to indicate the channel has been memorized.
5. Repeat the steps above for each channel or product to be memorized, up to 16.
6. To test the control operation, simply press the UP, STOP or DOWN buttons on the front of the control. The window treatment should move appropriately. The LED will flash red to indicate the radio signal has been transmitted.

B. INFRARED OPERATION

1. The RTS Interface is compatible with Somfy's multichannel transmitter. Connect an infrared sensor to the appropriate connector on the back of the Interface.
2. Each individual motor is activated by first aiming the transmitter at the sensor and pressing the desired unit number on the transmitter and then pressing the UP or DOWN buttons. Press the center button to STOP the window treatment at any time.

C. RS232 OPERATION

1. The Somfy RS232 interface uses the following communications settings: 9600 Baud, 8 Data Bits, 1 Stop Bit, No Parity
2. Set the rotary switch to position 1.
3. The basic format for communication is as follows: URTSI ADDR MOTOR CHAN DIR
   The URTSI address is 01.
   The motor channel should be 2 digits from 01 to 16.
   The directional commands are: U = Up D = Down S = Stop (Must be Capital letters)
4. Examples:
   Motor 1 UP: 0101U
   Motor 5 DOWN: 0105D
   Motor 12 STOP: 0112S

D. RS485 OPERATION

1. The Somfy RS485 interface uses the following communications settings: 9600 Baud, 8 Data Bits, 1 Stop Bit, No Parity
2. With RS485, it is possible to connect 16 Universal RTS Interfaces on one network. Each Interface will have its own address. To select the address, set the rotary switch to the desired number. Letters A through F stand for addresses 10 through 15, 0 for 16.
3. The basic format for communication is as follows: URTSI ADDR MOTOR CHAN DIR
   The URTSI address should be 2 digits from 01 to 16.
   The motor channel should be 2 digits from 01 to 16.
   The directional commands are: U = Up D = Down S = Stop (Must be Capital letters)
4. Examples:
   URTSI 1, Motor 1 UP: 0101U
   URTSI 3, Motor 12 DOWN: 0312D
   URTSI 14, Motor 9 STOP: 1409S
   URTSI 10, Motor 15 UP: 1015U

MECHANICAL SPECIFICATIONS

Overall Dimensions: L: 3 in. W: 4 in. D: 1 3/8 in.
Typical Range (Optimal Conditions): 65 ft.

ELECTRICAL SPECIFICATIONS

Power: 9V DC, 200mA
Frequency: 433.42 Mhz

RS232 to RTS Interface with X10 Compatibility

Description

The RS232 to RTS Interface is a 16-channel RTS transmitter that enables third party home automation systems to directly control Somfy's line of RTS motors and controls. The interface also includes X10 compatibility for direct control of RTS product from an X10 powerline system. The interface plugs into a standard 115 VAC electrical outlet.

Part Number 1810686

Operating Procedures

RTS Channel Programming

① Ensure the RTS motor or receiver to be controlled has already been assigned to a channel on a Telis or similar channel as outlined in the specific product instructions. All limits, intermediate positions and programmable functions should be set.
② Set the RTS receiver or motor into its programming mode as outlined in the specific product instructions.
③ Set the Rotary Address Dial to the channel you want the motor or receiver to respond to. Press the Programming Button on the Interface. The motor or receiver will respond accordingly.

RS232 Operation

① Set RS232 communication settings to: 9600 Baud, 8 Data Bits, 1 Stop Bit, No Parity
② Use the ASCII protocol: <!> <2 digit unit code> <Directional Command>
③ The directional commands must be capital letters and are as follows:
U: up
D: down
S: stop
④ There must be a 500mS delay between successive commands.
⑤ Examples: Motor 2 Up: !02U
Motor 5 Down: !05D
Motor 1 Stop: !01S

X10 Operation

① Set the Rotary Address Dial to the desired X10 house code.
② Send the address then the following commands to activate that motor or receiver:
BRIGHT: UP
DIM: DOWN
OFF: STOP
③ Examples: Motor 1 Up: 1 Bright
Motor 3 Down: 3 Dim
Motor 5 Stop: 5 Off



411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

RTS Repeater

Description

The RTS Repeater can be used in installations to extend the range of the standard Radio Technology signal. It will receive the signal from a Telis or similar device and retransmit the signal to a RTS compatible motor or receiver.

Part Number 1810686

Mechanical Specifications

Overall Dimensions: L: 4 in. W: 2¼ in. H: 1⅜ in.
Frequency: 433.42MHz
Range: 60ft

Operating Procedures

Simply plug the receiver into any 120v AC outlet. It should be located at least halfway between the transmitting device (Telis) and receiving device (RTS Motor). The red LED will blink, indicating communication.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Radio Motor Accessories

In the previous section radio motor transmitter information was given. This section talks about the accessory parts that come with Radio Motors. We have broken down the accessories and to which motor that they belong.

Battery motor accessory is:

Battery Wands- Wands are included with new battery motor shades. The battery wand replacements are part no. C105.005. There are now reloadable AA battery wands available and part no. is TBA.

Low Voltage motor accessories are:

Transformers- Transformers are need to supply power to each low voltage motors. The transformers come in different amperages to power different quantities of motors.

Part No.	Item	Type
C215.009	24VDC, 1.66A for 1 motor	Plug-in outlet
C215.010	24VDC, 2.5A for 1 motor	Plug-in outlet
C215.011	24VDC, 5A for 3 motor	Plug-in outlet
C215.012	24VDC, 10A for 6 motors	Plug-in outlet
C215.013	24VDC, 15A for 9 motors	Plug-in outlet
C215.014	24VDC, 20A for 12 motors	Plug-in outlet
C215.015	24VDC, 5A for 3 motors	Din Rail Mount
C215.016	24VDC, 10A for 6 motors	Din Rail Mount
C215.017	24VDC, 20A for 12 motors	Din Rail Mount

Radio Motor, high voltage, accessories are:

Motor Pigtails- Pigtails are needed at different length to connect the motor to power. These motor leads can have a 3 prong plug attached to connect to an outlet or be bought with a plug already molded. The standard is 6' with no 3 prong plug.

Part No.	Item
C107.043	12' RTS Motor cable, no plug
C107.044	24' RTS Motor cable, no plug
C107.045	3' RTS Motor cable, with 3 prong NEMA plug
C107.021	6' RTS Motor cable, with 3 prong NEMA plug
C107.039	12' RTS Motor cable, with 3 prong NEMA plug
C107.040	24' RTS Motor cable, with 3 prong NEMA plug

Standard Motor Accessory to turn the motor into a radio motor is:

Centralis- Part no. is TBA, but this part turns a standard motor into a radio motor.

Battery Wands

Battery Wands are the power source for battery motors. Wands do come with every motor purchased. Replacement wands can be purchased if needed. Draper only uses the 12V double battery wand or reloadable wand.

Battery life is highly variable depending on the shades size and number of operations that one runs. Typically, the life is 1 to 3 years. Another thing other than shade size and operation which may reduce battery life is RF interface.

If a battery motor is reading RF interface from an item, then it will stay on and drain battery power much faster. There is no way of knowing if there is interface draining the motor until it happens. Also conditions can change over time depending on whom or what is the source of the RF interface.

Reloadable wands will use 8 AA batteries to obtain the 12V needed to run the shade.

Battery Motors will run at different speeds depending on size of shade and type of battery supplying power.

Mounting battery wands can be done with the clips that are sent with the motors. There are 2 wands to mount when install 12V batteries and just one to mount when installing reloadable wands.

Battery Wand Size—12V Battery—1 Battery size
16" long x $^{11}/_{16}$" diameter

Reloadable Wand Size
18" long x $^{11}/_{16}$" diameter (screw on cap is ¾" diameter)

Plug-In Transformers

These transformers are for supplying 24VDC to our low voltage motors. There are 6 types of transformers, but the numbers and type of these transformers are subject to change at any time without notice.

These transformers are not special to window shade motors and you may source a transformer which meets the power requirements needed on your own. If you want something different than we carry, we recommend that you do this.

Plug-in transformers are called this because they plug into an outlet for power.

They will then feed power directly to a motor or a power panel feeding motors. The dims of the current transformers offered are as listed below.

Single Motor- Wall Plug-in
Dims: 2¼" w x 4" h x 1¼" d

Single Motor- Floor Plug-in, this transformer does not plug right into an outlet, but a cord plugs into it then into the outlet like a laptop transformer.
Dims: 2½" w x 3⅞" h x 1¼" d

Three Motor- Table top/shelf Plug-in
Dims: 7⅛" w x 2" h x 8⅝" d

Six Motor- Table top/shelf Plug-in
Dims: 7⅛" w x 2¾" h x 8⅝" d

Nine Motor- Table top/shelf Plug-in
Dims: 7⅛" w x 2¾" h x 8⅝" d

Twelve Motor- Table top/shelf Plug-in
Dims: 7⅛" w x 2¾" h x 8⅝" d

DIN-Rail Transformer—DR-120

Features:

- AC input range selectable by switch
- Protections: Short circuit/Overload/Over voltage/Over temperature
- Cooking by free air convection
- Can be installed on DIN rail TS-35/7.5 or 15
- UL 508 (industrial control equipment) approved
- LED indicator for power on
- 100% full load burn-in test
- Fixed switching frequency at 55KHz
- 3 years warranty

SPECIFICATION

MODEL		DR-120-24
	DC Voltage	24V
	Rated Current	5A
	Current Range	0 – 5A
	Rated Power	120W
	Ripple & Noise (max.) Note 2.	60mVp-p
OUTPUT	Voltage Adj. Range	24 – 28V
	Voltage Tolerance Note 3.	±1.0%
	Line Regulation	±0.5%
	Load Regulation	±1.0%
	Set Up, Rise Time	
	Hold-Up Time (Ty.)	36ms/230VAC 32ms/115VAC at full load
	Voltage Range	88 – 123VAC/176-264VAC by switch 248-370VDC
	Frequency Range	47 – 63 Hz
INPUT	Efficiency (Typ.)	64%
	AC Current (Typ.)	2.6A/115VAC 1.6A/230VAC
	Inrush Current (Typ.)	Cold Start 20A/115VAC 40A/230VAC
	Leakage Current	<3.5mA/240VAC
	Overload	105 – 150% rated output power Protection type: Constant current limiting, recovers Automatically after fault condition is removed
PROTECTION	Over Voltage	29-33V Protection type: Shut down o/p voltage, re-power on to recover
	Over Temperature	90°C±5°C(TSW1) Protection type: shut down o/p voltage, recovers automatically After temperature goes down
	Working Temp.	-10 – 60+C (refer to output load deraling curve
	Working Humidity	20 – 90% RH non-condensing
ENVIRONMENT	Storage Temp. Humidity	-20 - +65C, 10 – 95% RM
	Temp, Coefficient	±0.03%/C (0-50°C)
	Vibration	10 – 500Hz, 2G 10min./1cycle.60min.each along X, Y, Z axes; Mounting Compliance to IEC60068-2-6
	Safety Standards	UL508, UL60950-1, TUV EN60950-1 approved
	Withstand Voltage	!/P-O/P.3KVAC I/P-FG.1.5KVAC 0/P-FG.0.5KVAC
SAFETY &	Isolation Resistance	I/P-O/:, I/P-FG, O/P-FG:100M Ohms/500VDC
EMC (Note 4.)	EMI Conduction & Radiator	Compliance to EN55011, EN55022, (CISPR22) Class B
	Harmonic Current	Compliance to EN61000-3-2,-3
	EMS Immunity	Compliance to EN61000-4,2,3,4,5,6,8,11, ENV50204, EN55024, EN61000-6-2 (EN50082-2), heavy industry level, criteria A
	MTBF	136.8Khrs.min. MIL-HDBK-217F (25°C)
OTHERS	Dimension	65.5 x 125.2 x 100 mm (W x H x D)
	Packing	0.78Kg; 20pcs/16.5Kg/1,29CUFT

NOTE: ① All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature.
② Ripple & noise are measure at 20MHz of bandwidth by using a 10" twisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor.
③ Tolerance: includes set up tolerance, fire regulation and load regulation.
④ The power supply is considered a component which will be installed into a final equipment. The final equipment must be reconfirmed that it still meets EMC directives.

DRAPER®

DIN-RailTransformer—DR-120—Page 2

■ Mechanical Specification



Terminal Pin No. Assignment (TB1)

Pin No.	Assignment
1	FG ⏚
2	AC/N
3	AC/L

Terminal Pin No. Assignment (TB2)

Pin No.	Assignment
1,2	DC OUTPUT +V
3,4	DC OUTPUT -V

■ Block Diagram



■ Derating Curve



■ Static Characteristics (24V)



DIN-RailTransformer—DR-240

Features:

- Universal AC input/full range
- Built in active PFC function
- Protections: Short circuit/Overload/Over voltage/Over temperature
- Cooking by free air convection
- Can be installed on DIN rail TS-35/7.5 or 15
- UL 508(industrial control equipment/approved
- LED indicator for power on
- 100% full load burn-in test
- Fixed switching frequency at 100KHz
- 3 years warranty

SPECIFICATION

MODEL		DRP-240-24
	DC Voltage	24V
	Rated Current	10A
	Current Range	0 – 10A
	Rated Power	240W
	Ripple & Noise (max.) Note 2.	80mVp-p
OUTPUT	Voltage Adj. Range	24 – 28V
	Voltage Tolerance Note 3.	±1.0%
	Line Regulation	±0.5%
	Load Regulation	±1.0%
	Set Up, Rise Time	800ms, 40ms/230VAC 800ms, 40ms/115VAC at full load
	Hold-Up Time (Ty.)	24ms/230VAC 24ms/115VAC at full load
	Voltage Range Note 5.	65 – 264VAC 120 – 370VDC
	Frequency Range	47 – 63 Hz
INPUT	Efficiency (Typ.)	84%
	AC Current (Typ.)	2.8A/115VAC 1.4A/230VAC
	Inrush Current (Typ.)	Cold Start 27A/115VAC 45A/230VAC
	Leakage Current	<3.5mA/240VAC
	Overload	105 – 150% rated output power Protection type: Constant current limiting, recovers automatically after fault condition is removed
PROTECTION	Over Voltage	30 – 36V Protection type: Shut down o/p voltage, re-power on to recover
	Over Temperature	100°C±5°C(TSW1)detect on heat sink of power transistor Protection type: shut down o/p voltage, recovers automatically after temperature goes down
	Working Temp.	-10 – 70+C (refer to output load derating curve)
	Working Humidity	20 – 90% RH non-condensing
ENVIRONMENT	Storage Temp. Humidity	-20 - +85C, 10 – 95% RH
	Temp, Coefficient	±0.03%/C (0-50°C)
	Vibration	10 – 500Hz, 2G 10min./.1cycle.60min.each along X, Y, Z axes; Mounting Compliance to IEC60068-2-6
	Safety Standards	UL508, UL60950-1, TUV EN60950-1 approved
	Withstand Voltage	!/P-O/P.3KVAC I/P-FG.1.5KVAC 0/P-FG.0.5KVAC
SAFETY &	Isolation Resistance	I/P-O/P, I/P-FG, O/P-FG:100M Ohms/500VDC
EMC (Note 4.)	EMI Conduction & Radiation	Compliance to EN55011 (CISPR11) EN55022 (CISPR22), EN61204-3 Class B
	Harmonic Current	Compliance to EN61000-3-2,-3
	EMS Immunity	Compliance to EN61000-4,2,3,4,5,6,8,11, ENV6150204, EN55024, EN61000-6-2 (EN50082-2), heavy industry level, criteria A
	MTBF	105.5Khrs.min. MIL-HDBK-217F (25°C)
OTHERS	Dimension	125.5°125.2°100mm(W"H"D")
	Packing	1.2Kg; 12pcs/16.5Kg/1.29CUFT

NOTE: ① All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature.
② Ripple & noise are measure at 20MHz of bandwidth by using a 10" twisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor.
③ Tolerance: includes set up tolerance, fire regulation and load regulation.
④ The power supply is considered a component which will be installed into a final equipment. The final equipment must be reconfirmed that it still meets EMC directives.
⑤ Derating may be needed under low input voltages. Please check the derating curve for more details.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

■ Mechanical Specification



ADMISSIBLE DIN-RAIL: TS35/7.5 OR TS35/15

Terminal Pin Number Assignment (TB1)

Pin No.	Assignment
1	FG ⏚
2	AC/N
3	AC/L

Terminal Pin Number Assignment (TB2)

Pin No.	Assignment
1,2	DC OUTPUT +V
3,4	DC OUTPUT -V

■ Block Diagram

fosc : 100KHz



■ Derating Curve



■ Output derating VS input voltage



DIN-RailTransformer—DR-480S

Features:

- AC input range selectable by switch
- Built in passive PFC function compliance to EN61000-3-2
- High-efficiency 89% and low dissipation
- Protections: Short circuit/Over Load/Over voltage/Over temperature
- Cooling by free air convection
- Built-in constant current limiting circuit
- Can be installed on DIN rail TS-35/7.5 or 15
- UL 508 (industrial control equipment) approved
- EN61000-6-2(EN50082-2) industrial immunity level
- 100% full load burn-in test
- 3 years warranty

SPECIFICATION

MODEL		DRP480S-24
	DC Voltage	24V
	Rated Current	20A
	Current Range	0 – 20A
	Rated Power	480W
	Ripple & Noise (max.) Note 2.	120mVp-p
OUTPUT	Voltage Adj. Range	24 – 28V
	Voltage Tolerance Note 3.	±1.0%
	Line Regulation	±0.5%
	Load Regulation	±1.0%
	Set Up, Rise Time	1200ms, 40ms/230VAC,115VAC at full load
	Hold-Up Time (Ty.)	23ms/230VAC, 115VAC at full load
	Voltage Range Note 5.	90 – 132VAC/180 264VAC by switch 254-370FDC
	Frequency Range	47 – 63 Hz
	Power Factor (Typ.)	≥ 0.7/230VAC only
INPUT	Efficiency (Typ.)	89%
	AC Current (Typ.)	8A/115VAC 3.2A/230VAC
	Inrush Current (Typ.)	Cold Start 27A/115VAC 45A/230VAC
	Leakage Current	<3.5mA/240VAC
	Overload	105 – 150% rated output power Protection type: Constant current limiting, recovers automatically after fault condition is removed
PROTECTION	Over Voltage	30 – 36V Protection type: Shut down o/p voltage, re-power on to recover
	Over Temperature	100°C±5°C(TSW: detect on heat sink of power switch Protection type: shut down o/p voltage, recovers automatically after temperature goes down
	Working Temp.	-20 – +70°C (refer to output load derating curve)
	Working Humidity	20 – 90% RH non-condensing
ENVIRONMENT	Storage Temp. Humidity	-40 - +85°C, 10 – 95% RH
	Temp, Coefficient	±0.03%/C (0-50°C)
	Vibration	Component 10 – 500Hz, 2G 10min./.1cycle.60min.each along X, Y, Z axes; Mounting Compliance to IEC60068-2-6
	Safety Standards	UL508, UL60950-1, TUV EN60950-1 approved
	Withstand Voltage	!/P-O/P.3KVAC I/P-FG.1.5KVAC 0/P-FG.0.5KVAC
SAFETY &	Isolation Resistance	I/P-O/P, I/P-FG, O/P-FG:100M Ohms/500VDC
EMC (Note 4.)	EMI Conduction & Radiation	Compliance to EN55011, EN55022, (CISPR22) Class B
	Harmonic Current	Compliance to EN61000-3-2,-3
	EMS Immunity	Compliance to EN61000-4,2,3,4,5,6,8,11, ENV50204, EN61204-3, EN61000-6-2 (EN50082-2), heavy industry level, criteria A
	MTBF	187.9Khrs.min. MIL-HDBK-217F (25°C)
OTHERS	Dimension	227°125.2°100mm(W"H"D")
	Packing	2.60Kg; 6pcs/16.6Kg/1.75CUFT

NOTE: ① All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature.
② Ripple & noise are measure at 20MHz of bandwidth by using a 10" twisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor.
③ Tolerance: includes set up tolerance, fire regulation and load regulation.
④ The power supply is considered a component which will be installed into a final equipment.
⑤ The final equipment must be reconfirmed that it still meets EMC directives.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

DIN-RailTransformer—DR-480S—Page 2

Mechanical Specification



ADMISSIBLE DIN-RAIL:TS35/7.5 OR TS35/15

TB1 Terminal Pin. No Assignment

Pin No.	Assignment
1	AC/L(DC+)
2	AC/N(DC-)
3	FG ⏚

TB2 Terminal Pin. No Assignment

Pin No.	Assignment
1,2	DC OUTPUT +V
3,4	DC OUTPUT -V

■ Derating Curve



■ Output Derating VS Input Voltage



10 Motor Power Panel

The 10 motor power panel is for powering the Low Voltage Radio Motor. It is not required, but it does make installation easier.

A transformer is still needed, and it will feed power to the panel. You can parallel wire the motors directly into the power feed off the transformer. This, however, makes connecting and disconnecting the motor from power to program it difficult and cumbersome. With a power panel you can disconnect or connect each motor individually for programming, this will make installation quicker.

A power panel is also set-up to work with wiring that might have been pulled for a different system.

The diagram below shows the panel and how motors plug into it.



411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Centralis Receiver
Inteo Remote Control

The Centralis Receiver is a single motor control designed for residential use. It includes an integrated radio receiver, plus input terminals for an optional low voltage switch. Using the Telis Transmitters, it is possible to operate the controls individually or in groups. Two user-defined intermediate positions can be programmed. This control is packaged in a weatherproof enclosure and includes watertight strain-relief fittings for wires entering the box.

MECHANICAL SPECIFICATIONS

Overall Dimensions:
L: 6 in. W: 4¼ in. D: 2¼ in.

Typical Range (Optimal Conditions): 65 ft.

ELECTRICAL SPECIFICATIONS

Voltage Ratings:
INPUT: 120 VAC +/- 10% 50/60 Hz.
OUTPUT: 120 VAC 5A 1/4 HP

Approvals: The Centralis Receiver is UL508 for industrial controls (UL, cUL). Complies with the National Electrical Code (NEC) and FCC Standards.

OPERATING INSTRUCTIONS

System Set Up

① With power off, wire Centralis as indicated above. Turn all circuit breakers on (motors should not move).
② Set the Centralis Receiver into programming mode by pressing the programming button on the receiver until the LED lights solid (about 5 seconds).
③ Press the programming button on the Telis1 or Telis4 transmitter. Make sure the desired channel is selected on the Telis4 before programming. The programming LED on the Centralis will blink indicating the transmitter has been memorized.
④ Operate each motor in the DOWN direction using the radio transmitter.
⑤ The motorized window covering should move down or out. If this is incorrect, turn off the circuit breakers and reverse the red and black wires of the motor.

Operating Procedures

TRANSMITTER
① Pressing the UP button on the Telis transmitter will move the window covering up or in. The DOWN button will move the treatment down or out.
② To stop the motorized product at any time, press the CENTER button on the transmitter.
③ To reach one of the intermediate positions, the awning or rolling shutter must first be at the upper or lower limit, and stopped. Pressing the center button on the transmitter will move the window covering to the desired position.

LOW VOLTAGE SWITCH
④ If desired, a single pole, single throw switch can be connected to the low voltage terminals as indicated above. Each press of the switch will sequence through the directions as follows;

DEPRESS 1	UP DIRECTION
DEPRESS 2	STOP
DEPRESS 3	DOWN DIRECTION
DEPRESS 4	STOP

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Toggle Switch (SP/DT) and Princess Rocker (DP/DT)

The maintain toggle switch (SP/DT) is the standard switch which is sent with shades. Maintain switches when flipped stay in the up or down position for one to walk away while the shade moves. Ivory is the standard color (Part 121101), but one can get it in white (Part 121102).

The momentary toggle switch is an alternate switch which one can have in place of the maintained. They come in ivory (Part 121103) or white (Part 121104). The momentary switch returns to the center/off position when one releases the switch.

The above switch types are rated for 110-230V and 15A. This means that US and export markets can use the switch and the motor draw through the switch can be up to 12A. The switch fits in a single gang box and uses a conventional light switch cover plate.

The maintained rocker switch (DP/DT) is an up-charge switch which can run two motors at the same time. It comes in ivory (Part C112.012) and white (Part C112.002). There are two sets of relays on the back of the switch to wire each motor. The motors cannot be parallel wired to the switch.

The momentary rocker switch is an alternate to the maintained rocker. This switch must be held in place to keep from moving to the center/off position unlike the maintain switch which stays in position. The momentary switch comes in ivory (Part C112.026) and white (Part C112.043).

The above switch types are rated for 110-230V and 15A. This means that US and export markets can use the switch and the motor draw through the switch can be up to 12A. The switch fits in a single gang box and uses a princess rocker switch cover plate.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

KS-3
3-Position Key Switch
Technical Data Sheet

Part Numbers:

121018—Maintained
121022—Momentary

USES: The KS-3 replaces the standard single-station control switch for all products (screens, shades or projector lifts) where the directional functions (Up and Down) need to be combined with the security of a key switch.

COMPATIBILITY: KS-1 Power Supply Key Switch.
The KS-3 is intended as the sole control station, and cannot be used as a multiple station control. It can, however, be used with the KS-1 power supply key switch, although having two key switches is redundant.
It is not intended for use with any other control.

CONTACTS: Two cam-operated Single-Pole, Single-Throw contact blocks (On-Off), wired to emulate Single-Pole, Double-Throw, Center Off (On-Off-On). Maintained action.

RATING: 600 Volts, UL recognized, CSA recognized.

DESCRIPTION: 3-position key operator.
Cover plate is stainless steel.
Four 6" wire leads: black, black, red and blue (2 commons, down and up).
2¾" x 4½" cover plate fits a single-gang box.

ILLUSTRATION:



ISSUED: December 2009

Printed in the U.S.A. Copyright ©2008 Draper, Inc. Form KS-3_TechDataSheet08

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

MS-3R, MS-4R
Multiple-Station Control

Technical Data Sheet

Part Numbers:

121002—MS-3R and MS-4R
121025—Additional MS-4R

USES: The MS-3R and MS-4R are 3- and 4-wire versions of the same switch, used for controlling one screen from multiple locations, using the motor's voltage (115V or 220V). MS-4R is the first control station in a series of stations. It is also the intermediate control (s) in the case of three or more stations. The fourth wire passes electricity to the next switch in the series. This fourth wire is taped off to create the MS-3R. MS-3R is the last control station in a series of stations. Therefore, it does not need to pass electricity to a next switch. It is used with one or more MS-4R controls.

COMPATIBILITY: MS-3R and MS-4R are used with each other as multiple control stations. They can also be powered on and off with the KS-1 Power Supply Key Switch. They are not intended for use with any other controls.

CONTACTS: Single-Pole, Triple-Throw (On-On-On). Momentary (spring-loaded) action.

RATING: 16 Amps, 277 Volts, UL recognized, CSA recognized.

DESCRIPTION: Switch is a black, Euro-style (rounded or oval) rocker switch. Cover plate is aluminum, finished silver satin. Four 6" wire leads: black, red, blue and black (common, down, up, next switch). MS-3R and MS-4R start out as the same control. The 3 and 4 indicate the number of wires connected to the switch. The fourth wire is taped off to create the MS-3R. 2¾" x 4½" cover plate fits a single-gang box.

ILLUSTRATION:



ISSUED: December 2009

Printed in the U.S.A. Copyright ©2008 Draper, Inc.

Motor Pigtails and Disconnects

Motor Pigtails are a standard of 6' with a 18 gauge 3 conductor with a ground on 4 wire motors. It is a 18-2 with 3 wire motors. The pigtails do come in longer lengths up to 24'.

3 wire pigtails also can come with an optional 3 prong plug (see page 20).

All motor pigtails are not plenum rated. They are a PVC jacketed cable with a diameter of $^{5}/_{16}$".

Quick disconnect plugs come as a standard on Motorized Flexshades with brackets, fascia, or headbox (excluding small pocket headbox). They are not on Motorized Flexshades in Access Pockets (single, dual or ultimate), and they are not on Lightblocs, Colossals, Flexshade 2s, skylights or Romans.

The male plug is one foot off the motor. The female lead which can be sent early is toward the J-Box. It is available in 5' lengths (Part C116.030) as a standard, but you can also order female leads at 11' (Part C116.031), 17' (Part C116.032), and 23' (Part C116.033).

The female lead can be replaced with a wall entry plate, C201.001, for plugging the male connector into the wall or J-box face plate.

The picture below is the standard plug set-up. Each plug is 2" long so 4" when together.
The female is 1¼" w at the base and $^{7}/_{8}$" wide at the neck. It is $^{7}/_{8}$" high.
The male plug is 1¼" w at the base and $1^{3}/_{8}$" wide at the neck. It is $^{7}/_{8}$" high.



Isolating Relays

The isolating relay (ISO relay) prevents feedback between motors and allows multiple motors to run off a 120V switch. The switches that Draper supplies are 15A so twelve standard motors are able to run off one switch with isolating relays. To further help you decide if isolating relays are right for you, here are some conditions in which you would use them:

- You want to run multiple shades at one time, together off of one high voltage wall switch.
- You have parallel wired motors that you are trying to fix.
- You want to remote locate controls in J-boxes by the shades to reduce wiring.
- You want the cheapest, most effective way to control up to twelve motors from one high voltage switch.

Isolating relays are not to be used if the following are your conditions.

- You are planning at any point and time to run the shades from a low voltage system such as AMX, Crestron, Vantage, etc.
- You want to operate a group of shades as two or more groups and together.
- You want to have preset intermediate stop action.
- You want to operate the shades from an IntelliFlex input device such as a sun sensor, IntelliFlex wall switch, IR remote, RF remote, etc.
- You want the controls to come in an electrical enclosure.
- You want to upgrade the system at a later time to work from a computer or other low voltage switching device.



Wiring Instructions
IntelliFlex™ Isolating Relay by Draper

Part Number C157.012

Please Note

① Make sure power is disconnected before installing controls.
② This product is designed to be a job site rescue device by allowing multiple motors to be connected to one motor control or switch and provides group control of these motors. Each motor must have its own ISO Relay. Make sure the total FLA of all motors grouped together does not exceed the load carrying capacity of the switch or motor control being used.
③ When installing an ISO into an enclosure, maintain a minimum of .2" (5mm) spacing in all directions using the supplied spacers. An insulator plate should also be used. Shorts will result in damage to the component.
④ All metal traces may have AC power on them and must be insulated from the user and from electrical ground. An INS-ISO (Draper Part# C199.004) insulation board is provided.
⑤ Large black part may have a small voltage on it immediately after unit is active.
⑥ To achieve Pollution Degree 2 environment, mount in an enclosure with tight fitting seams or one that is gasketed.
⑦ The Main Disconnect and Branch Circuit Protection shall be provided by installer. Protection for shade motor must be provided at the switch or breaker panel.
⑧ Maximum surrounding air temperature 70 degrees Celsius.
⑨ Use copper conductors rated 75 degrees Celsius or higher only, 18-12AWG.

Please Note: This device has not been evaluated for reliability to the Standard for Tests for Safety-Related Controls Employing Solid-State Devices, UL 991 and therefore is not considered suitable for entrapment protection.

Electrical Specifications

Input:
Line Voltage: 115v AC +/- 10%

Output:
115V AC 5 FLA 1/6 HP

Dims: 2.07" L x 1.41" W x 0.82" H
(52.6 x 35.8 x 20.8 mm)
1 Isolating Relay fits in a standard single gang J-Box.

c UL us LISTED E225537 20HN



(For a wiring diagram of more than one Isolating Relay Daisy chained together, see below)

Inserting wire into spring terminal

① Open spring terminal by inserting screw-driver into upper opening.
② Insert wire into lower opening.
③ Remove screwdriver.



Wiring Diagram of more than one Isolating Relay Daisy-Chained



Fabric unrolling from back of roller (standard)

Right hand motor (Standard)
Black—Up
Red—Down

Left hand motor
Black—Down
Red—Up



Fabric unrolling from front of roller (reverse roll)

Right hand motor (Standard)
Red—Up
Black—Down

Left hand motor
Red—Down
Black—Up



DRAPER

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc. Form ISO_WD07-R4 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex control, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

IntelliFlex™ GC4

The GC4 (group control 4 motors) prevents feedback between motors and allows multiple motors to run off a 120V switch. The switches that Draper supplies are 15A so twelve standard motors or three GC4' s are able to run off one switch with GC4' s. To further help you decide if a GC4 is right for you, here are some conditions in which you would use them:

- You want to run multiple shades at one time, together off of 1 high voltage wall switch.
- You want controls in an electrical enclosure and a UL rating on the assembly.
- You want to "home run" wires to a control location.
- You want the cheapest, most effective way to control up to 12 motors from one high voltage switch.

GC4' s are not to be used if the following are your conditions.

- You are planning at any point and time to run the shades from a low voltage system such as AMX, Crestron, Vantage, etc.
- . You want to operate a group of shades as two or more groups and together.
- You want to have preset intermediate stop action.
- . You want to operate the shades from an IntelliFlex input device such as a sun sensor, IntelliFlex wall switch, IR remote, RF remote, etc.
- You want the controls to be remotely located near the motors to reduce wiring.
- You want to upgrade the system at a later time to work from a computer or other low voltage switching device.



Part Number C156.058

Wiring Instructions
IntelliFlex™ GC4 Control by Draper

Please Note

① Make sure power is disconnected before installing controls.
② This product allows up to four motors to be connected to one motor control or switch and provides group control of these motors. Make sure the total FLA of all motors grouped together does not exceed the load carrying capacity of the switch or motor control being used.
③ Up to 3 GC4s (12 motors total) can be banked as long as the switch ratings are not exceeded and 80% of the circuit breaker rating is not exceeded.
④ GC4 enclosure is 8" x 8" x 4".
⑤ The Main Disconnect and Branch Circuit Protection shall be provided by installer.
⑥ Maximum surrounding air temperature 70 degrees Celsius.
⑦ Use copper conductors rated 75 degrees celsius or higher only, 18-12AWG.

Please Note: This device has not been evaluated for reliability to the Standard for Tests for Safety-Related Controls Employing Solid-State Devices, UL 991 and therefore not considered suitable for entrapment protection.

Electrical Specifications

Input:
Line Voltage: 115v AC +/- 10%

Output:
115VAC Largest Motor 1FLA, 4FLA Total

c UL us E258229 LISTED

Inserting wire into spring terminal

① Open spring terminal by inserting screw-driver into upper opening.
② Insert wire into lower opening.
③ Remove screwdriver.





Fabric unrolling from back of roller (standard)

Right hand motor (Standard)
Black—Up
Red—Down

Left hand motor
Black—Down
Red—Up

Interior side

Fabric unrolling from front of roller (reverse roll)

Right hand motor (Standard)
Red—Up
Black—Down

Left hand motor
Red—Down
Black—Up

Interior side

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc.

Form GC4_WD07-R Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex control, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

IntelliFlex™ SC1

The SCI (smart control 1 motor) gives intelligence to standard motor. This intelligence allows you to group shades and run them from low voltage switching. You may run the SC I' s from a number of IntelliFlex inputs. Here are some conditions in which you would use them:

- You want to control shades individually and as a group.
- You want to have up to four preset intermediate stop locations.
- You want to reduce wiring by remotely locating the controls near motors.
- You want to offer the ability to upgrade the system in the future.
- You want to be able to change shade groups and operations in the future no matter the layout of the rooms.
- You want the most intelligent control for a standard motor.
- You want to interface standard motors with a low voltage control system or computer.

SCI's are not to be used if the following are your conditions.

- You want to use high voltage switching to control the shades.
- You want the controls to come in an electrical enclosure.
- You want the cheapest group control operation.
- You do not want to locate the controls near the shades.
- You do not want to learn how to program a control from an IR remote.



Wiring Instructions
IntelliFlex™ SC1 Control by Draper

Part Number C156.065

Please Note

① Make sure power is disconnected before installing controls.
② SC1 has a rated switching capacity of 6 amps.
③ SC1 is a line voltage control, designed to operate one motor. Activation by Low Voltage input commands. If you want to switch two or more motors, ISO relays must be installed in the circuit.
④ SC1 is electrically "hot" on the back of the circuit board. INS-SC1 (Draper Part Number C199.004) insulation board is provided.

Electrical Specifications

Input:
Data: +5v AC BUS Commands
Low Voltage: Dry Contact—0v AC
Line Voltage: 115 V AC +/- 10%

Output: 115V AC 6 FLA per SC1 1/3 HP

Dimensions: 2 1/8" W x 3 1/4" L x 7/8" H.
One SC1 fits in a ***deep*** single gang J-Box.

Wiring Instructions for Controlling One Shade with One SC1



Please Note: *When connecting data "BUS," never link an "Eye" port to another "Eye" port. You may link your BUS from "Eye" to "Aux" or "Aux" to "Aux." All BUS command input devices must connect to an "Eye" port in order to power the input device.*

Inserting wire into spring terminal

① Open spring terminal by inserting screwdriver into upper opening.
② Insert wire into lower opening.
③ Remove screwdriver.



Note: Motor red and black wires will need to "flip" if one motor is right hand and the other is left hand.

Wiring Instructions for Controlling Multiple Shades with One SC1

Please Note: *This configuration will limit SC1 functions.*



Fabric unrolling from back of roller (standard)

Right hand motor (Standard)
Black—Up
Red—Down

Left hand motor
Black—Down
Red—Up



Fabric unrolling from front of roller (reverse roll)

Right hand motor (Standard)
Red—Up
Black—Down

Left hand motor
Red—Down
Black—Up



Please Note:

All input devices (low voltage LED switches, IR eye, RF receiver) which connect to the Eye jack must be connected using ***electrically straight*** 4-conductor modular cable (RJ11). This means colors do not cross over: blue leads to blue, orange to orange, etc. (see diagram below)

Electrically Straight Data Cable



All connection wires must conform to the motor manufacturer's recommendation and prevailing electrical codes. The switch and control system wires should be at least 24 AWG and no larger than 18 AWG.

Using Telephone Cable

If you use standard telephone cable, you must first remove one connector, turn it over and re-attach, to ensure that the cable is electrically straight (see diagram below). Standard phone cable is 26 AWG.





411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2008 Draper Inc. Form SC1_WD08 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex control, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

IntelliFlex™ SGC4

The SGC4 (smart group control 4 motors) gives intelligence to standard motors. This intelligence allows you to group shades and run them from low voltage switching. You may run the SGC4' s from a number of IntelliFlex inputs. Here are some conditions in which you would use them:

- You want to control shades as a group.
- You want the most cost effective group control that works with low voltage switching.
- You want the controls in an electrical enclosure and to be a UL assembly.
- You want to offer the ability to upgrade the system in the future.
- You want to interface standard motors with a low voltage control system or computer.

SGC4's are not to be used if the following are your conditions.

- You want to use high voltage switching to control the shades.
- You want the controls to be remotely located to reduce wiring.
- You want preset intermediate stops or the ability to regroup shades.
- You want to locate the controls near the shades.
- You do not want to learn how to program a control from an IR remote.



Part Number C156.059

Wiring Instructions
IntelliFlex™ SGC4 Control by Draper

Please Note

① Make sure power is disconnected before installing controls.
② SGC4 is a line voltage control, designed to operate up to 4 motors as a group, activated by Low Voltage input commands.
③ SGC4 enclosure is 8" x 8" x 4".
④ Main Disconnect and Branch Circuit Protection provided by installer.
⑤ Maximum surrounding air temperature 50° C.
⑥ Use copper conductors rated 75 degrees Celsius or higher only, 18-12AWG.

Please Note: *This device has not been evaluated for reliability to the Standard for Tests for Safety-Related Controls Employing Solid-State Devices, UL 991 and therefore not considered suitable for entrapment protection.*

Please Note:

All input devices (low voltage LED switches, IR eye, RF receiver) which connect to the Eye jack must be connected using ***electrically straight*** 4-conductor modular cable (RJ11). This means colors do not cross over: blue leads to blue, orange to orange, etc. (see diagram below)

Electrically Straight Data Cable



All connection wires must conform to the motor manufacturer's recommendation and prevailing electrical codes. The switch and control system wires should be at least 24 AWG and no larger than 18 AWG.

Electrical Specifications

Input:

Data: +5v AC BUS Commands
Low Voltage: Dry Contact—0v AC
Line Voltage: 115v AC +/- 10%

Output:

115v AC Largest Motor 1FLA, 4FLA Total

c UL us LISTED E258229

Using Telephone Cable

If you use standard telephone cable, you must first remove one connector, turn it over and re-attach, to ensure that the cable is electrically straight (see diagram below).



Fabric unrolling from back of roller (standard)

Right hand motor (Standard)
Black—Up
Red—Down

Left hand motor
Black—Down
Red—Up

Interior side

Fabric unrolling from front of roller (reverse roll)

Right hand motor (Standard)
Red—Up
Black—Down

Left hand motor
Red—Down
Black—Up

Interior side

Note: Motor red and black wires will need to "flip" if one motor is right hand and the other is left hand.

Max of 100 feet of low voltage-cable between controls, or control and input with circuit board.



Inserting wire into spring terminal

① Open spring terminal by inserting screw-driver into upper opening.
② Insert wire into lower opening.
③ Remove screwdriver.

DRAPER
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc.

Form SGC4_WD07-R2 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex control, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

IntelliFlex™ SPGC4

The SPGC4 (smart programmable group control 4 motors) gives intelligence to standard motors. This intelligence allows you to group shades and run them from low voltage switching. You may run the SPGC4' s from a number of IntelliFlex inputs. Here are some conditions in which you would use them:

- You want to control shades individually and as a group.
- You want to have up to four preset intermediate stop locations.
- You want the controls in an electrical enclosure and to be a UL assembly.
- You want to offer the ability to upgrade the system in the future.
- You want to be able to change shade groups and operations in the future no matter the layout of the rooms.
- You want the most intelligent control for a standard motor.
- You want to interface standard motors with a low voltage control system or computer.

SPGC4's are not to be used if the following are your conditions.

- You want to use high voltage switching to control the shades.
- You want the controls to be remotely located to reduce wiring.
- You want the cheapest group control operation.
- You want to locate the controls near the shades.
- You do not want to learn how to program a control from an IR remote.



Wiring Instructions
IntelliFlex™ SPGC4 Control by Draper

Part Number C156.060

Please Note

① Make sure power is disconnected before installing controls.
② SPGC4 is a line voltage control, designed to individually operate 4 motors, activated by Low Voltage input commands.
③ SPGC4 enclosure is 8" x 8" x 4".
④ The Main Disconnect and Branch Circuit Protection shall be provided by installer.
⑤ Maximum surrounding air temperature 50° C.
⑥ Use copper conductors rated 75 degrees Celsius or higher only, 18-12AWG.

Please Note: *This device has not been evaluated for reliability to the Standard for Tests for Safety-Related Controls Employing Solid-State Devices, UL 991 and therefore not considered suitable for entrapment protection.*

Electrical Specifications

Input:

Data: +5v AC BUS Commands
Low Voltage: Dry Contact—0v AC
Line Voltage: 115v AC +/- 10%

c UL us LISTED E258229

Output:

115VAC Largest Motor 1FLA, 4FLA Total

Max of 100 feet of cable between controls, or control and input with circuit board.




To Switch, splitter or other input device
Dry Contacts
To Eye Port
Aux Port
Eye Port
Aux Port
To Motor Neutral Red (Dir) Black (Dir)
Neutral
AC (115V AC)
To Motor Neutral Red (Dir) Black (Dir)
Please Note: Connect all Ground wires to ground block provided.
Eye Port
Aux Port
Dry Contacts
To Motor Black (Dir) Red (Dir) Neutral
Eye Port
Aux Port
Dry Contacts
Data cable from Aux Port to Eye port of next SPGC4
To Motor Black (Dir) Red (Dir) Neutral

Inserting wire into spring terminal

① Open spring terminal by inserting screw-driver into upper opening.
② Insert wire into lower opening.
③ Remove screwdriver.



Please Note: Connect Ground wires as noted on enclosure

Please Note:

All input devices (low voltage LED switches, IR eye, RF receiver) which connect to the Eye jack must be connected using ***electrically straight*** 4-conductor modular cable (RJ11). This means colors do not cross over: blue leads to blue, orange to orange, etc. (see diagram below)

Electrically Straight Data Cable



All connection wires must conform to the motor manufacturer's recommendation and prevailing electrical codes. The switch and control system wires should be at least 24 AWG and no larger than 18 AWG.

Using Telephone Cable

If you use standard telephone cable, you must first remove one connector, turn it over and re-attach, to ensure that the cable is electrically straight (see diagram below). Standard phone cable is 26 AWG.



Fabric unrolling from back of roller (standard)

Right hand motor (Standard)
Black—Up
Red—Down

Left hand motor
Black—Down
Red—Up

Interior side

Fabric unrolling from front of roller (reverse roll)

Right hand motor (Standard)
Red—Up
Black—Down

Left hand motor
Red—Down
Black—Up

Interior side

DRAPER

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc. Form SPGC4_WD07-R2 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex control, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

IntelliFlex™ Inputs

We have many different low voltage input devices for controlling shades through IntelliFlex. Here is a listing and brief description of each input available to you.

- IR control- This is an IR eye plugged in an SC1, SGC4, or SPGC4 to receive IR remote commands.

- RF control- This is an RF receiver plugged in an SC1, SGC4, or SPGC4 to receive RF remote commands. Long range antennas are available.

- IntelliFlex wall switch- This switch comes as a BUS version which plugs directly into a SC1, SGC4, or SPGC4 or an RF version which talks to an RF receiver. These versions of the switch are programmable to send out whatever commands are desired. Dry contacts version which are not programmable are also available for some types.

- RS 232 interface- This is an RS 232 bridge to run shades from RS 232 commands. These commands can give full function to the controls.

- Sun sensors- This is an interior sensor that will read light intensity and run a group of shades up and down accordingly. It does not track the sun' s movement.

- Timer- This item will run a group of shades up and down at given times of the day.

- Dry Contact Converter- This item takes dry contact commands and turns them into bus commands for the SC1's to respond.

- SolarFlex- This is a sun tracking software which is programmed to drive a specific building's shades per the needs of the end user based on the sun's position.

- Dry Contacts- The SC1, SGC4, and SPGC4 are built with dry contacts already on them so one can connect dry contacts to one of the controls to drive it. The dry contacts on the controller itself will not communicate on the BUS line.

- Two-way communication on the bus line can be accomplished with certain input set-ups and cabling. Ask Draper for more details.



IR control



RF control



IntelliFlex wall switch



RS 232 interface



Sun sensor



Timer



Dry Contact Converter



Dry Contacts

Input Device Sample Configuration

IntelliFlex™ by Draper


1 sample "Bus" System shown (motors on line voltage side). Multiple "Systems" may be combined and "linked" in an installation.
To Motor (s)
SC1, SPGC4 or SGC4
From "Aux" To "Aux" (can also be "Aux to Eye")*
From "Aux" To "Eye"*
From "Aux" To "Aux" (can also be "Eye to Aux" if "Eye" port not in use)*
From "Aux" To "Aux" (can also be "Eye to Aux" if Eye port is not in use)*
To "Eye" Port (+75mA)
Splitter
Eye Eye Main Aux
PSI 60 (-9 mA)
SPDT: Keyswitch, Mag. switch, etc.
Sun Sensor (-13 mA)
PSSW
Sun Sensor Eye
RR24 RF Receiver (-17 mA)
RF Signal to Receiver
IntelliFlex Switch (Local/Sub-group/ Master Control) (-8 mA)
IR Receiving Eye (-2 mA)
IR Signal to Eye
R2D7 (-17 mA)
PC/ Home Automation

***Never connect "Eye" port to "Eye" port**

Please Note:
Wiring diagrams are available for each control and input device at www.draperinc.com.

Notes on Cable Lengths:

You can have a total of approximately 100 feet of cable between SC1s, up to a maximum of 1000 feet. However, any device that includes a Repeater can drive 1000 feet of cable regardless.

IR Eyes have no circuit board and can only drive about 20' of cable.

Notes on Power Consumption:

Any input device may be connected to any available Eye port. All Eye ports are "powered" by the "SC1" they feed off of. Each SC1 Eye port provides 75 milliAmps at 5v of power to the connected input devices. You may attach any combination of input devices to an SC1 Eye port, as long as the ***combined*** power requirements do not exceed the available power from the SC1 (see chart below).

Input Device Power Consumption Chart

Input Device[1]	Power Consumption (milliAmps)
RF Remote Receiver	17
IR Receiver Eye	2
Sun Sensor	13
IntelliFlex Bus Switch	8
IntelliFlex RF Switch (not on Bus)	0
IntelliFlex Dry Contact Switch (not on Bus)	0
PSI60	9
R2D7 (RS232 Translator)	17
Hardwired Keypad	1
RF Keypad (not on Bus)	0

[1] IR Eye can drive a maximum of 25 SC1s. Other accessories can drive a maximum of 70 SC1s.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc. Form IntelliFlex-InputDeviceConfig07 Printed in U.S.A.

Installation Instructions
IntelliFlex™ IR Remote Control by Draper

Caution:

① The IR Receiver Eye must connect to an "Eye" Jack on an SC1 or Splitter. If it connects to a Splitter, then the Main Jack of the Splitter must connect to the "Eye" Jack of an SC1.
② Main Jack on splitters connects to Eye Jack on SC1.
③ Any Aux Jack can be connected to any Aux or Eye Jack.
④ Never connect any two Eye Jacks together.
⑤ For IR commands to work, or for remote programming, there must be at least one Eye connected to one of the Eye Jacks.

Installing the IR Eye

The IR Eye must connect to an Eye Jack on an SC1 (see Fig. 1) or Splitter. If the eye connects to a Splitter, then the Main Jack of the Splitter must connect to the Eye Jack of an SC1. The IR Eye is line-of-sight: It must be visible to "see" the infrared signal from the transmitter.



IR Eye in plastic box shown. IR Eye with length of modular cable is also available (see page 2), and plugs into the SC1 or other Bus control in the same fashion.

Figure 1

The combined length of ALL cables in the system (Eye to SC1, plus SC1 to SC1, plus Splitter to SC1, plus Eye to Splitter, plus Splitter to Splitter) can be up to 100 feet per SC1 without problems. The Repeater/Timer Interface with built-in IR filter (Part # C072.026) can be used if additional length is needed. Contact Draper for further information.

If the cable length is too long, some units may operate sporadically where the motor pulses on and off. Some units may not operate at all, or may operate intermittently.

Similar symptoms can come from interference in the room. Sunlight is a very strong infrared source. Try to place the sensor out of direct or bright reflected sunlight. The Repeater/Timer Interface with built-in IR filter (Part # C072.026) can be used to help solve this problem.

Sunlight will also reduce your effective range. Expected line-of-sight range with no interference is at least 50 feet, usually as much as 100 feet. Electronically ballasted fluorescent lighting and Halogen lights can cause similar trouble.

None of the wires associated with the IR sensor should be run next to power lines. And all wires should be kept at least 18" away if run parallel to a power line. If they must go near power lines, they should cross at a right angle. They may need to be shielded if running near very noisy power lines.

One eye can be connected to multiple boards by "daisy-chaining" SC1s together, or using a Splitter. Never use a standard telephone splitter for this connection. Larger splitters are available—contact Draper for more information. All connections are made with standard "telephone" type cord, but connectors are "flipped" so a standard phone cable will not work. See "A Note on Wiring" on page 2. The installer will need a 6P4C telephone plug crimping tool, with 6P4C plugs, and silver satin 4 conductor phone wire (all are available from Draper). 6P6C plugs will also work, as will 6 conductor wire with these plugs.

When connected together, all receivers must be powered for any of them to work. Any unit that is not powered will "short out" the IR signal. Manual inputs will work but the IR will not.

If a splitter is not available, the wiring can be done manually. Assuming the yellow wire is on the right of the plug with the cable toward you and the "flipper" away from you (this is how all SC1s are wired), then:

① The black wire is common or "ground" (not AC or earth ground) which is the same as the common pin on the 3 wide screw terminal for manual switch. Connect all black wires together.
② The yellow wire (sometimes white) is the demodulated IR signal. This line is normally about 5 volts (pulled high by a resistor on the SC1). Connect all these wires together.
③ The red wire is 5 Volt power. Do not connect 5 volt lines of multiple receivers together. Connect the red wire from any one receiver to the red wire from the eye or the accessory unit.
④ All green wires are unused and should be cut off and isolated from each other.
⑤ Make sure that none of the wires "flip"—i.e., yellow is always on the right. Multiple eyes allow operation from more than 1 room, or to cover the room more completely.

Operation from multiple rooms can also be done using standard IR repeater systems, such as X-10 Powermid® or products from Xantech. Radio repeaters such as a remote extender or Leapfrog® can also be used.

When using a Xantech IR repeater system, do not attempt to run the signal directly from the connecting block into the SC1. Simply place an emitter near one of the IR Eyes.

Installing IR Eye and SC1 into JBox


Plastic Snap
INS-SC1
Short screws
Eye Jack for connecting control devices to SC1
To Optional Manual Switch
To AC Power and Motor
.062" Nylon Washer
Earth Ground
Please Note: Orientation MUST be as shown so the ground terminal connection on the terminal block connects to the aluminum plate via the screw.
1" flat head screws in J-box
Infrared Cover fits in Decora Plate

Please see page 2 for more installation information and IR codes.

Powermid™ is a registered trademark of X-10.
Leapfrog® is a registered trademark of Terk Technologies Corporation.

Please Note:

Draper recommends using a PDA or PC to program your IntelliFlex controls. Software is available at www.draperinc.com.
For button press sequences to manually program, see "SC1 Quick Reference Guide" at www.draperinc.com

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999 ▮ fax 765-987-7142
e-mail draper@draperinc.com ▮ www.draperinc.com

Copyright ©2004 Draper Inc. Form IntelliFlex-IR_Inst04 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex IR control, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; fax (765) 987-7142; or e-mail draper@draperinc.com.

Installing IR Eye Only into J-Box



1" flat head screws in J-box



Infrared Cover fits in Decora Plate

IR Codes

IR wavelength is 950 nm. Light is modulated at 38 KHz with 1/3 duty cycle.

An on pulse must be at least 158 µseconds (µs) long (6 cycles) and should not be longer than 448 µs (17 cycles).

From the start of a pulse till the start of the next pulse is 1050 µs for a "0 bit", and 2000 µs for a "1 bit".

A Flash is 11 pulses (10 bits), minimum time between flashes (interflash time) is 11 mseconds (ms). When using the small eye the minimum interflash time is 25 ms, 30 ms is recommended. There is NO preamble.

Channel 1 OPEN sequence is 0101000010. The sequence always starts with 01, so for simplicity strip that off, and we get 0100 0010 = hex 42 (see figure below).

Please Note: low = off, high =38 KHz signal on.



The complete table of codes (in hex) is:

OPEN1	42	OPEN13	40
CLOSE1	22	CLOSE13	20
OPEN2	62	OPEN14	60
CLOSE2	12	CLOSE14	10
OPEN3	32	OPEN15	30
CLOSE3	0a	CLOSE15	08
OPEN4	4a	OPEN16	48
CLOSE4	2a	CLOSE16	28
OPEN5	1a	OPEN17	18
CLOSE5	06	CLOSE17	04
OPEN6	46	OPEN18	44
CLOSE6	26	CLOSE18	24
OPEN7	16	OPEN19	14
CLOSE7	0e	CLOSE19	0c
OPEN8	56	OPEN20	54
CLOSE8	36	CLOSE20	34
OPEN9	4e	OPEN21	4c
CLOSE9	2e	CLOSE21	2c
OPEN10	5a	OPEN22	58
CLOSE10	3a	CLOSE22	38
OPEN11	02	OPEN23	1c
CLOSE11	72	CLOSE23	70
OPEN12	6a	OPEN24	68
CLOSE12	66	CLOSE24	64
OPEN ALL (1-12)	76	OPEN ALL (13-24)	74
CLOSE ALL (1-12)	6e	CLOSE ALL (13-24)	6c
STOP	52		

IR Eye Only



Optional Cable Accessories

Splitter



Modular Jack Adapter



Modular Cable Coupler



A Note on Wiring

The IR Receiver Eye must be plugged in to an open "Eye" jack (see diagram on page 1). All input devices connect using ***electrically straight*** 4-conductor modular cable.

Please note: *If you use standard telephone cable, you must first remove one connector, turn it over and re-attach, to ensure that the cable is electrically straight (see diagram below).*

Please Note:

Draper recommends using a PDA or PC to program your IntelliFlex controls. Software is available at www.draperinc.com.

For button press sequences to manually program, see "SC1 Quick Reference Guide" at www.draperinc.com

Installation Instructions
IntelliFlex™ RF Remote Control by Draper

① The Radio Frequency receiver must be connected to an Eye Jack on an SC1 or splitter.
② Mount receiver with the antenna pointing up.
③ Do not mount receiver on or near a metal surface.
④ Each RF receiver must be "trained" to "hear" each transmitter before it will work.
⑤ Each receiver can "learn" to "hear" up to five different transmitters.

Installing the Receiver

Connect the receiver to the Eye Jack on an SC1 or splitter (see Fig. 1). If the eye connects to a splitter, then the Main Jack of the Splitter must connect to the Eye Jack of an SC1.

Mount the receiver with the antenna pointing up. For longer range reception, detach the provided antenna and attach the optional Long Range Antenna—Part # C267.001 (see Fig. 2).

Please Note: *For information on installing SC1 or other "BUS" command controls, please see the instruction sheet for the appropriate item.*



Figure 1



Figure 2

Training Your RF Receiver

The receiver can "learn" up to 5 different transmitters. It ships from the factory with NO transmitters learned: you must train it in the field to work with your specific transmitters. If the receiver is new with no transmitters learned, the LED will automatically come on when plugged into an "Eye" port.

① Press and release the "Learn Transmitter" button on the receiver. The red LED will come on if 5 transmitters have not already been learned. The unit is now ready to learn another radio transmitter.
② Press any button on the radio transmitter. The LED on the receiver will go out. This transmitter is added to the list of known transmitters. The receiver returns to normal operation after it has learned a transmitter. If this transmitter is already known to the receiver, the LED will remain lit because the transmitter does not need to be learned again.

If no command is received within 10 seconds:

① The red LED will flash off, then on, and then go out. No new transmitters were learned.
② If no transmitters are known, the LED will turn back on immediately.

If the red LED is on and the learn button is pressed and released:

① The red LED will turn off with no changes to the learned list.
② If no transmitters are known, the LED will turn back on immediately.

If no transmitters are known (factory default):

① The red LED will turn on as soon as the unit is powered.
② The red LED will flash every 10 seconds until a transmitter is learned.
③ Pressing the learn button has no meaning while in this mode (the LED will turn off while the button is pushed).

To clear all known transmitters:

① Press and hold the learn button for 5 seconds. The red LED will blink on and remain on, until a new transmitter is learned.
② Release the button, the red LED will come on. The unit is ready to learn the 1st transmitter.

Please Note: *If you press and release the learn button and the red LED does not come on, the list may be "full" and no more transmitters can be learned. The unit may also not be powered correctly—to fix this, clear receiver and start over.*

The receiver will not pass commands to the SC1:

① While in the learn mode (the red LED is on).
② While the button is pressed.

Please Note: *The stop command will be sent to the SC1 system if the transmitter's STOP button is still pressed when the receiver exits from learn mode after learning the transmitter.*

Installing the RF Keypad or Wall Switch

If using an RF Wall Mounted Keypad or RF Wall Switch, first test for reception and successful operation of the switch in the desired location. Then, cut hole in appropriate location, attach transmitter module to switch or keypad using modular cable, and attach switch to wall.

Please see Fig. 3 (below), and information provided with the specific switch or keypad for more information. Three AAA batteries required.



Figure 3

RF Handheld Transmitters



Please see page 2 for information on radio frequencies and codes.

Please Note:

For button press sequences to manually program your control, see "SC1 Quick Reference Guide" at www.draperinc.com

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc. Form IntelliFlex-RF_Inst07 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex RF control, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

A Note on Interference

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

① Reorient or relocate the receiving antenna.
② Increase the separation between the equipment and receiver.
③ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
④ Consult the dealer or an experienced radio/TV technician for help.

Operation with non-approved equipment is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Radio Codes

Radio Frequency is 418 MHz ± 75 KHz, on-off keying.



All times in the following description are nominal with a tolerance of ± 5%, however, all times must change proportionally.

A packet of data consists of:

A start sequence, 20 address bits, and 16 data bits. The packet is similar to that used by the Holtek brand of data encoder chips.

The Start sequence consists of:

471 µs on, 471 µs off, 973 µs on, 973µs off, 471 µs on, 471 µs off, 973 µs on, 973 µs off, 471 µs on.

Address & data bits consist of:

A "0 bit" being defined as 471 µs off, 973 µs on,
A "1 bit" being defined as 973 µs off, 471 µs on.

The start sequence plus the address and data bits make a packet 57 msec long. There must then be a pause of 17 msec before the packet is transmitted again.

The address is encoded in 20 bits (A0 = least significant bit, A8 = most significant bit of 512 possible addresses):

A0 0 A1 0 A2 0 A3 0 A4 A5 A6 A7 A8 1 1 1 1 1 1 1

The button data is encoded in 16 bits (D0 = least significant bit, D7 = most significant bit of 256 possible numbers):

1 D0 1 D1 1 D2 1 D3 1 D4 1 D5 1 D6 1 D7

The button data is converted into a command compatible with the "BUS" connecting receiver controls together.

The complete table of codes (in hex) is:

OPEN1	42	OPEN10	5a	OPEN19	14
CLOSE1	22	CLOSE10	3a	CLOSE19	0c
OPEN2	62	OPEN11	02	OPEN20	54
CLOSE2	12	CLOSE11	72	CLOSE20	34
OPEN3	32	OPEN12	6a	OPEN21	4c
CLOSE3	0a	CLOSE12	66	CLOSE21	2c
OPEN4	4a	OPEN13	40	OPEN22	58
CLOSE4	2a	CLOSE13	20	CLOSE22	38
OPEN5	1a	OPEN14	60	OPEN23	1c
CLOSE5	06	CLOSE14	10	CLOSE23	70
OPEN6	46	OPEN15	30	OPEN24	68
CLOSE6	26	CLOSE15	08	CLOSE24	64
OPEN7	16	OPEN16	48		
CLOSE7	0e	CLOSE16	28	OPEN ALL	76
OPEN8	56	OPEN17	18	CLOSE ALL	6e
CLOSE8	36	CLOSE17	04	OPEN ALL (13-24)*	74
OPEN9	4e	OPEN18	44	CLOSE ALL (13-24)*	6c
CLOSE9	2e	CLOSE18	24	STOP	52

**** These commands correspond to channel 25 on the R2D7 RS232 Serial Translater.***

Optional Cable Accessories

Splitter



Modular Jack Adapter



Modular Cable Coupler



A Note on Wiring

The RF Receiver must be plugged in to an open "Eye" jack (see diagram on page 1). All input devices connect using ***electrically straight*** 4-conductor modular cable.

Please note: *If you use standard telephone cable, you must first remove one connector, turn it over and re-attach, to ensure that the cable is electrically straight (see diagram below).*



IntelliFlex™ Wall Switch

by DRAPER

2 button, 1 channel—horizontal switch for 1 shade or group of shades



121105—BUS command
121106—Dry Contact
121107—RF (requires 1 RFTM p/n C072.022, ordered separately)

2 button, 2 channel—sequencing switch for 1 shade or group of shades



121108—BUS command
121109—Dry Contact
121110—RF (requires 1 RFTM p/n C072.022, ordered separately)

3 button, 3 channel—sequencing switch for 1 shade or group of shades



121111—BUS command
121112—Dry Contact
121113—RF (requires 1 RFTM p/n C072.022, ordered separately)

3 button, 1 stop—vertical switch for 1 shade or group of shades



121114—BUS command
121115—RF (requires 1 RFTM p/n C072.022, ordered separately)

4 button, 2 channel—horizontal switch for 2 shades or groups of shades



121116—BUS command
121117—Dry Contact
121118—RF (requires 1 RFTM p/n C072.022, ordered separately)

4 button, 4 channel—sequencing switch for 4 shades or groups of shades



121119—BUS command
121120—Dry Contact
121121—RF (requires 1 RFTM p/n C072.022, ordered separately)

4 button, 2 stop—vertical switch for 1 shade or group of shades



121122—BUS command
121123—RF (requires 1 RFTM p/n C072.022, ordered separately)

5 button, 3 stop—vertical switch for 1 shade or group of shades



121124—BUS command
121125—RF (requires 1 RFTM p/n C072.022, ordered separately)

5 button, 5 channel—sequencing switch for 1 shade or groups of shades



121126—BUS command
121127—RF (requires 1 RFTM p/n C072.022, ordered separately)

6 button, 3 channel—horizontal switch for 3 shades or groups of shades



121128—BUS command
121129—Dry Contact
121130—RF (requires 1 RFTM p/n C072.022, ordered separately)

6 button, 6 channel—sequencing switch for 6 shades or groups of shades



121131—BUS command
121132—Dry Contact
121133—RF (requires 1 RFTM p/n C072.022, ordered separately)

6 button, 1 stop, 2 groups—vertical switch for 2 shades or groups of shades



121134—BUS command
121135—RF (requires 1 RFTM p/n C072.022, ordered separately)

6 button, 4 stop—vertical switch for 1 shade or group of shades



121136—BUS command
121137—RF (requires 1 RFTM p/n C072.022, ordered separately)

6 button, 6 channel—vertical switch for 1 shade or group of shades



121138—BUS command
121139—RF (requires 1 RFTM p/n C072.022, ordered separately)

8 button, 8 channel—sequencing switch for 8 shades or groups of shades



121140—BUS command
121141—RF (requires 1 RFTM p/n C072.022, ordered separately)

8 button, 4 channel—horizontal switch for 4 shades or groups of shades



121142—BUS command
121143—RF (requires 1 RFTM p/n C072.022, ordered separately)

8 button, 2 stop, 2 groups—vertical switch for 2 shades or groups of shades



121144—BUS command
121145—RF (requires 1 RFTM p/n C072.022, ordered separately)

10 button, 10 channel—sequencing switch for 10 shades or groups of shades



121146—BUS command
121147—RF (requires 1 RFTM p/n C072.022, ordered separately)

10 button, 5 channel—horizontal switch for 5 shades or groups of shades



121148—BUS command
121149—RF (requires 1 RFTM p/n C072.022, ordered separately)

10 button, 3 stop, 2 groups—vertical switch for 2 shades or groups of shades



121150—BUS command
121151—RF (requires 1 RFTM p/n C072.022, ordered separately)

12 button, 12 channel—sequencing switch for 12 shades or groups of shades



121152—BUS command
121153—RF (requires 1 RFTM p/n C072.022, ordered separately)

12 button, 6 channel—horizontal switch for 6 shades or groups of shades



121154—BUS command
121155—RF (requires 1 RFTM p/n C072.022, ordered separately)

12 button, 4 stop, 2 groups—vertical switch for 2 shades or groups of shades



121156—BUS command
121157—RF (requires 1 RFTM p/n C072.022, ordered separately)

Please Note: For wiring and programming instructions, please see page 2.

Please Enter Appropriate Information:

Switch: _____ How Many? _____
Switch: _____ How Many? _____
Switch: _____ How Many? _____
Switch: _____ How Many? _____

PROJECT: _____

_____

ARCHITECT: _____

CONTRACTOR: _____

SUPPLIER: _____

DATE: _____ REVISED: _____

DRAPER
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright © 2007 Draper Inc. Form IntelliFlexWall Switch_Sub07 Printed in U.S.A.

IntelliFlex Wall Switch by Draper

Programming IntelliFlex Switch

Dry Contact: Does not have a Bus connection, and is not programmable. It is somewhat configurable, based on how it is connected—it must be connected directly to each device it is controlling.

Bus: Programming requires physical contact with the back of the switch. This allows programming of which button sends which command, and other options. The switch must be powered by installing it on the SC1 Bus. Plug it into any available "Eye" jack.

RF: Battery operated. Programming the RF switch requires physical contact with the back of the switch, and allows programming of which button sends which command, along with other options. When replacing batteries, test switch to make sure it works. If not, remove batteries, wait a few seconds, then re-insert them. The switch may operate with low batteries, but programming may not work.

Programming Switch "Locally" Using IR Transmitter

Press programming button on back of switch. Red LED on back of switch will come on, indicating it is in program mode. This method uses the eye on the back of the switch, so you must use an IR transmitter for programming, and you must have access to the back of the switch. Bus commands are ignored during this process.

To set button "#" on the switch to send a new "command":

① Press programming mode button on back of switch (red LED appears).
② Press and release the switch button you want to program. The LED will change from red to green.
③ Press the command on the IR transmitter you want to be assigned at the button you just selected (pressing "Stop" at this point will assign the stop command to the selected button).
④ The LED will go back to red and you are back in program mode; e.g. to program the top left button to send Close 7: press the top left button, then press Close 7 on the IR transmitter.

Clear button "#":

Press programming mode button on back of switch (red LED will appear). Press OPEN "#" on the IR transmitter, where "#" is the switch button number to clear. The red LED will blink off then back on, and you are back in program mode.

Reset to factory default:

Press programming mode button on back of switch(red LED will appear). Press CLOSE ALL on IR transmitter. The red LED will blink off then back on, and you are back in program mode. If this is an RF switch, the radio address will not change.

Exit programming mode:

Press STOP on the IR transmitter, and LED will turn off; or, LED will turn off automatically after 10 seconds of no IR commands or buttons pushed.

Please Note

The eye on the back of the switch is only for programming and will not act as a receiving eye.

Hardwired "Bus" Command Switch



RF "Bus" Command Switch



Dry Contact Switch (not programmable)

(Switch Front/ Button Map)





(Switch Back/ Board Map)

Please Note: This drawing indicates all possible connection and button locations. Your switch may not have the same number of buttons or connections, but their locations will be consistent with these "maps."

Dry Contact switch is not programmable.

Installation Instructions
IntelliFlex™ Wall Switch by Draper

RF "Bus" Wall Switch



"Bus" Wall Switch



Dry Contact Wall Switch

(Switch Front/ Button Map)



(Switch Back/ Board Map)



Please Note: This drawing indicates all possible connection and button locations. Your switch may not have the same number of buttons or connections, but their locations will be consistent with these "maps."

Compare your switch with these diagrams, and wire the buttons and connections on your switch accordingly.

Dry Contact switch is not programmable. Dry Contact switch can be connected to a Bus via a PSI60.

Please Note: For programming instructions, please see page 2.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc. Form IntelliFlex-WallSwitch_Inst07 Printed in U.S.A.

If you encounter any difficulty installing or servicing your IntelliFlex Switch, call your dealer or Draper, Inc., Spiceland, Indiana, (765) 987-7999; or fax (765) 987-7142.

Programming IntelliFlex Switch

Dry Contact: Does not have a Bus connection, and is not programmable. It is somewhat configurable, based on how it is connected—it must be connected directly to each device it is controlling. Can be connected to a Bus via PSI60.

RF: Battery operated. Programming the RF switch requires physical contact with the back of the switch, and allows programming of which button sends which command, along with other options. When replacing batteries, test switch to make sure it works. If not, remove batteries, wait a few seconds, then re-insert them. The switch may operate with low batteries, but programming may not work.

Programming Switch "Locally" Using IR Transmitter

Press programming button on back of switch. Red LED on back of switch will come on, indicating it is in program mode. This method uses the eye on the back of the switch, so you must use an IR transmitter for programming, and you must have access to the back of the switch. Bus commands are ignored during this process.

To set button "#" on switch to send a new "command":

① Press programming mode button on back of switch (red LED appears).

② Press and release the switch button you want to program. The LED will change from red to green.

③ Press the command on the IR transmitter you want to be assigned at the button you just selected (pressing "Stop" at this point will assign the stop command to the selected button).

④ The LED will go back to red and you are back in program mode; e.g. to program the top left button to send Close 7: press the top left button, then press Close 7 on the IR transmitter.

Clear button "#":

Press programming mode button on back of switch (red LED will appear). Press OPEN "#" on the IR transmitter, where "#" is the switch button number to clear. The red LED will blink off then back on, and you are back in program mode.

Reset to factory default:

Press programming mode button on back of switch(red LED will appear). Press CLOSE ALL on IR transmitter. The red LED will blink off then back on, and you are back in program mode. If this is an RF switch, the radio address will not change.

Change RF switch's radio address:

Press programming mode button on back of switch (red LED will appear). Press Open 13 on the IR transmitter. Red LED will blink off then back on, and the radio address will be changed.

Exit programming mode:

Press STOP on the IR transmitter, and LED will turn off; or, LED will turn off automatically after 10 seconds of no IR commands or buttons pushed.

Please Note

The eye on the back of the switch is only for programming and will not act as a receiving eye.

Installation Instructions

IntelliFlex™ R2D7 RS232 Professional Integration Interface by Draper

Please Note

① Includes free "GUI" software capable of scheduling timed events and global alignment positioning of shades.
② For information on programming and operation, see IntelliFlex Programmer instructions available at www.draperinc.com.
③ This input device can be used with SC1, SGC4 or SPGC4.


To Bus System 7 (or to RF Transmitter)
To Bus System 6
To Bus System 5
To Bus System 4
To RS232 Port:
Yellow = Rx (Receive data from control system)
Green = Tx (Transmit data to control system)
Red = Unused
Black = Gnd (Signal Ground)
To Bus System 1
To Bus System 2
To Bus System 3

Codes and Technical Information

Serial Port to Motor Link		
Information	Data	Number of characters [1]
Header (Start of command)	* (asterisk) for use on RP B US	1
Subsystem number or Administration command	0 [2] – 7 if BUS, 7 – 99 if Radio V [3] = report version R = make port 7 Radio [4] B = make port 7 BUS	1 or 2
Command [5]	o = open c = close s = stop p = program q [6] = quit sending	1
Channel [7]	00 [8] –60 [9]	2
Time to send [10] [11]	0 0 0 [12] – 9 9 9 20th of seconds [13] (this value is optional)	3
Terminator	; (semicolon) or "CR" (enter key)	1
Pause	Send a command on an unused channel for the desired pause time.	

Motor Link to Serial Port	
Event	R2D7 sends
Powered up	"version, X-on"
Terminator is received	"LF" if good command "U" sent if command cannot be understood "CR" is sent after command has been relayed to motors
Buffer [14] overflows and all data is purged	"O" is sent
Buffer is half full	"X-off" (Ctrl-S)
Buffer is empty	"X-on" (Ctrl-Q), but only if X-off was previously sent

Special characters		
Character	Description	ASCII Character Number
" ; "	Semicolon, signifies end of command	59 (0x3B)
" CR "	Carriage return, signifies end of command	13 (0x0D)
" * "	Asterisk, Shift 8 on most keyboards	42 (0x2A)
" LF "	Line feed, ignored (not used)	10 (0x0A)
"X-off "	Ctrl-S on most keyboards, requests sender to stop sending	19 (0x13)
"X-on "	Ctrl-Q on most keyboards, requests sender to resume sending	17 (0x11)

You may also need ...

Serial Port Adapter

Converts a standard DB9 serial output of a PC into an RJ11 connection providing RS232 serial commands.



USB-to-DB9 Serial Port Converter

Serves as a bridge between USB port and standard RS232 Serial Port.



1. Total message length may be as short as 2 and as long as 10 characters, typically 6.
2. 0 means ALL systems, for super groups ALL does not include the radio channels.
3. Version reports "2.1" then R if administered as Radio, or B if BUS, followed by carriage return (All characters after V in this command are ignored).
4. Radio requires a RF TM be plugged into port 7 jack.
5. Case is important: o is different from O and so on.
6. Stop sending a forever command. Any other command will stop transmission, but an error will be reported.
7. If command is stop or quit, then this value is optional and ignored.
8. 00 = ALL.
9. 60 = "cut strap ALL" (note that version 2.0 used 25 for this channel).
10. If no digits, then the command is sent for 2 seconds, except for stop and program which are sent for ¼ second.
11. Time between commands = .5 sec if multiple commands are buffered (Time = .1 sec after a stop).
12. 000 = Forever, use the q command to stop transmission.
13. Max timed pulse = 50 sec. If this is a radio command, the value is rounded up to the nearest 10th second.
14. Buffer is 120 bytes long.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999 ▮ fax 765-987-7142
e-mail draper@draperinc.com ▮ www.draperinc.com
Copyright ©2004 Draper Inc. Form IntelliFlex-RS232_Inst04 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex RS232 Professional Integration Interface, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; fax (765) 987-7142; or e-mail draper@draperinc.com.

Connect to the Sun and Wind Sensor as shown:



All wires labeled “Common” are connected together and are electrically the same as the Black wire on the Bus; any common wire can be used in place of any other common wire in the drawing.
The Light Sensor may be connected to the spring-loaded connector or to the sensor jack. For best results, use only one of the Light Sensors shown. More than one light sensor can be installed on either or both connections; however, if this is done the sensors' scale is disturbed. Sharing a Light Sensor between two Sun and Wind Sensors is not supported. The actual light sensor is the small round device in the box. This part does not have to be in direct sunlight, but it may be if desired. (If the indoor white box is in direct sunlight it may discolor over time.) The small white box must NOT be mounted outdoors—it is NOT weatherproof. A weatherproof sensor may easily be connected to the spring-loaded connector. If the sensor becomes disconnected, then the control unit will not be able to detect sunlight and will report total darkness all the time. The wire to the light sensor may be up to 500 feet long and wire type and gauge does not matter, but exterior rated wire should be used if the wire is exposed to the elements. When connected to a modular jack, this sensor uses the black and green wires as shown.

The two BUS jacks are electrically connected together in parallel.
5VDC Power (the red wire) is shared between BUS and Sun Sensor Switch (DSK) jacks.
Commands on the Sun Sensor Switch jack are repeated to the BUS jacks, and vice versa.
This unit works well with other accessories on the same SC1 Bus.

SUN AND WIND SENSOR LED:
The LED is bi-colored.
-On power-up, the LED will blink red, green if unit is Bus, green, red if unit is RF (lowercase indicates short LED blink, while UPPERCASE indicates LONG LED blink).
-The GREEN LED will flash briefly whenever the unit is transmitting to the SC1 Bus or via RF.
-The GREEN LED on solid indicates program mode. Note this is opposite the Sun and Wind Sensor.
-The RED LED will flash briefly whenever the unit is unable to transmit to the SC1 Bus due to traffic, indicating that the command is being discarded.

SUN AND WIND SENSOR Accessory Enter Program Mode:
To Enter Program Mode:
-Using a programmable remote: press & hold STOP; while still holding STOP press both OPEN7 and CLOSE7.
-Release all three buttons; within 6 seconds press CLOSE 'N', where “N” represents the accessory number of this device (factory default for N is 1), or CLOSE ALL will put all accessories in program mode. Note that Stop+7+7 Close 1 is supported by the R2D7 command: *1a01.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142
Copyright 2008 IntelliFlex_SUN AND WIND SENSOR_Programming_Inst08 Printed in USA

The Program Mode LED must now be lit solid GREEN, if it is not, repeat the above steps.

The SUN AND WIND SENSOR will automatically exit program mode after 20 seconds if no commands are received.

If programming commands started via an eye on the BUS, then BUS must be used to complete this programming. The same goes for the Sun Sensor Switch jack. While in programming mode, commands seen on either jack are repeated to the other.

While in programming mode, sun and wind sensors and all switches are ignored.

When program mode exits, the sun sensor is reset to where the level is now, there are no pending events.

SUN AND WIND SENSOR Configuration
This Sheet uses "#" for this unit's accessory number - new units will use a 1 where the # is (ALL also works).

To set this	LED:	on	blink	blink	off
Reset ALL Sun, Wind, & Switch options to factory default [1]	S+7+7	C#	CALL		S
Change accessory number to *'N'* (*N* = 1 to 60) default = 1	S+7+7	C#	C8	C *'N'*	S
Plugged into RP Bus (default)	S+7+7	C#	C8	O1	S
Or Plugged into RFTM (Radio mode)	S+7+7	C#	C8	O2	S
Change radio address	S+7+7	C#	C8	O3	S
Demo Wind Timing (report every 7 seconds)	S+7+7	C#	C8	O4	S
Or Standard Wind Timing (every 4.5 minutes) (default)	S+7+7	C#	C8	O5	S

[1] The accessory number is reset to 1. Radio address is not changed

Defaults:
Accessory number = 1, Plugged into SC1 (RP) Bus, Standard Wind Timing.
For the most reliable operation, this unit should be hardwired to the SC1 system. If that is not practical, the SUN AND WIND SENSOR may be connected to an RFTM for wireless operation. Please see "Installing SUN AND WIND SENSOR using radio (RFTM): Step by Step" for more info.
Putting the SUN AND WIND SENSOR in Demo Wind Timing mode is useful for demonstrating the unit to a potential client without having to wait several minutes to see actions. Demonstrating the Sun Sensor is achieved by setting a fast Sun Delay Time as described under the Sun Sensor section of this document.
Command send time is not selectable. It is 1/4 second for all commands. This means the controlled SC1 action must not be momentary, or they must be sticky, which is what is recommended in the notes.

Sun Actions:

This Sheet uses "#" for this unit's accessory number - new units will use a 1 where the # is (ALL also works).

To set this	LED:	on	blink	blink	off
Reset ALL Sun, Wind, & Switch options to factory default	S+7+7	C#	CALL		S
Sun Sensor options:					
10 seconds delay time	S+7+7	C#	C3	O1	S
10 minutes delay time (default)	S+7+7	C#	C3	O2	S
15 minutes	S+7+7	C#	C3	O3	S
20 minutes	S+7+7	C#	C3	O4	S
30 minutes	S+7+7	C#	C3	O5	S
60 minutes	S+7+7	C#	C3	O6	S
Set On/Off channel to *'N'* (*N* = 1 to 60)	S+7+7	C#	C3	O10 [2] O *'N'*	S
Sun Sensor not disabled via a channel (default)	S+7+7	C#	C3	O10 OALL	S
Set Summer/Winter channel to *'N'* (*N* = 1 to 60)	S+7+7	C#	C3	O11 [2] O *'N'*	S
Sun Sensor always Summer (default)	S+7+7	C#	C3	O11 OALL	S
???					
Bus Command sent at low Sunrise in Summer	S+7+7	C#	C1	O1 [2] Button [3]	S
med-low Sunrise in Summer	S+7+7	C#	C1	O2 Button	S
medium Sunrise in Summer	S+7+7	C#	C1	O3 Button	S
med-high Sunrise in Summer	S+7+7	C#	C1	O4 Button	S
high Sunrise in Summer	S+7+7	C#	C1	O5 Button	S
Bus Command sent at low Sunrise in Winter	S+7+7	C#	C1	O6 Button	S
med-low Sunrise in Winter	S+7+7	C#	C1	O7 Button	S
medium Sunrise in Winter	S+7+7	C#	C1	O8 Button	S
med-high Sunrise in Winter	S+7+7	C#	C1	O9 Button	S
high Sunrise in Winter	S+7+7	C#	C1	O10 Button	S
Bus Command sent at low Sunset in Summer	S+7+7	C#	C2	O1 [2] Button [3]	S
med-low Sunset in Summer	S+7+7	C#	C2	O2 Button	S
medium Sunset in Summer	S+7+7	C#	C2	O3 Button	S
med-high Sunset in Summer	S+7+7	C#	C2	O4 Button	S
high Sunset in Summer	S+7+7	C#	C2	O5 Button	S
Bus Command sent at low Sunset in Winter	S+7+7	C#	C2	O6 Button	S
med-low Sunset in Winter	S+7+7	C#	C2	O7 Button	S
medium Sunset in Winter	S+7+7	C#	C2	O8 Button	S
med-high Sunset in Winter	S+7+7	C#	C2	O9 Button	S
high Sunset in Winter	S+7+7	C#	C2	O10 Button	S
Sun Level NOT User Selectable (fixed)					
Set the low Sunrise (Light) Threshold to 10x+y [4] [5]	S+7+7	C#	C4	O11 [2] Ox Oy	S
med-low Sunrise	S+7+7	C#	C4	O12 Ox Oy	S
medium Sunrise	S+7+7	C#	C4	O13 Ox Oy	S
med-high Sunrise	S+7+7	C#	C4	O14 Ox Oy	S
high Sunrise	S+7+7	C#	C4	O15 Ox Oy	S
Min = 0 0 = dark, Max = 9 9 = direct sun (use O10 for 0)					
Set the low Sunset (Dark) Threshold to 10x+y [4] [5]	S+7+7	C#	C5	O11 [2] Ox Oy	S
med-low Sunset	S+7+7	C#	C5	O12 Ox Oy	S
medium Sunset	S+7+7	C#	C5	O13 Ox Oy	S
med-high Sunset	S+7+7	C#	C5	O14 Ox Oy	S
high Sunset	S+7+7	C#	C5	O15 Ox Oy	S
Min = 0 0 = dark, Max = 9 9 = direct sun (use O10 for 0)					
Sun Level User Selectable from DSK					
No Intermediate positions on Sun [6] (default)	S+7+7	C#	C10	O1 [8]	S
One Intermediate position on Sun	S+7+7	C#	C10	O2 [8]	S
Two Intermediate positions on Sun	S+7+7	C#	C10	O3 [8]	S
Three Intermediate positions on Sun	S+7+7	C#	C10	O8 [8]	S
Four Intermediate positions on Sun	S+7+7	C#	C10	O9 [8]	S
Force User Selectable Level "on" [7]	S+7+7	C#	C10	O4	S
Set the "low" Sunrise (Light) Threshold to 10w+x and the increment between levels at 10y+z [5] Min = 0 0 = no light, Max = 9 9 = direct sun (use O10 for 0)	S+7+7	C#	C4	Ow [2] Ox Oy Oz	S
Set the "low" Sunset (Dark) Threshold to 10w+x and the increment between levels at 10y+z [5] (same comments as for sunrise)	S+7+7	C#	C5	Ow [2] Ox Oy Oz	S

[2] The LED will turn RED then back to GREEN to indicate you are in a multi-button sequence.

[3] This means whatever "button" you want to "send" at the selected event, STOP means ignore the event.

[4] Completing this sequence automatically turns off user selection of sun "level" via Sun Sensor Switch.

[5] See "Sun Thresholds and Levels" for full explanation.

[6] See "Sun Intermediate Stops" for full explanation. Summer and Winter events are both set the same.

[7] See "SUN assuming fixed levels" for full explanation and warning.

[8] Completing this sequence automatically turns on user selection of sun "level" via Sun Sensor Switch.

Defaults:
Sun sensor timing = 10 minutes, low sunrise at 68 with increment of 3, low sunset at 48 with increment of 3. User level selection is allowed and is set to high, Summer and Winter Actions =No Intermediate Positions on Sun (as shown in "Sun Intermediate Stops"), Sun Sensor not disabled via a channel, No channel to switch between Summer & Winter, Sun Sensor always uses Summer Actions.

Sun Intermediate Stops
No Intermediate Positions on Sun, use default settings (S+7+7 > C# > C10 > 01):

Commands sent at each Sun Level:

	sunrise	sunset
high	Close ALL	
med-high		
medium		
med-low		
low		Open ALL

Recommended RP settings:
Open ALL = full open, sticky

Close ALL = full close, sticky

When the "high" LED on the Sun Sensor Switch display blinks, then the sunrise event is pending. When the selected delay time expires, Close ALL will be sent. The sunrise event has then happened and the high LED will stop blinking.

When the "low" LED on the Sun Sensor Switch display blinks, then the sunset event is pending. After the delay time, Open ALL will be sent. The sunset event has then happened and the low LED will stop blinking.
Other levels of sun will display appropriately with no bus commands.
The user may adjust all levels up or down using the Sun Sensor Switch.

One Intermediate Position on Sun (S+7+7 > C# > C10 > 02):

Commands sent at each Sun Level:

	sunrise	sunset
high	Close ALL	
med-high		
medium	Open23	Open23
med-low		
low		Open ALL

Recommended RP settings:
Open ALL = full open, sticky, open is reference

Open23 = Int Stop (Close23 not used here)

Close ALL = full close, sticky

If it was dark and is getting brighter (motor assumed open), and the "medium" LED on the Sun Sensor Switch display blinks, then the 1" position sunrise event is pending. When the selected delay time expires, Open23 will be sent. This sunrise event is then finished and the LED will stop blinking.
When the "hgh" LED on the Sun Sensor Switch display blinks, then the full sunrise event is pending. After the delay time, Close ALL will be sent. The sunrise event has then finished and the high LED will stop blinking.
As it gets darker, the "medium" LED on the Sun Sensor Switch display will blink. This indicates the 1st position sunset event is pending.
After the delay time, Open23 will be sent and the LED will stop blinking.
When the "low" LED on the Sun Sensor Switch display blinks, then the full sunset event is pending. After the delay time, Open ALL will be sent and the low LED will stop blinking.
Other levels of sun will display appropriately with no bus commands.
The user may adjust all levels up or down using the Sun Sensor Switch.

Two Intermediate Positions on Sun, use default settings (S+7+7 > C# > C10 103):

Commands sent at each Sun Level:

	sunrise	sunset
high	Close ALL	
med-high	Close23	Close23
medium		
med-low	Open23	Open23
low		Open ALL

Recommended RP settings:
Open ALL = full open, sticky, open is reference

Open23 = Int Stop
Close23 = Int Stop

Close ALL = full close, sticky

Three Intermediate Positions on Sun, use default settings (S+7+7 > C# > C10 > 08):

Commands sent at each Sun Level:

	sunrise	sunset
high	Close ALL	
med-high	Close23	Close23
medium	Open24	Open24
med-low	Open23	Open23
low		Open ALL

Recommended RP settings:

Open ALL = full open, sticky, open is reference
Open23 = Int Stop

Open24 = Int Stop (Close24 not used here)

Close23 = Int Stop
Close ALL = full close, sticky

Four Intermediate Positions on Sun, use default settings (S+7+7 > C# > C10 > 09):

	sunrise	sunset
high	Close ALL	Close23
med-high	Close23	Close24
medium	Close24	Open24
med-low	Open24	Open23
low	Open23	Open ALL

Open ALL = full open, sticky, open is reference
Open23 = Int Stop

Open24 = Int Stop
Close24 = Int Stop
Close23 = Int Stop
Close ALL = full close, sticky

Sun Thresholds and Levels

User selection of "level" using Sun Sensor Switch:

If the user presses the appropriate buttons on the Sun Sensor Switch to set the Sun threshold, all thresholds are moved up or down appropriately. All pending sun actions are lost when a level is selected.
Example: Default sunrise setting is 68 with 3 increment, sunset is 48 with 3 increment.
The sunrise LEDs at low setting indicate 68,71,74,77,80, and at high setting 80,83,86,89,92.
The sunset LEDs at low setting indicate 48,5 1,54,57, Mi, and at high setting 60,63,66,69,72.
At low setting with 2 intermediate positions Open23 will be sent at 71, Close23 at 77, Close ALL at 80, Close23 at 57, Open23 at 5 1, and Open ALL at 48.
At medium setting the numbers change to: Open23 @ 77, Close23 @ 83, Close ALL @ 86, Close23 @ 63,Open23 @ 57, and Open ALL @ 54.

Setting Sun Thresholds

To set the sun thresholds you must enter the two-digit low threshold number and then enter the two digit increment. For example, entering 40 as the low sunset threshold with an increment of 04, sets the low 5 thresholds from low to high to: 40,44,48,52,56, and the high 5 thresholds to 56,60,64,68,72.
This example would be done with the following sequence: S+7+7 > C# > C5 > 04 > 0 10 > 0 10 > 04
The following sequence must be completed to change any thresholds:
1- Press S+7+7 > C#, the GREEN programming LED must light.
2- Press C4, the LED will blink off then GREEN, and you are setting sunrise thresholds (or press C5 for sunset).
3- Press 0 1-10 to select the 10's of percent of the low threshold (01 0 selects O), the LED will blink RED then GREEN.
4- Press 01-10 to select the 1's of percent of the low threshold, the LED will blink RED then GREEN.
5- Press 0 1-1 0 to select the 10's of percent of the increment, the LED will blink RED then GREEN.
6- Press 0 1-10 to select the 1's of percent of the increment, the LED will blink off and then be GREEN.
If bad numbers are entered, the LED will flash GREEN & RED a few times and then be GREEN and the original thresholds are UNCHANGED and the accessory is still in program mode but must get a close command next.
Errors include:
-Entering a starting threshold where low sunrise would not be more than low sunset.
-Entering an increment of 0.
-Entering a threshold and increment where the high threshold (Low + 8" Increment) would be > 99 percent.
-Entering a threshold and increment where a sunrise would not be more than the associated sunset.
-Programming either sunrise or sunset thresholds automatically sets the threshold to high (default).
If you are not using the Sun Sensor Switch to change between the thresholds, then the high threshold set is the only one used. The programming sequence MUST still be completed.
After installation, be sure to select a Sun Sensor Delay of at least 10 minutes.

SUN assuming fixed levels

The sun sensor is capable of sending independent bus commands as a result of each of the 5 sunrise and sunset events, and the thresholds may be adjusted individually. However, once this capability is enabled, the user selectable "level" is disabled. The Sun Sensor Switch is simply a display of sun levels in this case.

Setting any sun event to a custom value (S+7+7 > C# > C1 or C2 > Cx . . .) automatically turns off the users ability to set the level. You can force the ASM to allow user selection using S+7+7 > C# > C10 > 04 > S, however, operation may be strange.

Setting Sun Thresholds individually

S+7+7 > C# > C4 or C5 > Ow > Ox > Oy > Oz may still be used to set multiple thresholds at once; please see that section above. The highest 5 (as though the user selected high level) are the values used in fixed mode.

To set a specific sun threshold you must enter the two-digit threshold after selecting the threshold to set. For example, setting the medium sunrise threshold to 86 would be done with the following sequence: S+7+7 > C# > C4 > C3 > 08 > 04

The following sequence must be completed to change any threshold:

1. Press 5+7+7 > C#, the GREEN programming LED must tight.
2. Press C4, the LED will blink off then GREEN, and you are setting sunrise thresholds (or press C5 for sunset).
3. Press C 1-5 to select which threshold to set, the LED will blink RED then GREEN.
4. Press 0 1 - I0 to select the 10's of percent for this threshold (0 10 select 01, the LED will blink RED then GREEN.
5. Press 0 1-1 0 to select the 1's of percent for this threshold, the LED will blink off and then be GREEN.

If bad numbers are entered, the LED will flash GREEN & RED a few times and then be GREEN and the original thresholds are UNCHANGED; the accessory is still in program mode but must get a close command next.

Errors include:

-Entering a sunrise threshold smaller than the associated sunset.

-Entering a sunset threshold larger than the associated sunrise.

Programming any individual threshold automatically sets the "level" to high (default).

If you are not using the Sun Sensor Switch to change between the thresholds, then the thresholds as described under "intermediate positions using default"' are the ones used.

After installation be sure to select a Sun Sensor Delay of at least 10 minutes.

Installing SUN AND WIND SENSOR using radio (RFTM): Step by Step

The SUN AND WIND SENSOR may be connected to an RFTM for wireless operation. However, the batteries on an RFM will not power the SUN AND WIND SENSOR for very long, so a DCPM must also be used. The "change radio address" may be used if more than one SUN AND WIND SENSOR is connected to a system using radio and they happen to have the same address. Connect everything as shown:



This setup allows the SUN AND WIND SENSOR to convert BUS commands received on the Sun Sensor Switch (DSK) port to radio commands. You must have a method of getting commands into the Sun Sensor Switch port to program the SUN AND WIND SENSOR. This can be accomplished by temporarily plugging an eye in the Sun Sensor Switch jack.

Using an IR only handheld transmitter, program the SUN AND WIND SENSOR to radio mode (S+7+7 > C# > C8 > 02).

Press the "learn" button on the RR that you want the SUN AND WIND SENSOR to talk to. Its LED must come on. Quickly press a button on the IR transmitter aimed at the eye plugged into the SUN AND WIND SENSOR. (This will cause the SUN AND WIND SENSOR to send a radio command that will be learned by the RR.) The LED on the RR must go out when the button is pressed indicating the RR has learned the radio address of the SUN AND WIND SENSOR.

Press an open or close command on the IR transmitter and make sure the appropriate action happens on the SC1 system.

Draper Sun Switch (DSK) (optional):

This Sheet uses $ for this Sun Sensor Switch's accessory number - new units will use a 6 where the # is (ALL also works).

To set this	LEDs [14]	on	blink	blink	off
Reset all options and accessory number to default	S+7+7	C¢	CALL		S
Change accessory number to *'N'*	S+7+7	C¢	C1	O*'N'*	S
Bus Command sent by button labeled Open	S+7+7	C¢	C2	Button [15]	S
Bus Command sent by button labeled Stop	S+7+7	C¢	C3	Button [15]	S
Bus Command sent by button labeled Close	S+7+7	C¢	C4	Button [15]	S
Put the DSK (Decorator Switch) into Sun only mode	S+7+7	C¢	C5	O1	S
Put the DSK (Decorator Switch) into Sun & Wind mode	S+7+7	C¢	C5	O2	S

14 This means open + close, all others are turned off

15 This means whatever “button" you want to "send" when the button is pushed.

Sun Sensor Switch MUST be plugged into the Sun Sensor Switch (DSK) jack for it to work correctly.

Defaults:

Accessory number = 6.

Open button sends OPEN 1.

Stop button sends STOP (this is All Stop).

Close button sends CLOSE 1.

Sun & Wind Mode (both GREEN and RED LEDs will display on the Programming Switch).

It is possible to make the open & close buttons send commands that do not control this motor simulator, but this would probably be confusing. The open/stop/close LEDs are updated according to the status of the SUN AND WIND SENSOR "motor simulator" to which it is connected regardless of any channel number (s).

Note that the default channel for the Sun Sensor Switch is 1 and the default channel for the SUN AND WIND SENSOR is 22, so the Sun Sensor Switch channels should be changed to 22 for use with SUN AND WIND SENSOR.

Power-Up

The LEDs go through a sequence where all LEDs are turned on so you may easily determine if any are not working. After this sequence is completed, the Decorator Switch may take a few seconds before the correct state is displayed. The sequence begins: All 6 RED LEDs on the Programming unit, then All 6 GREEN LEDs on the Programming unit, then ALL 4 LEDs on the Control unit. Then the bottom 4 LEDs will flash RED for ¼ of a second indicating WALL SWITCH is version 4. The version of the SUN AND WIND SENSOR must be 1 and the Sun Sensor Switch must be 4 for correct operation.

Configuring the WALL SWITCH & SUN AND WIND SENSOR using the WALL SWITCH:

Press and hold the 2 buttons indicated below for 5 seconds to perform the configuration shown. After completion, the LEDs next to the buttons held will come on green for 1 second. If 5 RED LEDs come on, then that configuration is not allowed.

Sun & Wind Display:

Medium-high (3d) and medium-low (5th) buttons. The Sun Sensor Switch will display and set both Sun and Wind. The SUN AND WIND SENSOR does not change any settings.

Sun Only Display:

Medium-high (3d) and low (6th) buttons. The Sun Sensor Switch will display and set only Sun. Multi-positions on sun are not affected. This does not stop wind detection; the Sun Sensor Switch will just never report wind levels and the user cannot select a wind threshold.

The SUN AND WIND SENSOR does not change any settings.

NO intermediate positions on Sun:
High (2nd from the top) and medium-high (3d from the top) buttons. Sunrise & Sunset events will be set as shown in "Sun Intermediate Stops" section above under “No Intermediate Positions." Selected Sun level is set to high.
The SC1s intended to be controlled by the SUN AND WIND SENSOR are NOT affected by this action and must be programmed separately.

ONE intermediate position on Sun:
High (2nd) and medium (4th) buttons. Sunrise & Sunset events will be set as shown in "Sun Intermediate Stops" section above under "One Intermediate Position." Selected Sun level is set to high.
The SC1s intended to be controlled by the SUN AND WIND SENSOR are NOT affected by this action and must be programmed separately.

TWO intermediate positions on Sun:
High (2nd) and medium-low (5th) buttons. Sunrise & Sunset events will be set as shown in "Sun Intermediate Stops" section above under "Two Intermediate Positions." Selected Sun level is set to high.
The SC1s intended to be controlled by the SUN AND WIND SENSOR are NOT affected by this action and must be programmed separately.

THREE intermediate positions on Sun:
High (2nd) and low (6th) buttons. Sunrise & Sunset events will be set as shown in "Sun Intermediate Stops" section above under 'Three Intermediate Positions." Selected Sun level is set to high. This button combination may be called Toggle Reference in the Sun Sensor Switch documentation, but the function is as described here for SUN AND WIND SENSOR.
The SC1s intended to be controlled by the Sun and Wind Sensor are NOT affected by this action and must be programmed separately.

FOUR intermediate positions on Sun:
Medium-high (3d) and medium (4th) buttons. Sunrise & Sunset events will be set as shown in "Sun Intermediate Stops" section above under "Four Intermediate Positions." Selected Sun level is set to high. This button combination may be called Toggle Motor Leads in the Sun Sensor Switch documentation, but the function is as described here for SUN AND WIND SENSOR.
The SC1s intended to be controlled by the Sun and Wind Sensor are NOT affected by this action and must be programmed separately.

Sun Sensor in Summer mode:
Medium (4th) and medium-low (5th) buttons. All Sunrise & Sunset events will be Summer actions. This button combination may be called Auto-return in the Sun Sensor Switch documentation, but the function is as described here for SUN AND WIND SENSOR.

Sun Sensor in Summer mode:
Medium (4th) and low (6th) buttons. All Sunrise & sunset events will be Winter actions. This button combination may be called Auto-return in the Sun Sensor Switch documentation, but the function is as described here for SUN AND WIND SENSOR.

Pressing the button combination to start Calibration will light all 5 LEDs indicating the function is not supported.

Programming the Sun Sensor Switch, Accessory number, BUS & Sun Sensor Switch jacks:
There is no association between the Sun Sensor (Decorator) Switch "accessory number" and simulated SC1 "main channel".
The Sun Sensor Switch simply works with whatever SUN AND WIND SENSOR it is plugged into. The messages going between the Sun Sensor Switch for status display and the SUN AND WIND SENSOR are special and not repeated to the BUS jack.

You cannot program the Sun Sensor Switch using S+7+7 CloseALL unless you are using a splitter etc. The CloseALL command is interpreted by the SUN AND WIND SENSOR as '"enter program mode" - and it turns on its GREEN LED and awaits programming commands -and the Sun Sensor Switch goes into program mode, and they do not use the same programming steps.

Sun Sensor Switch Reporting Delay:
Be aware that the LEDs on the Sun Sensor Switch may lag behind an actual change in light level or other event by as much as 6 seconds.
This is particularly significant when demonstrating light reactions.

Debug feature, simulating an event:
The Sun Sensor Switch can be used to simulate an event to verify that everything is programmed as desired.
Press and hold the desired 'level" button on the Programming Switch, then press and hold the STOP (middle) button for 4 seconds to simulate the event associated with that level of wind.
Press and hold the desired button on the Programming Switch, then press and hold the top button for 4 seconds to simulate the event associated with that level at sunrise (Summer/Winter is whatever is currently selected).

Press and hold the desired button on the Programming Switch, then press and hold the bottom button for 4 seconds to simulate the event associated with that level at sunset.
If there is no action associated with that level then nothing will happen.
Be careful to not push multiple buttons on the Programming Switch, as that may cause a configuration change!

Order dependent programming on SUN AND WIND SENSOR:
Forcing user level set must be done only after setting all events C 1 ... or C2 ... .
Resetting accessory to factory default, or selecting default actions on multi-sun, puts full sunrise and sunset events on channel 22 regardless of simulator 'main' channel, so this setting must be made before changing main channel actions.

Installation Instructions
IntelliFlex™ LCD Timer by Draper

① The timer acts as a "normally open" (NO) switching device.
② The timer may be set to deliver up to seven (7) On/Off setting pairs. Each setting pair can be set to activate: everyday, once a week, every weekday, or weekends only.
③ When connecting to SC1 or PSI60, polarity does not matter

① The timer acts as a "normally open" (NO) switching device. This delivers a closed contact in the "On Mode," and an open contact in the "Off Mode."
② The manual inputs of an SC1 or PSI60—when set into SPST mode—may be set to react to these types of contact by opening and closing motorized products to their respective limits.
③ The timer may be set to deliver up to seven (7) On/Off setting pairs. Each setting pair can be set to activate: everyday, once a week, every weekday or weekends only.
④ The timer can be used as a local switch by pressing the clear "Cover/ Switch, and activating the "Next/On/Off" operation.
⑤ The timer is capable of many other powerful and flexible features (including: Astronomic Feature, Automatic Daylight Savings Time adjustment, Random Operation feature, and much more). Please see timer "Installation and Operating Instructions" (included with the timer).

Connecting to PSI60 or SC1

① The BLACK and BLUE wires from the timer should be connected to the Common and Up (Open) terminals on a PSI60 or SC1.
Please Note: Polarity does not matter.
② Be sure to configure manual inputs of the PSI60 or SC1 you are using for Single Pole Single Throw (SPST). Please refer to the documentation for the PSI60 or SC1 to correctly enable the "SPST Manual Switch" setting.
Please Note: If using a PSI60, be sure to program the PSI60 to send the specific SC1 "Bus" command you wish the timers action to initiate.
③ See page 2 of these instructions for configuring the timer to activate at the desired time(s).

Technical Notes

① The timer's blue and black wire gauge is too large to fit the screw terminals of a PSI60 or SC1. Use the wire-nuts provided with the timer to connect a smaller gauge wire (18-28 AWG is acceptable) to make interfacing with the screw terminals possible.
② Two wires have been provided for making the connection noted above.
③ The red wire on the Timer is used for three-way line voltage switching, and is not used in IntelliFlex applications.
④ Upon initial insertion of the battery, the timer may enter a mode where the internal motor-switch may cycle repeatedly. In this case, press and release the Reset button once, and the timer should function normally. If this does not resolve the issue, refer to the "Troubleshooting Guide" on page 2 of these instructions.
⑤ The timer has an internal backup battery (not serviceable), which will hold your timer memory settings for a short period of time (refer to the timer documentation for details.) This internal backup battery allows you an opportunity to replace the AAA battery without losing your timer memory settings.
⑥ For additional actions at the same installation, please purchase additional timers.



Figure 1

Connecting PSI60 to LCD Timer



Figure 2

Connecting One SC1 to LCD Timer



Figure 3

Connecting Multiple SC1s to LCD Timer



Figure 4

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc. Form IntelliFlex-LCDTimer_Inst07 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex LCD Timer, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

Programming/Setting the LCD Timer

Resetting the timer

Press the reset and the "Next/On/Off" buttons at the same time. Release the buttons and wait for "12:00" to start blinking.

Setting the calendar

Press the mode button one time. "Cal" will appear in the top left corner. Year will be flashing between the word "year" and "2000." If the year is not showing 2000 you must repeat the reset procedure. To adjust the year, press the "m+zone" button (bottom right). If you pass the current year use the (bottom center) button to subtract a year. Press the "Next/On/Off" button one time. Date will be flashing. Press the "day/dst" (bottom left) button to set the current day. Press the "M+zone" (bottom right) to set the current month. Press the "Next/On/Off" button one time. "DST/Auto" will be flashing. Press the "Day/DST" button (bottom left) to select Daylight Savings Time. If daylight savings is not being used press the button again and select "man." Press the "Next/On/Off" button one time. "Zone" will be flashing. Press the "M+zone year" button (bottom right) and select the zone area of your location (South, Central or North—see Fig. 7). Press the "Next/On/Off" button one time. "SUNUP" will be flashing, showing the preset time for this zone. To adjust this time, press the "Hour/Year" button (bottom center) to adjust the hour and the "M+zone" button (bottom right) to adjust the minutes. Press the "Next/On/Off" button one time. "SUNDN" will be flashing, showing the preset time for this zone. To adjust this time, press the "Hour/Year" button (bottom center) to adjust the hour and the "M+zone" to (bottom right) to adjust the minutes. The calendar portion of the timer is now set. Note: you must continue and set both the clock and the programming function.

Setting the clock

Press the "mode" button one time. "Clk" will be displayed in the left corner of the timer. Using the "Hour/Year" button (bottom center) to set the hour of your current time. Using the "M+zone" (bottom right) button set the minutes of your current time.

Programming

Press the mode button one time. "Pgm" will be displayed on the top left corner of the timer. We are setting the "On" time for Program 1. "---:--- 1on" will be displayed on the screen. Press the "Day/DST" (bottom left) button to select the day or series of days the timer is to turn on. You can either select the "Astro" time which will adjust as the days get longer and shorter or a specific time. To use the "Astro" time, press the "Day/DST" until "snst" appears on the screen (all seven days will be shown on the bottom of the timer). To use a specific time press the "Day/DST" button and select the day or series of days the timer is to turn on. Use the "Hour/Year" (bottom center) button to select the hour to turn the unit on. Use the "M+zone" (bottom right) button to set the minutes of your on time. Press the "Next/On/Off" button one time. We are now setting the "Off" time for program 1. Press the "Day/DST" (bottom left) to select the day or series of days of operation. To use the "Astro" time press the button until "snup" appears on your screen. To select a specific time, press the button and select a day or series of days the unit is to turn off. Press the "Hour Year" (bottom center) button and set the hour of your "Off" time. Press the "M+zone" (bottom right) button to select the minutes of your "Off" time. For additional programs press the "Next/On/Off" button to the next program and follow above steps.

Exit Programming

Press the "Mode" button once for "Auto" or twice for "Auto Rand."

Note: your timer is in the on position. If the program calls for the unit to be off at this time Press the next "On/Off" button to toggle the unit to off.


NEXT/ON/OFF
Switches between ON and OFF settings when programming the time. Confirms program entry and advances timer to next selection.
MODE
Switch from one program mode to another.
DAY/DST
Changes days when setting calendar or programming ON and OFF times. Press to select automatic or manual daylight savings time.
RESET
Press RESET while holding down NEXT/ON/OFF button to clear all previous programming.
M+ ZONE + YEAR+
Advances months in the calendar mode. Advances minutes in the clock and program modes. Advances years in the calendar mode.
HOUR+ YEAR-
Subtracts years in the calendar mode. Advance hours in the clock and program modes.

Figure 5



Figure 6

Figure 7

Battery Replacement

The 15 Volt alkaline battery should operate your timer for 1½ years or more under typical conditions. High or low temperature or frequent use of the manual pushbutton will reduce the battery life. Replace the battery when the digital display is dim, the message "lobAt" (meaning low battery) is displayed or if the timer fails to operate. Press any button to clear the "lobAt" message. The timer has built-in memory protection providing at least 15 seconds to change a weak battery without losing your time-of-day setting. You do not need to turn off the load or the power in order to replace the battery; however, do not attempt to switch the timer on or off while the battery is out or your time setting will be lost and the timer will need to be reset.

TROUBLESHOOTING GUIDE

SYMPTOM	POSSIBLE CAUSE	REMEDY
Timer does not operate, display is dim, blank or unreadable, display shows nonsense or 'lobAt', or timer operates erratically.	Battery is worn out, missing or is installed backwards, timer was operated while battery was removed, or battery was out too long during battery replacement.	Install a fresh AAA size alkaline battery in the direction indicated. Press RESET button, then reprogram the time-of-day.
Timer does not switch but display is normal.	Timer not in AUTO, AUTO RAND(om), or MAN(ual) mode.	Use MODE pushbutton to select the desired operating mode.
Timer works manually but does not follow scheduled program.	Timer not in AUTO or AUTO RAND(om) mode.	Use MODE pushbutton to select AUTO or AUTO RAND
Timer won't enter the AUTO or AUTO RAND modes when MODE button is pushed.	Time of day and/or switching times are not programmed.	Make sure time of day and at least one scheduled activity are programmed.
Timer switches at incorrect times or skips some switching times.	Programmed schedule(s) are incorrect. Timer is in AUTO RAND(om) mode (Varies switching times up to +/- 15 minutes).	Review / Revise ALL 7 ON/OFF switching time pairs by repeatedly pushing the next NEXT/ON/OFF button while in PGM mode. Use MODE pushbutton to select AUTO mode.
When using a combination of Astronomic and Specific switching times, the timer switches at unexpected times or *doesn't* switch when expected.	Conflicting Astronomic and Specific switching time settings.	Complete the steps under "Setting the Calendar" then temporarily change your timer's calendar setting to June 21st. Now review the SUNUP and SNSET times by pushing the NEXT/ON/OFF button. Make sure your Specific ON or OFF time settings won't interfere with these Astronomic switching times. Be sure to change the date back to today's date when you're done.
Load state doesn't match programmed state immediately after programming the time or schedule.	Timer does not "catch up" to the programmed load state. The load will remain in it's state prior to entering the PGM mode. The timer will begin following the scheduled program at the next contrary ON/OFF time.	After entering your schedules or the time, then returning to the AUTO modes, push the next NEXT/ON/OFF button to change the load state if necessary.
Display shows 'no Op'.	Mechanism is inoperative.	If timer is in a very cold environment, try again when warmer. If not, and if the battery is good, the timer should be replaced. Push in battery cover until you hear a click. Push reset button to clear display and reprogram the time-of-day. Replace device if NoOp will not clear from display.
Timer operates, but light doesn't come on in dimmer applications.	Dimmer is turned off or is set too low to turn back on or the bulb is burned out.	Make sure timer display shows 'ON' then check dimmer operation at full brightness setting. If timer control is required at very low brightness settings, use a premium quality dimmer that can be turned on when set low.
Load only operates when the remote (3-way) switch is in one position or timer ignores the remote switch.	Remote switch is wired incorrectly.	Recheck wiring, especially for the jumper, per **"Installation Instructions - 3-Way Switch"** and **"Other Installations"**.
Timer ignores remote (3-way) switch even though it is wired correctly.	Excessive length of wire (greater than 100 feet) or buried wiring to the remote switch. Remote switch is defective or worn out.	Eliminate condition, replace the buried cable, do without the remote switch, or consult factory for other options. Replace remote switch.
Load turns off immediately after being turned on.	Remote switch or timer wired incorrectly, excessive length of wire (greater than100') or bad wiring to remote switch, or defective timer.	If the problem persists with the red wire disconnected or with a 'remote' switch temporarily connected right at the timer, replace the defective timer, otherwise try the above remedies.
Battery holder is difficult to snap in place	Battery not seated in holder, holder misaligned, or contact tabs of holder are bent.	Line up tabs on bottom of holder with notches in timer housing when pushing in. Straighten bent contact tabs.

Installation Instructions

IntelliFlex™ PSI60 Bus Command Converter by Draper

① Make sure power is disconnected before installing controls.
② Make sure AC Amperage of any wall switches are not exceeded, and that wires are large enough for loads.
③ All AC motor controls are UL approved.

Installing the PSI60

① Connect the PSI60 to the SC1 network (see Fig. 1).



Figure 1

General installation guidelines based on type of switch

SPDT Momentary Switch or Somfy 3-Button Switch:

SC1 control will be programmed to SPDT Momentary by factory default (SPDT Momentary Switch). Button action is exactly like the keypad. A momentary press of either directional button sends the appropriate command. The motor action will be maintained, running the shade to its limit. If the command is repeated, this will "stop" the motor at that point in its travel.

SPDT Maintained Switch:

Program SC1 to "Stop on Manual Button Release." A standard SPST maintained switch will now operate the SC1 control just like normal AC switching. Press "Down," latching the switch down = the shade runs down. Action of "Up" is the same. Return switch to center = "Stop."

SPST Maintained Switch:

Program SC1 for "SPST Switches." Connect the two wires from the switch to common and open. Electrical closing of switch sends "Close." Opening of switch sends "Open." Enabling "Invert" causes closing of the switch to send "Open" and vice versa (useful for winter/summer if using a thermostat). To "Stop" a motor while it is running: "Quick Toggle" of the switch (running open—flip to "Close" then back to "Open") will stop the motor.

SPST Momentary Push-Button Switch:

Program SC1 for "SPST Switches." Connect switch between common and close. A Momentary Press of this switch sends a command to run. The direction that the motor runs is in relation to the "last command" that the SC1 received, so it could be "Open" or it could be "Close." This switch method is a true sequential switching action.

Timed relay closure from automation system:

Program to factory default (SPDT Momentary Switch). Closure of either relay sends the appropriate command. The contact time of this "Momentary" closure should be ½ second.

For use with X-10 controls:

① SPDT Mode: Program to factory default, and connect 2 universal modules in momentary mode (one between open and common, the other between close and common.)
② Activate the open module to open the shade; activate the close module to close the shade; simply repeat any command to stop the shade.
③ SPST Mode: Maintained—Using one universal module connect two wires between Open and Common. X-10 to deliver a maintained contact. Electrically Closed=shade closed. Electrically Open=shade open. The delay times within the X-10 system make it difficult to stop the motor using the "Quick Toggle" feature of the SC1.

Programming the PSI60

To Enter Program Mode—

① Using a programming remote - press & hold "Stop."
② While still holding "Stop," press both "Open 7" and "Close 7," then release all three buttons. Within 6 seconds press "Close All." The Red Program Mode LED on the PSI60 must now be lit. If it is not repeat the above steps.

In the following table, S = "Stop," C = "Close," O = "Open".

Desired Change	LED:	on	blink	blink	off
Left Switch Channel to 1	S+7+7	C ALL	C 1	O 1	S
Left Switch Channel to "N" (N = ALL, 1 - 60)	S+7+7	C ALL	C 1	O "N"	S
Left Switch Channel to "ALL"	S+7+7	C ALL	C 1	O ALL	S
Reset the Left Switch options to factory default	S+7+7	C ALL	C 2	O ALL	S
SPST Switches on Left	S+7+7	C ALL	C 2	O 3	S
SPDT Maintained Switch on Left	S+7+7	C ALL	C 2	O 2	S
Invert Left SPST switch	S+7+7	C ALL	C 2	O 4	S
Right Switch Channel to "N" (N = ALL, 1 - 60)	S+7+7	C ALL	C 3	O "N"	S

Notes:

- The right switch must be SPDT Momentary. Its type cannot be changed via programming. Left switch default is SPDT Momentary switch.
- The PSI60 unit is also a repeater.
- This unit cannot be used as the only repeater in a system unless everything is already programmed, because "enter program" commands are blocked and NOT repeated.
- While programming this unit (red LED is on) IR signals are not repeated.
- Note that the Palm Pilot will not program this unit correctly.
- Pushing a second button while another is active will cause the first button to be interrupted. The SC1 will probably ignore the change. Wait at least ¼ second between button pushes or subsequent pushes will be misinterpreted.
- If you plan to use two switches simultaneously, it is recommended that they both be SPDT momentary. If left and right switches are pushed simultaneously, note that only one will be handled at a time.
- "ALL on the cut strap T12" cannot be sent by PSI60.

DRAPER
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright ©2007 Draper Inc. Form IntelliFlex-PSI60_Inst07 Printed in U.S.A.

If you encounter any difficulties installing/wiring your IntelliFlex PSI60, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999; or fax (765) 987-7142.

Introductory Overview

The IntelliFlex Control System is an intelligent yet simple package of controls and input devices that provides a single source opportunity to install any type of motor controls on a range of products and have them all work together seamlessly in an installation.

The heart of the system is the SC1 (see Fig. 1), a single motor switching relay with a built in microprocessor. Think of the SC1 as being two different switches in one. The relay component acts as a switch to turn the power on and off to the motor, operator or device you wish to control. With the IntelliFlex system, the processor on the SC1 control acts as the switch to tell the relay when to turn on and off.


To Optional Manual Switch
Eye Jack for connecting control devices to SC1
Aux Jack for linking SC1s together
To AC Power and Motor
From Wall Switch, IR, RF, or other control device
Earth Ground

Figure 1

The SC1 communication system uses the power of each device's microprocessor to receive and interpret commands. There are two ways of sending commands to the system. One is through a set of dry contact closure terminals on each SC1. The second and most powerful method is via a low voltage data communication Bus system.

Each SC1 has two RJ11 4-conductor modular phone plug ports that can be used to link multiple devices together. The microprocessor on each device listens for commands addressed to it. The Bus utilizes a proprietary protocol allowing up to 60 channels of communication to be shared between devices in a single system. Multiple systems can be combined in an installation.

Each microprocessor is programmed with firmware, which acts as the operating code for the system. Each device's firmware can be written to through special programming functions, allowing special features and actions to be enabled and modified. (For a complete listing of special functions see our quick reference programming guide.)

The key feature to reprogram for any installation is what is referred to as the Main Address. This is the primary Bus channel to which the SC1 processor is programmed to respond. While it is not necessary to edit this address, doing so allows each SC1 in a Bus system to be addressed individually. Once an SC1 has a unique main address on the Bus it can be addressed and programmed remotely, thereby eliminating the need to gain physical access to the SC1 to modify or change its configuration!

Other features include up to six subgroup functions per SC1 and the ability to enable up to four mid-window stopping positions. It can be set to turn a light on or off. The motor output terminals can be reversed via programming, eliminating the need for an electrician to deal with motor polarity, etc.

Inputs:

The SC1 dry contact input terminals are unique in the ability to change, through programming, the way the relays respond to contact closures. These terminals can be used in a standard latch and run mode or can be set to require a maintained contact for momentary motor action. They can also be set to X10 timing mode. This flexibility allows the system to be integrated with virtually any automation system.

The Bus communication is capable of receiving input commands from a wide variety of different input devices (see our reference sheet, and sample input device configuration sheets) in any combination and number and at any time, allowing great flexibility and power in providing a control system ranging from the most simplistic to the most complex, all in a plug and play fashion.

Input devices include, but are not limited to, IP devices to launch commands remotely via a Local Area Network (LAN), RS232 devices for launching commands from a local PC or HA system, sun sensors, wind sensors, timers, thermostat interfaces, interface devices for other building automation and fire alarm system overrides, radio remote controls, infrared remote controls, wireless wall switches and keypads, hardwired wall switches and keypads, standard toggle switches and key switches. Each input device can be used to launch individual, subgroup or group actions, or any combination thereof. Commands can also locate multiple shades to as many as four intermediate stops.

In addition, Draper has developed a "standard" "custom" switch program that allows the user to choose a wall switch configured to provide intuitive labeling and actions in a stocking switch program. The IntelliFlex Wall Switch is available in over 50 stocking configurations. Each of up to 12 available buttons can be programmed to send any command necessary, creating an extremely flexible user interface for the system.

Draper provides a number of ways to program the system and all are relatively inexpensive and simple to use. These include programming functions from a number of different keypads and transmitters, but the fastest and simplest methods are done using free programming PC software (requires Draper's RS232 translator to connect to the system).

For the most current information, check out our Web site, www.draperinc.com.

DRAPER
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999 ▮ fax 765-987-7142
e-mail draper@draperinc.com ▮ www.draperinc.com

Copyright © 2005 Draper Inc. Form IntelliFlex_Overview05 Printed in U.S.A.

IntelliFlex® Controls Planning Sheet

by DRAPER

Assign Group Numbers:																
	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)
Main Channel Assignment*																
Shade Location	**Shade 1**				**Shade 2**				**Shade 3**				**Shade 4**			
1st Group																
2nd Group																
3rd Group																
4th Group																
5th Group																
6th Group																

	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)
Main Channel Assignment*																
Shade Location	**Shade 5**				**Shade 6**				**Shade 7**				**Shade 8**			
1st Group																
2nd Group																
3rd Group																
4th Group																
5th Group																
6th Group																

	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)	Stop Enabled (A or B)	Group Channel	Open Command Position (%)	Close Command Position (%)
Main Channel Assignment*																
Shade Location	**Shade 9**				**Shade 10**				**Shade 11**				**Shade 12**			
1st Group																
2nd Group																
3rd Group																
4th Group																
5th Group																
6th Group																

Please Note: Main Channel Assignment = Shade at 0%/100%
Stop (A/B) = Indicate whether Stop A or Stop B is enabled

(If more grids are required, please copy this page. Be sure to submit all layout grids to Draper, and keep a copy for yourself.)

PROJECT: _____

_____

ARCHITECT: _____

CONTRACTOR: _____

SUPPLIER: _____

DATE: _____ REVISED: _____

DRAPER

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright © 2007 Draper Inc. Form IntelliFlex_PlanningSheet07-R Printed in U.S.A.

SC-1 Quick Reference Guide (OS firmware version 3) by Draper

This Sheet uses # for the receiver's main channel number - new units will use a 1 where # is.
Note that # can also be ALL if you want to program several receivers S = Stop C = Close 0 = Open

	LED	on	blink	blink	off
Reset EVERYTHING to factory default	S+7+7	O ALL	hold 5 sec. until blink		S
Reset everything ***except*** main channel to factory default	S+7+7	O #	C ALL		S
Main Channel to "N"ew channel (N = 1 through 59),	S+7+7	O #	C 1	O "N"	S
1ST Group Channel to "N"ew channel (N = 1 through 60)	S+7+7	O #	C 2	O "N"	S
1ST Group Channel OFF	S+7+7	O #	C 2	O ALL	S
Set 2ND Group Channel (same as above)	S+7+7	O #	C 3	O "N"	S
Set 3RD Group Channel (same as above)	S+7+7	O #	C 4	O "N"	S
Set 4TH Group Channel (same as above)	S+7+7	O #	C 5	O "N"	S
Set 5TH Group Channel (same as above)	S+7+7	O #	C 13	O "N"	S
Set 6TH Group Channel (same as above)	S+7+7	O #	C 14	O "N"	S
Set "Sequential Action" Channel (same as above)	S+7+7	O #	C 20	O "N"	S
Set "Specific Stop" Channel (same as above)	S+7+7	O #	C 22	O "N"	S
Reset the following options to factory default	S+7+7	O #	C 6	O ALL	S
Momentary Motor Action	S+7+7	O #	C 6	O 1	S
Reverse Motor Direction	S+7+7	O #	C 6	O 2	S
Do NOT Act on ALL buttons from Transmitter	S+7+7	O #	C 6	O 3	S
Stop On Transmitter Button Release	S+7+7	O #	C 6	O 8	S
Disable the Deadbeat Counter	S+7+7	O #	C 6	O 11	S
Enable the Deadbeat Counter, and reset it to 120	S+7+7	O #	C 6	O 12	S
Reset the following options to factory default	S+7+7	O #	C 7	O ALL	S
SPST Manual switch	S+7+7	O #	C 7	O 1	S
Stop On SPDT Manual Switch Release	S+7+7	O #	C 7	O 3	S
Swap Open and Close on SPDT, Invert SPST	S+7+7	O #	C 7	O 5	S
Enable SPST Magnetic Switch as Override	S+7+7	O #	C 7	O 6	S
Turn off all "A" intermediate stops (factory default)	S+7+7	O #	C 10	O ALL	S
Enable "Intermediate Stop A" on the main channel	S+7+7	O #	C 10	O 1	S
Enable "Int. Stop A" on 1ST group channel	S+7+7	O #	C 10	O 2	S
Enable "Int. Stop A" on 2ND group channel	S+7+7	O #	C 10	O 3	S
Enable "Int. Stop A" on 3RD group channel	S+7+7	O #	C 10	O 4	S
Enable "Int. Stop A" on 4TH group channel	S+7+7	O #	C 10	O 5	S
Enable "Int. Stop A" on 5TH group channel	S+7+7	O #	C 10	O 6	S
Enable "Int. Stop A" on 6TH group channel	S+7+7	O #	C 10	O 14	S
Enable "Int. Stop A" on the ALL channel	S+7+7	O #	C 10	O 7	S
Enable "Int. Stop A" on Manual Switches	S+7+7	O #	C 10	O 8	S
Calibrate the travel times ***Required for using Int. Stop A or B***	S+7+7	O #	C 10	O 10	**
Reference the bottom (close limit) instead of top (open) *(if both A & B stops are set on a channel, A takes precedence)*	S+7+7	O #	C 10	O 11	S
"Intermediate Stop A Open Button," default is 20% closed Set to 10x+y percent of travel time away from reference end min = 0 0 (at ref.), max = 9 9 (opposite limit) use O10 for 0	S+7+7	O #	C 11	Ox Oy	S
"Intermediate Stop A Close Button," default is 80% closed	S+7+7	O #	C 12	Ox Oy	S
Turn off all "B" Intermediate stops (factory default)	S+7+7	O #	C 15	O All	S
Enable "intermediate Stop B" on the main channel	S+7+7	O #	C 15	O 1	S
Enable "Int. Stop B" on 1ST group channel	S+7+7	O #	C 15	O 2	S
Enable "Int. Stop B" on 2ND group channel	S+7+7	O #	C 15	O 3	S
Enable "Int. Stop B" on 3RD group channel	S+7+7	O #	C 15	O 4	S
Enable "Int. Stop B" on 4TH group channel	S+7+7	O #	C 15	O 5	S
Enable "Int. Stop B" on 5TH group channel	S+7+7	O #	C 15	O 6	S
Enable "Int. Stop B" on 6TH group channel	S+7+7	O #	C 15	O 14	S
Enable "Int. Stop B" on the ALL channel	S+7+7	O #	C 15	O 7	S
Enable "Int. Stop B" on Manual Switches *(if both A & B stops are set on a channel, A takes precedence)*	S+7+7	O #	C 15	O 8	S
"Intermediate Stop B Open Button," default is 40% closed	S+7+7	O #	C 16	Ox Oy	S
"Intermediate Stop B Close Button," default is 60% closed	S+7+7	O #	C 17	Ox Oy	S

** There is no Stop button press at the end of the calibration command. Calibration required for Int. Stops to work.**

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright © 2008 Draper Inc. Form DraperSC1QuickReferenceGuide_08 Printed in U.S.A.

SC-1 Quick Reference Guide by Draper

Defaults:

Main Channel = 1, Group Channels 1-6 = off, no sequencing action channel,
Maintained Motor Action, Standard Motor Direction, Act on ALL buttons from Transmitter, Standard action on the group buttons, Standard IR Release Time, Do not Stop On Transmitter Button Release, Deadbeat Counter Disabled, Demo mode Off.
SPDT Manual Switch, Standard Timing, Do not Stop On Switch Release, Standard action (not sticky), Switch inputs as labeled, Magnetic Switch Override Disabled.
Run Time = 180 sec.
Standard accuracy on Intermediate stops, Intermediate stop reference is at the top, "Auto Tilt" not enabled, Travel Time unknown (i.e., not calibrated).
Intermediate Stop A not enabled on any channel or on the manual switch, Open to Int. Stop A = 20%, Close to Int. Stop A = 80%, no nudge amount.
Intermediate Stop B not enabled on any channel or on the manual switch, Open to Int. Stop B = 40%, Close to Int. Stop B = 60%, no nudge amount.
Minimum load = 0.144A (17 Watts).
Stall load = 6.04 Amps (the maximum rating of the unit at 115V, 695 Watts).
Turn on Delay time = 0 sec (immediate).

Calibration & Intermediate stops:

If you are changing the motor direction (C6 O2) or Using the bottom reference (C10 O11), these options must be selected before doing the calibration (C10 O10).
The motor limits must be set before doing the calibration. If the limits are changed, then you must recalibrate.
Calibration is required before intermediate stops will work. If the unit is not calibrated correctly, the intermediate stops will be different when going open than when going closed. The stops will also be off if the material is thick, or if the motor does not move at a constant speed in both directions.
The intermediate stops are calculated based on % of travel time plus nudge offset.
% and nudge can be set before calibration if so desired.
20% = rolling shade barely closed = 20% down from top (assuming top is reference)
If travel time is unknown (not yet calibrated), all intermediate stop commands are ignored.
If you are changing the intermediate stop percent, then you must calibrate the unit after entering the new percent before it becomes active.
If the unit is calibrated and power cycles, and an intermediate stop button is pressed before the unit goes to the reference, then the command will cause the motor to "auto reset," i.e., go to the reference limit, then back to the intermediate stop.

Standard action:

There is an auto reset every 6TH intermediate stop movement if the motor does not go to either limit. Any user action that stops the motor part way will cause the next intermediate stop command to auto reset.

There is an auto reset if an intermediate stop command is received that will cause the motor to go up, or if the motor has gone up anytime since being at the top.

This Quick Reference guide does not include all SC1 features. If you have a questions on a possible features, please contact Draper, Inc.
24 Channel IR Remote (C072.017) and IR eye required for prgramming. SC1's are factory set channel 1. SGC4's are factory set channel 1.
SPGC4 has 4 SC1's with factory set main channels 1 through 4. Main channel information applies to step 2 of programming (see below).



What is S + 7 + 7 ?
Answer: Hold all three buttons at the same time to get "into" program mode.

Special Program Note:

Wait no more than 8 seconds between steps or SC1 exits program mode.

Example:

I need to change the SC1 main channel from current channel to a new channel. **From Above:**

S+7+7,	O#	C1	O "N"	Stop.
Step 1	Step 2	Step 3	Step 4	Step 5

Step 1-Remote Into Program Mode
S+7+7, see left, remote LED in upper left will blink on release of buttons if step is done properly.

Step 2- SC1 Into Program Mode
O# is open button of current SC1 main channel. SC1 LED will light if step is done correctly.

Step 3- File On SC1 To Change
Hit close of channel listed, SC1 LED will blink.

Step 4- Change File
Hit open of channel listed or wanted, SC1 LED will blink.

Step 5- Stop
Hit red Stop button, except calibration, LED will go off.

Intelligent (ILT) Motor Overview

The Intelligent Motor is designed to offer the sophisticated, diverse control of a window shade. The motor contains a controller inside of it. This means that there are two wires exiting the motor head. One wire is for power. It is a high voltage wire which will supply power to the motor at all times. The other wire is low voltage. This wire will connect to control and operate the motor.

High voltage wire can be hard wired into power or one can attach a 3 prong and plug it into an outlet.

The low voltage wire can connect to multiple items for operation. Some items are:

ILT Wall Switch, 121171- This switch must be used for setting limits. Limits are not factory set and must be done on site with this item. It can also be used to control the motor.

ILT Wall Switch
121171

4-Jack Modular Interface, C156.096- This item has 4 modular jacks for plugging in any combination of inputs such as ILT switches and motors. This device also has a dry contact interface for operating Intelligent Motors with dry contacts. All motors connect to the interface will operate as a group.

4-Jack Modular Interface,
C156.096

RF Receiver, C156.095- This receiver plugs onto the low voltage lead or into a 4-jack interface. You use RF transmitters (page 7) to run the motors.

RF Receiver, C156.095

IR Receiver and Transmitter, single channel, 121169- The eye plugs into a 4-jack interface for IR control.

IR Receiver and Transmitter, single channel—
121169

RS 485 Control Tap – C156.111; and Power Tap – C156.112 -
The RS 485 tap allows one to connect Intelligent Motors together on a network to run shades from an IP interface.

RS 485 Control Tap, C156.111, and
Power Tap, C156.112

A variety of other controls can control the Intelligent Motor when it is on an RS 485 network. Sun sensors, smart switches are just a couple. If you are planning to work Intelligent Motors from a RS 485 network please review these documents and contact Draper, Inc.

ILT Switch and Limit Sets

The ILT switch has a modular connector on the back to plug in the Intelligent Motor, once the motor is connected then limits can be set and the shade can be operated. The ILT switch fits into a single gang box with a decora face plate and is flush with the plate.

Setting Limits on an Intelligent Motor Shade are as follows:

① Connect the ILT switch to motor via the modular cable port. The cable connectors MUST NOT be crimped in reverse as with standard telephone cable.
② Set the slide switch to the lower position. Press and hold the down button to run the shade to the desired lower limit. If the shade moves the opposite direction, release the button and depress the stop button. This will reverse the motor direction. You may then continue running to the lower limit. Once at the lower limit move the slide switch to the middle position.
③ Set the slide switch to the upper position. Move the shade to the desired upper limit by depressing the up button.
④ Once at the upper limit move the slide switch to the middle position. When the slide switch is in the middle position, then the shade is in user mode.

The shade will move in momentary fashion when the slide switch is up or down for setting limits.

To set an intermediate stop:

① Run the shade to the desired intermediate stop.
② Press the stop button for at least 3 seconds to record the position.
③ Now when the shade is stopped, you may press the stop button to run it to the record intermediate stop position.



Back View

ILT Dry Contact Interface
Wiring Diagram



Dry Contact Input

The ILT Dry Contact Interface will operate up to four ILT motors as a group from an external device such as a home automation system.

① To activate an UP command, a momentary contact closure is required between the UP and COM terminals.

② To activate a DOWN command, a momentary contact closure is required between the DWN and COM terminals.

③ To activate a STOP command, a momentary contact closure is required.

2" W. x 2" L. x 1 1/8" H.

Typical Application



Draper Digital Network IP Interface

The Draper Digital Network IP Interface is a serial device server used to connect the RS485 SDN BUS consisting of ILT2 motors and control devices to a managed LAN network. The firmware of the IP Interface is remotely upgradeable over the Internet. The SDN IP Interface contains an internal Web server with configuration software that is accessed via any standard Web browser. The IP Interface is compatible with both the PC and the Mac platforms.

Main software features:

An almost unlimited number of personalized GUIs can be configured and created, remotely deployed and then accessed from a link on the individual users desktop allowing personal solar shading control. The Graphical User Interface actions have associated URL commands for interfacing with 3rd party IP control systems. Remote access to the IP Interface for configuration and remote diagnostics is available through HTTP port 80, un-proxied. Completely automated shade movements can be programmed via internal time scheduling and solar angle utility.

LAN:
Ethernet: 10/100 Mbps, RJ45
Protection: Built-in 1.5 KV magnetic isolation

Serial Interface:
Interface: RS- 232 (Half duplex RS-485 with adapter)
No. of Ports: 1
Port Type: DB9 (Male)
Transmission Speed: 1.2 -115 Kbps
Signals: Tx, Rx, RTS, CTS, DTR, DSR, DCD, GND
Serial Line Protection: 15 KV ESD for all signals

Serial Communication Parameters:
Parity: None, Even, Odd, Space, Mark
Data Bits: 5,6,7,8

Power Requirements:
Power Input: 9 to 18 VDC
Power Consumption: 300 mA@12V

Mechanical:
Casing: Steel case (1 mm)
Dimensions (w x H x D): 2.87 x 1.00 x 3.75 in
Gross Weight: 0.580 kg

Software Features:
Protocols: ICMP, IP, TCP, UDP, DHCP, BOOTP, Telnet, DNS, SNMP, HTTP, SMTP
Configuration: Web console, Telnet console

Environment:
Operating Temperature: 0 to 55°C (32 to 131OF), 5 to 95%RH, non-condensing
Storage Temperature: -20 to 85°C (-4 to 185°F), 5 to 95%RH, non-condensing

Regulatory Approvals:
EMC FCC Class A, CE Class A, Safety UL, CUL, TÜV

Warranty:
5 years

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Draper Digital Network

The Draper Digital Network which is run from the IP interface mentioned on the previous page is programmed through a series of actions. These actions and items used to program the system are constantly changing so it is required to contact Draper before programming a Digital Network. Here are the items that you will currently need to program a Draper Digital Network.

1 Laptop Computer
2 RS 485 adaptor cable- Draper can direct you where to buy.
3 DB9 to Cat 5 convertor- Draper can direct you where to buy.
4 Cat 5 patch cord at least 3' long
5 ILT TAP- Buy from Draper
6 9V battery
7 GUI for programming- Draper will provide GUI

With these items, you will be able to obtain motor addresses and set group address to operate shades in the desired groups, up to 16 groups per motor.

The first part of installing a Draper Digital Network is to obtain the address of each motor and note the address on a planning sheet or building floor plan. To obtain a motor address, you will need to do the following.

1 Power must be on to the shade.
2 You will need the GUI installed on your laptop.
3 You will connect the laptop to the low voltage line on the motor. This is done by connecting the RS 485 adaptor cable to the laptop, the DB9 adaptor to the RS 485 cable, a Cat 5 cable from the DB9 to the ILT tap, and then you plug the motor into the ILT tap. A 9V battery or transformer will need to be supplying power to the tap to work.
4 You will then bring up the motor GUI and hit the "GET ADDRESS" button to retrieve the motor address.
5 You will then need to mark down the address on a planning sheet or floor plan.

The next part of the install is the planning out of groups for operating the shades. You have the motor address, but you need to decide what groups you want the motor to belong to by assigning like group addresses with different motors. If two motors have the same address in any group, then they will run together when that address is told to go up or down. Steps to consider in grouping shades are:

1 Each motor address must be 6 characters long using numbers 0-9 and A-F.
2 You have 16 group addresses per motor.
3 Any two shades with the same address in them, whether it is a group 1 or group 5 or group16 address, will work together.
4 If using smart switches or virtual switches, you will want to program an individual address to each motor to make motor changes easier.

The next part of the install is to program the group addresses. For this you will have to check several different things:

1 Are the low voltage lines from the motors going to an ILT Tap? Are the ILT Taps connected together with Cat 5? Do you have a 12V trans former feeding power to every 40 ILT Taps?
2 You may use a splitter to put up to 3 motors in an ILT Tap, but a motor cannot have more than 30' of cable between it and an ILT Tap even with a splitter.
3 If the Draper Digital Network is programmed and powered, then you may plug your computer into an ILT Tap on the network and program.
4 The laptop will plug in as before, but the ILT Tap that it now plugs into will be on the network.
5 You will pull up the GUI that you used to get the motor address.
6 You will type in a motor address that you wish to program and hit the "GET DATA" button.
7 The motor will talk back. If you get an error, then you need to check your set-up as communication is not getting to the motor.
8 You will then change the group addresses to be as you want them and hit "Compute IP Range", then hit the "Send Data" button. This will program the motor with the addresses that you want.
9 You will then proceed back to step 6 for the next motor address until all motors are programmed.

Lastly, you will program smart switches and the IP interface to the switch configuration that you want. You program the IP interface and smart switch as follows.

1 A smart switch is programmed with the same set-up as you used to get a motor address. Except, you will plug in a smart switch not a motor, but you will plug a smart switch into the ILT Tap by connecting the Cat 5 to the switch.
2 You will pull up a GUI on your laptop for programming the switch and you will determine what addresses you want the switch to send when buttons are pressed.
3 To program the IP interface, you will need to connect to the server. You will type in the IP address of the interface and access the settings on the interface.
4 At the settings page, you will set up virtual buttons and what actions you want behind each button.

Programming switches, motor, and IP interface will have more details than this so please use these pages as a reference for the amount of work done to program the system.

RS485-ILT Link

DESCRIPTION

The RS485-ILT Link will enable third party communication to Somfy's line of intelligent (ILT) motors, and for programming and receiving addresses from intelligent motors.

MECHANICAL SPECIFICATIONS

Overall Dimensions: L: 3 1/8 in. W: 2 5/8 in. H: ¾ in.

CONNECTION DIAGRAM



Low Voltage
Input Detail



A termination resistor of at least 120ohms should be placed only at the extreme ends of the data line, and no more than two resistors should be placed in any system that does not use repeaters.

RS485 Connector
(RJ45) Pin Out



1 - RS485 A
2 - RS485 B
3 - NOT CONNECTED
4 - BUS POWER +9V
5 - BUS POWER +9V
6 - NOT CONNECTED
7 - BUS POWER GND
8 - BUS POWER GND

ORDERING INFORMATION

Description	Part Number
RS485 - ILT Link	1870127

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Draper Digital Network—Smart Switch

Description: The Smart Switch is a control device which outputs the SDN protocol over RS-485, providing digital control of the Digital Network. The Smart Switch allows the SON to function as a stand alone natural lighting control system and can be fully customized though the SON Smart Switch Configuration Software. The Smart Switch is available in 3-button and 6-button versions which can be located anywhere on the Somfy Digital Network.

Specification:

-Three button Smart Switch -Catalog # 1810827
-Six button Smart Switch -Catalog # 1810828
-Buttons are fully programmable
-Standard Decora style
-Mounts in a single gang box
-8 dry contact inputs for system integration
-IR compatible
-Warranty: 5 years

Back of Switch



411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

110-120V Standard and Quiet Motorized Flexshade



Idler End Cap
Small C002.572
Large C002.676

Idler Mounting Bracket

Right Small	C002.062.49
Right Large	C002.055.49
Left Small	C002.063.49
Left Large	C002.056.49
(Shown to right)	
Ceiling Small	C002.064.49
Ceiling Large	C002.064.49

Fascia:
3 7/8”
4 5/8”



Motor Adapter Bracket

Small	C010.240
	as shown
Large	C010.267
	not shown
Stud	C002.101
	brackets only
	not shown
Quiet	C021.016
	Stud used with Quiet motor

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Draper Motor Grid

	Standard motor	Motor Specifications at a glance						Available tube sizes								Draper Products					Min/ Max, C.O.,			Limit Type
		Quiet Motor	Torque (Nm)	RPM	Volts	Amps	Parallel Wire	1.5" Aluminum	2" Aluminum	2" Steel	2 1/8" Steel	3" Steel	3 1/8" Steel	4" Steel	6"	Flexshade MO	Flexshade 2	Lightbloc	Skylight	Colossal	Min Width	Min. Crank Width	Crank overide	"Limit Setting P=Push Button T=Turn Screw R=Remote/Switch Set"
Standard 4-Wire Motors	Flexshade	506S2RH		6	38	120	0.95	N		•	•	•	•	•			•		•	•		24"	29"	Y	P
		510S2RH		10	38	120	1.3	N		•	•	•	•	•			•			•		25"	30"	Y	P
		504S2RH-ST	Y	4	32	120	0.95	N		•	•	•					•		•			32"	37"	Y	P
		506G	Y	6	30	120	0.9	N		•	•	•	•	•			•					24"			T
	Flexshade 2	506S2PA		6	38	120	0.95	N							•			•				6"			T
		510S2PA		10	38	120	1.3	N							•			•				36"			P
	Flexshade/Export	506S1RH		6	38	230	0.95	N		•	•	•	•	•			•		•	•		24"	29"	Y	P
		510S1RH		10	38	230	0.95	N		•	•	•	•	•			•					25"	30"	Y	P
		503S1RH-ST	Y	3	32	230	1.3	N		•	•	•					•		•			32"	37"	Y	P
	Flexshade 2/Export	506S1PA		6	38	230	0.95	N							•			•				36"			T
		510S1PA		10	38	230	1.3	N							•			•				36"			T
		660R2		60	14	120	2.5	N								•					•	48"			T
Altus Motors		506S2RH-RTS		6	38	120	0.95	Y		•	•	•	•	•			•					27 1/8"	32¼"	Y	R
		510S2RH-RTS		10	38	120	1.3	Y		•	•	•	•	•			•			•		29"	34"	Y	R
		504S2RHST-RTS	Y	4	38	120	0.95	Y		•	•	•					•					32"			R
		506S2-RTS		6	38	120	0.95	Y							•			•				36"			R
		510S2-RTS		10	38	120	1.3	Y							•			•				36"			R
DC		ST-30	Y	2	28	24DC	1.8	N	•								F/S 24V only							R	
		BA-RTS		1	27	12DC	n/a	N/A	•								F/S Battery only						R		
ILT		506S2ILTRH		6	38	120	0.95	Y		•	•	•	•	•			•		•			27¼"	32¼"	Y	R

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S2RH	

Torque in Nm: 6		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: **No**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel, 3” steel, 3 1/8” steel		
Product (s) Used In: Motorized Flexshades, Lightblocs, Skylights		
Min. Shade Width: 24” om With Crank Override 29” om		Part No: C047.054

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate Quick Disconnect, 4-wire only
Limit Type: Push Button	Used in: Flexshade, Skylight, Lightbloc Hardware Only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other controls ask Draper, Inc.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor using a motor test cable and adjust limits.

3. Let electrician connect to wiring

4. If control programming is required, then program and set controls.

5. Test motors through wiring using switching

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Special Notes:

This is the standard motor for Draper’s Flexshade line. If you are pricing a shade, this is the included motor in the pricing.

	Motor Name: 510S2RH	

Torque in Nm: 10		RPM: 38
Volts: 120	Amps: 1.3	Parallel Wire: **No**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel, 3” steel, 3 1/8” steel		
Product (s) Used In: Motor Flexshades, Skylights as needed		
Min. Shade Width: 25” om With Crank override 30” om		Part No: C047.056

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Push Button	Used in: Flexshade and Skylight Hardware Only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other controls ask Draper, Inc.

Installation Procedure:

1. Install Brackets, endcaps, or box to mount shade

2. Test motor using a motor test cable and adjust limits.

3. Let electrician connect to wiring

4. If control programming is required, then program and set controls.

5. Test motors through wiring using switches

Special Notes:

This motor is step up in power from the standard motor. It is included in pricing where needed.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 504S2RH-ST	

Torque in Nm: 4		RPM: 32
Volts: 120	Amps: .95	Parallel Wire: **No**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel		
Product (s) Used In: Motorized Flexshades, Lightblocs		
Min. Shade Width: 32” om With Crank Override 37” om		Part No: C047.158

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Push Button	Used in: Flexshade and Lightbloc Hardware Only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other controls ask Draper, Inc.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor using a motor test cable and adjust limits.

3. Let electrician connect to wiring

4. If control programming is required, then program and set controls.

5. Test motors through wiring using switching

Special Notes:

This is the quiet motor for Draper’s Flexshade line. If you are pricing a shade, this is not included in the shade pricing. It requires an extra charge.

Decibels--42

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506G	Motion Control Motor

Torque in Nm: 6		RPM: 34
Volts: 120V	Amps: .9	Parallel Wire: **No**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” Steel, 3” steel, 3 1/8’ steel		
Product (s) Used In: Motorized Flexshades		
Min. Shade Width: 24” om		Part No: C047.134.001

Standard Motor Lead Length: 6’	Optional Lead Lengths: 30’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Turn Screw	Hardware Restrictions: Cannot go into Duals, Access Pocket, Ult. Access, Lightblocs, Flexshade 2, Skylight and Colossal.

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other controls ask Draper, Inc.

Installation Procedure:

1. Install hardware for shade
2. Mount motor and test limits and operation
3. Let electrician tie into controls
4. Program controls
5. Test operation through controls

Special Notes:

This quiet motor does not have a crank override option, and it does not fit into all hardware._Used for shades either too small or too large for standard quiet motors.

Decibels--42

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S2ILTRH	

Torque in Nm: 6		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: **Yes**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel, 3” steel, 3 1/8” steel		
Product (s) Used In: Motorized Flexshades, Lightblocs		
Min. Shade Width: 27 1/4” om With Crank Override 32 1/4”		Part No: C047.162

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Flexshade, Skylight, Lightbloc Hardware Only

Controls that motor can wire into: This motor does not wire into any controls. It is controlled via controllers that plug into the data cable existing the motor head.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor, set limits, and bind to controls

3. Let electrician connect to wiring

Special Notes:

This motor has built-in intelligence for operation. It has both a data cable and high voltage cable exiting the motor head. The data cable ties into control and the high voltage ties into power.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 504S2ILTRH-ST	

Torque in Nm: 4		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: **Yes**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel		
Product (s) Used In: Motorized Flexshades, Lightblocs		
Min. Shade Width: 32” om		Part No: C047.164

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Motorized Flexshade

Controls that motor can wire into: This motor does not wire into any controls. It is controlled via controllers that plug into the data cable existing the motor head.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor, set limits, and bind to controls

3. Let electrician connect to wiring

Special Notes:

This motor has built-in intelligence for operation. It has both a data cable and high voltage cable exiting the motor head. The data cable ties into control and the high voltage ties into power.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S2RH-RTS	

Torque in Nm: 6		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: **Yes**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel, 3” steel, 3 1/8” steel		
Product (s) Used In: Motorized Flexshades		
Min. Shade Width: 27 1/8” om With Crank Override 32 1/4”		Part No: C047.143

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Flexshade, Lightbloc, Skylight Only Dual Headboxes Not Recommended

Controls that motor can wire into: This motor does not wire into any controls. It is controlled via RTS Transmitters, both handheld and wall switch.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor, set limits, and channels from transmitter.

3. Let electrician connect to wiring

Special Notes:

This motor has a built-in radio receiver, and it is an up-charge on regular shade pricing.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 510S2RH-RTS	

Torque in Nm: 10		RPM: 38
Volts: 120	Amps: 1.3	Parallel Wire: **Yes**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel, 3” steel, 3 1/8” steel		
Product (s) Used In: Motor Flexshades and Skylights as needed		
Min. Shade Width: 29” om With Crank override 34” om		Part No: C047.157

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Flexshade and Skylight Hardware Only Dual Headboxes Not Recommended

Controls that motor can wire into: This motor is not wired into any controls. It is operated through RTS transmitters, both hand held and wall switch.

Installation Procedure:

1. Install Brackets, endcaps, or box to mount shade

2. Test motor and set limits and channels using remote

3. Let electrician connect to wiring

Special Notes:

This motor has a built-in radio receiver, and it is an up-charge on regular shade pricing.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 504S2RHST-RTS	

Torque in Nm: 4		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: **Yes**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel		
Product (s) Used In: Motor Flexshades		
Min. Shade Width: 32” om		Part No:

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Flexshade and Skylight Hardware Only Dual Headboxes Not Recommended

Controls that motor can wire into: This motor is not wired into any controls. It is operated through RTS transmitters, both hand held and wall switch.

Installation Procedure:

1. Install Brackets, endcaps, or box to mount shade

2. Test motor and set limits and channels using remote

3. Let electrician connect to wiring

Special Notes:

This motor has a built-in radio receiver, and it is an up-charge on regular shade pricing.

This motor is also a quiet motor.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S2PA	

Torque in Nm: 6		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: No
Roller Diameter Choices: 4”		
Product (s) Used In: Flexshade 2		
Min. Shade Width: 36” om		Part No: C047.050

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Turn Screw	Used in: Flexshade 2 hardware only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other controls ask Draper, Inc.

Installation Procedure:

1. Mount hardware and shade into hardware
2. Test motor and adjust limits
3. Let electrician tie into electrical
4. Program controls
5. Test shade operation through switching

Special Notes:

This is the standard motor for a Flexshade 2

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 510S2PA	

Torque in Nm: 10		RPM: 38
Volts: 120	Amps: 1.3	Parallel Wire: **No**
Roller Diameter Choices: 4” steel		
Product (s) Used In: Flexshade 2		
Min. Shade Width: 36” om		Part No: C047.058

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Push Button	Used in: Flexshade 2 Hardware only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other controls ask Draper, Inc.

Installation Procedure:

1. Install Brackets, endcaps, or box to mount shade

2. Test motor using a motor test cable and adjust limits.

3. Let electrician connect to wiring

4. If control programming is required, then program and set controls.

5. Test motors through wiring using switches

Special Notes:

This motor is step up in power from the standard Flex 2 motor. It is included in pricing where needed.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S2ILT	

Torque in Nm: 6		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: **Yes**
Roller Diameter Choices: 4” steel		
Product (s) Used In: Flexshade 2		
Min. Shade Width: 36” om		Part No: C047.146

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Flexshade 2 Hardware only

Controls that motor can wire into: This motor does not wire into any controls. It is controlled via controllers that plug into the data cable existing the motor head.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade
2. Test motor, set limits, and bind to controls
3. Let electrician connect to wiring

Special Notes:

This motor has built-in intelligence for operation. It has both a data cable and high voltage cable existing the motor head. The data cable ties into control and the high voltage ties into power.

Not for all FlexShade 2 sizes.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S2-RTS	

Torque in Nm: 6		RPM: 38
Volts: 120	Amps: .95	Parallel Wire: **Yes**
Roller Diameter Choices: 4” steel		
Product (s) Used In: Flexshade 2		
Min. Shade Width: 36” om		Part No: C047.117

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Flexshade 2 Hardware only

Controls that motor can wire into: This motor does not wire into any controls. It is controlled via RTS Transmitters, both handheld and wall switch.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor, set limits, and channels using transmitter.

3. Let electrician connect to wiring.

Special Notes:

This is a radio motor for the Flexshade 2, and it is an extra charge on top of the shade price.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 510S2-RTS	

Torque in Nm: 10		RPM: 38
Volts: 120	Amps: 1.3	Parallel Wire: **Yes**
Roller Diameter Choices: 4” steel		
Product (s) Used In: Flexshade 2		
Min. Shade Width: 36” om		Part No: C047.118

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-2 w/ground	Plug Options: 3-prong
Limit Type: Remote Set	Used in: Flexshade 2 Hardware only

Controls that motor can wire into: This motor does not wire into any controls. It is controlled via RTS Transmitters, both handheld and wall switch.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor, set limits, and channels using transmitter.

3. Let electrician connect to wiring

Special Notes:

This is a radio motor for the Flexshade 2, and it is an extra charge on top of the shade price.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S1RH	

Torque in Nm: 6		RPM: 38
Volts: 230	Amps: .95	Parallel Wire: **No**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel, 3” steel, 3 1/8” steel		
Product (s) Used In: Motorized Flexshades, Lightblocs, and Skylights		
Min. Shade Width: 24” om With Crank Override 29” om		Part No: C047.055

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Push Button	Used in: Flexshade, Lightbloc, Skylight Hardware Only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other 230V controls ask Draper, Inc.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor using a motor test cable and adjust limits.

3. Let electrician connect to wiring

4. If control programming is required, then program and set controls.

5. Test motors through wiring using switching

Special Notes:

This is the standard motor for Draper’s 230V Flexshade line. If you are pricing a shade, this is the included motor in the pricing.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 510S1RH	

Torque in Nm: 10		RPM: 38
Volts: 230	Amps: 1.3	Parallel Wire: **No**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel, 3” steel, 3 1/8” steel		
Product (s) Used In: Motor Flexshades		
Min. Shade Width: 25” om With Crank override 30” om		Part No: C047.160

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Push Button	Used in: Flexshade Hardware Only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on 230V other controls ask Draper, Inc.

Installation Procedure:

1. Install Brackets, endcaps, or box to mount shade

2. Test motor using a motor test cable and adjust limits.

3. Let electrician connect to wiring

4. If control programming is required, then program and set controls.

5. Test motors through wiring using switches

Special Notes:

This motor is step up in power from the standard export motor. It is included in pricing where needed.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 503S1RH-ST	

Torque in Nm: 3		RPM: 32
Volts: 230	Amps: .95	Parallel Wire: **No**
Roller Diameter Choices: 2” aluminum, 2” steel, 2 1/8” steel		
Product (s) Used In: Motorized Flexshades, Lightblocs		
Min. Shade Width: 32” om With Crank Override 37” om		Part No: C047.159

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Push Button	Used in: Flexshade and Lightbloc Hardware Only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other 230V controls ask Draper, Inc.

Installation Procedure:

1. Install brackets, endcaps, or box to mount shade

2. Test motor using a motor test cable and adjust limits.

3. Let electrician connect to wiring

4. If control programming is required, then program and set controls.

5. Test motors through wiring using switching.

Special Notes:

This is the quiet motor for Draper’s 230V Flexshade line. If you are pricing a shade, this is the included motor in the pricing.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 506S1PA	

Torque in Nm: 6		RPM: 38
Volts: 230	Amps: .95	Parallel Wire: No
Roller Diameter Choices: 4”		
Product (s) Used In: Flexshade 2		
Min. Shade Width: 36” om		Part No: C047.051

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Turn Screw	Used in: Flexshade 2 Hardware only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo for questions on other 230V controls ask Draper, Inc. Of course, these are 230V versions of these controls.

Installation Procedure:

1. Mount hardware and shade into hardware
2. Test motor and adjust limits
3. Let electrician tie into electrical
4. Program controls
5. Test shade operation through switching

Special Notes:

This is the standard motor for a Flexshade 2

in export sales.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 510S1PA	

Torque in Nm: 10		RPM: 38
Volts: 230	Amps:1.3	Parallel Wire: No
Roller Diameter Choices: 4”		
Product (s) Used In: Flexshade 2		
Min. Shade Width: 36” om		Part No: C047.059

Standard Motor Lead Length: 6’	Optional Lead Lengths: 12’ and 24’
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Turn Screw	Used in: Flexshade 2 Hardware only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo. For questions on other 230V controls ask Draper, Inc.

Installation Procedure:

1. Mount hardware and shade into hardware
2. Test motor and adjust limits
3. Let electrician tie into electrical
4. Program controls
5. Test shade operation through switching

Special Notes:

This is the more powerful motor for a 230V Flexshade 2. The price list is adjusted for the Motor.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: 660R2	

Torque in Nm: 60		RPM: 14
Volts: 120	Amps: 2.5	Parallel Wire: No
Roller Diameter Choices: 6”		
Product (s) Used In: Colossal		
Min. Shade Width: 48” om		Part No: C047.032

Standard Motor Lead Length: n/a	Optional Lead Lengths: No Options
Lead Type: 18-3 w/ground	Plug Options: Wago w or w/o wall plate Anderson w or w/o wall plate
Limit Type: Turn Screw	Used in: Colossal Only

Controls that motor can wire into: Isolating Relays, SC1 controllers, GC4 control, SGC4 control, SPGC4 control, Keyed Wall Switch, SP/DT toggle switch, DP/DT toggle switch, Animeo. For questions on other controls ask Draper, Inc.

Installation Procedure:

1. Mount complete unit
2. Test motor and adjust limits
3. Let electrician tie into electrical
4. Program controls
5. Test shade operation through switching

Special Notes:

This is the standard motor for a Colossal.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: ST-30	

Torque in Nm: 2		RPM: 28
Volts: 24VDC	Amps: 1.8	Parallel Wire: YES
Roller Diameter Choices: 1 ½" aluminum		
Product (s) Used In: Low Voltage Shades only		
Min. Shade Width:		Part No: C047.165

Standard Motor Lead Length: 15'	Optional Lead Lengths: N/A
Lead Type: 22-2, awg/conductor	Plug Options: Plug-in Transformer or power box
Limit Type: Remote Set	Used in: Brackets, fascia, or headbox only

Controls that motor can wire into: Works with RTS transmitters only, handheld and wall switch

Installation Procedure:

1. Install hardware
2. Install motorized shade
3. Install transformer
4. Test motor and set limits from transmitter

Special Notes:

This motor can possibly tie into existing low voltage wiring.

Transformer required to power shades.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

	Motor Name: BA-RTS	

Torque in Nm: 1		RPM: 27
Volts: 12 V	Amps: n/a	Parallel Wire: n/a
Roller Diameter Choices: 1 ½" aluminum		
Product (s) Used In: Battery Flexshade only		
Min. Shade Width:		Part No: C047.144

Standard Motor Lead Length: n/a	Optional Lead Lengths: n/a
Lead Type: n/a	Plug Options: n/a
Limit Type: Remote Set	Used in: Brackets, fascia, or headbox only

Controls that motor can wire into: Works with RTS transmitters only, handheld and wall switch

Installation Procedure:

1. Install hardware
2. Install motorized shade
3. Install battery pack
4. Test motor and set limits from transmitter

Special Notes:

Dual Battery Pack part no. is C105.005.

Replacement motor price does include a battery pack and is kit part number 122215.

DRAPER®
411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Minimum Shade Sizes

Motorized

24" OM (24 1/8" IM) 506 Motorized shade regular motor in 2" roller (Dual 24 1/8" OM -24¼" 1M)
(If using Somfy 504 Quiet Motor add 7½")

24 1/8" OM (24¼" IM) 506 Motorized shade regular motor in 3" roller (If using Somfy 504 Quiet Motor add 7½")

24¼" OM (24 3/8" IM) 506 Motorized shade regular motor in 3" roller with 1/8" brackets (If using Somfy 504 Quiet Motor add 7½")

27 1/8" OM (27¼" IM) Motorized shade with 506 Altus RTS Round Head or ILT Motor in a 2" or 2 1/8" Roller (If ILT Quiet Motor or Altus Quiet Motor, add 7½")

27¼" OM (28 3/8" IM) Motorized shade with 506 Altus RTS Round Head or ILT Motor in 3" or 3 1/8" Roller (If ILT Quiet Motor or Altus Quiet Motor, add 7½")

14" OM (14 1/8" IM) 12 V Battery Motor shade

18" OM (18 1/8" IM) Low Voltage ST30 24 V Quiet Motor

24 7/16" OM (24 9/16" IM) Motorized lightbloc 506 motor (Dual 24 9/16" OM - 24 11/16" IM) (If using Somfy 504 Quiet Motor add 7½")

27¼" OM (27 3/8" IM) Motorized Lightbloc with 506 Altus RTS Round Head or ILT Motor (add 7½" if ILT Quiet Motor or Altus Quiet Motor)

36" OM (36 1/8" IM) Flexshade 2

36" OM (36 1/8" IM) Colossal

28" OM (28¼" IM) Roman Motorized regular motor

29" OM (29 1/8" IM) 506 Motorized shade with crank override regular motor-old style endcap system

29 1/8" OM (29¼" IM) 506 Motorized shade with crank override regular motor-small snap on endcap system

29 3/16"OM (29 5/16" IM 506 Motorized shade with crank override regular motor -large snap on endcap system

24" OM (24 1/8" IM) MotionCo Quiet Motor in 2" roller (No small pocket hdbx available at this time.)

24 1/8" OM (24¼" IM) MotionCo Quiet Motor in 3" roller

28 5/8" OM (29 3/8" IM) Skylight using 506 Motor or crank operated (Using 1½" Spring roller up to 96" high. 1¾" minimum is 34 3/8" OM (35 1/8" 1M) (NOTE: The spring roller is the ruler of the minimum size.)

33½" OM (34¼" IM) Skylight using Somfy 504 Quiet Motor (Using 1½" Spring roller up to 96" high. 1¾" minimum is 34 3/8" OM (35 1/8" 1M) (NOTE: The spring roller is the ruler of the minimum size if using the 1¾" spring roller.)

29 1/8" OM (29 7/8" IM) Skylight using ILT or Altus RH Motor

36 5/8" OM (37 3/8" IM) Skylight using ILT Quiet Motor or Altus Quiet Motor

The following is for coupled shades

27" OM (27 1/16" IM -we take a 1/16" off the left & right panel to equal a total 1/8" IM deduction) for 506 Motorized Coupled unit (If using Somfy 504 Quiet Motor add 7½")

OR

30 1/8" OM (30 1/16" IM -we take a 1/16" off the left & right panel to equal a total 1/8" 1M deduction) for 506 Altus RTS Round Head or ILT Motor (If ILT Quiet Motor or Altus Quiet Motor, add 7½")

9¾" OM (9¾" IM -No IM deductions are made on center panels) for a center sleeve on a coupled unit

6¼" OM (6 5/16" IM -we take a 1/16" off the left & right panel to equal a total 1/8" IM deduction) for idler end of a couple unit

Installation Instructions
Motorized FlexShade by Draper

⚠Caution

① Inspect all boxes to make sure you have received the proper shades and parts. Controls may be shipped separately, or in same carton as shades.
② Open cartons lengthwise.
③ All brackets, fascia, headboxes, pockets, wall clips, and other hardware must be installed level. Shades must be level and square.
④ All motors should be tested and limits set using test cord before electrician wires shade.
⑤ Before connecting switches, controls, or electrical, make sure power is off. Wiring indicated in diagram by dashed lines *must be completed by an electrician.*
⑥ Do not wire motors in parallel without written permission from Draper.
⑦ It is the installer's responsibility to make sure appropriate fasteners are used for mounting surface.
⑧ ***Please read the following installation guidelines thoroughly and follow them carefully. Failure to do so may cause product to fall or otherwise fail, and invalidates warranty.***

Please Note: Custom products/installations may not be reflected by this document. Call Draper, Inc. if you have questions about your installation.

Mounting Brackets

① Mark wall, jamb or ceiling for placement of mounting brackets.
⚠Caution: Before mounting shades, verify measurements on the card provided with the shade, and ensure the brackets are installed at the correct width.
② Drill small starter hole in mounting surface (if necessary).
③ Mount brackets using appropriate fasteners for surface (see Fig. 1 for bracket types). ***The installer is responsible for selecting mounting hardware appropriate for site conditions.***

Brackets



Figure 1

④ Place operator (motor) end onto its bracket. If a coupled unit, place slotted end of shade into coupler bracket, then insert idler pin end of next shade into coupler bracket.
⑤ Slide notched pin on idler end into slot on bracket. Slip retainer clip onto idler end between bracket and roller (see Fig. 2).



Please Note: Install motor so that limit switches are accessible.

Figure 2

Mounting Endcaps

① Snap end covers into place (see Fig. 3).
② Mark wall, jamb or ceiling for placement of mounting endcaps.
③ Drill small starter hole (if necessary) in mounting surface.
④ Mount endcaps using appropriate fasteners for surface (see Fig. 4 for endcap dimensions). If this is a coupled unit, be sure to mount coupled endcap in the center position. ***The installer is responsible for selecting mounting hardware appropriate for site conditions.***
⚠Caution: Before mounting shades, verify measurements on the card provided with the shade, and ensure the endcaps are installed at the correct width.



Figure 3

Endcaps



Figure 4

⑤ Place operator (motor) end into its endcap (see Fig. 5).
⑥ For coupled units insert idler pin into center (coupled) endcap. Next Insert slotted end of next shade into the center (coupled) endcap (see Fig. 5).
⑦ Slide notched pin into idler endcap and attach retainer clip(see Fig. 5).




Three washers not required if fascia or headbox endcaps look like this.
Shade Roller
Coupling (slotted)
Shade Roller
Coupling (idler pin)
Bearing Endcaps
Operator End
Bearing boss oriented toward slotted coupling
Coupler
Three washers required if fascia or headbox endcaps look like this.

Figure 5

Fascia

① Snap end covers onto endcaps.
② If Crank override is provided, remove crank handle assembly from endcap and discard washers (see Fig. 6)
③ Follow steps 1 through 6 under "Mounting Endcaps" section.
④ Place groove along top of fascia over endcaps, and snap into place (see Fig. 7 on page 2). ***Fascia is not fully seated until it clicks into place on both ends. Once in place, check for secure fit. If not secure, secure with appropriate fastener (not included).***



Figure 6

If you encounter any difficulties installing or servicing your Motorized FlexShade, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999, or fax (765) 987-7142.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright © 2008 Draper Inc. Form MotorizedFlexShade_Inst08-R Printed in U.S.A.

Motorized FlexShades by Draper



Figure 7

⑤ If crank override is included, re-attach to endcap (see Fig. 8). Make sure fascia is in place before attaching crank handle, so the screws attach both the handle and the fascia to the endcap.



Figure 8

Surface (Ceiling/Wall) Headbox or Large Pocket Headbox

① Snap endcap covers onto endcaps.
② Place endcaps into back/top portion of wall/ceiling headbox or into pocket extrusion of large pocket headbox. Using pre-drilled holes in endcaps, mark the headbox for drilling.

⚠Caution: Before mounting shades, verify measurements on the card provided with the shade, and ensure the unit is installed at the correct width.

③ Drill holes in back or top, depending on whether you will be mounting the headbox to the wall or ceiling, or in a pocket.
④ Attach endcaps and wall/ceiling headbox back/top or large pocket headbox extrusion to wall, ceiling or pocket using mounting hardware appropriate for site conditions. ***The installer is responsible for selecting mounting hardware appropriate for site conditions.***
⑤ Install shade following steps 2-5 under "Fascia" section.
⑥ Attach headbox fascia or large pocket closure (see Fig. 9). ***Note on surface style headbox: Fascia is not fully seated until it clicks into place on both ends. Once in place, check for secure fit. If not secure, secure with appropriate fastener (not included).***



Figure 9

⑦ If crank overrise was included, reattach to endcap (see Fig. 8). Make sure fascia is in place before attaching crank handle, so that the screws attach both the handle and the fascia to the endcap.

Small (3¼" Hardware) Pocket Headbox

① Follow steps 1 through 5 as described in "Surface (Ceiling/Wall) Headbox or Large Pocket Headbox" section.

Please note that when you remove the crank handle assembly (if provided) there will be no washers to discard.

② If crank override was included, reattach to endcap (see Fig. 8). Make sure the fascia is in place before attaching crank handle (see Fig. 9), so the screws attach to the handle and the fascia to the endcap.

Small Pocket Endcap Dims



Field Adjustments

Each Draper Solar Control Shade is tested to ensure proper operation. Even with this testing, some field adjustments may be needed for telescoping. If shade is telescoping, place a piece of high quality gaffer tape about 1" wide on the exposed roller (where the fabric will cover it) on the side that you want the fabric drawn toward. For example: if fabric is tracking to the left, place the tape on the right side.

Electrical Connections

Shade operates on 110-120V, 60 Hz. current. Shade is shipped with internal wiring complete and control switch(es) fully boxed, and standardly supplied with a 6' cable lead. Longer lead can be substituted by removing two screws in motor end of roller, removing lead, plugging new lead in, and replacing screws. Wire to connect shade to switch(es) and switch(es) to power supply should be furnished by installer. Connections should be made in accordance with attached wiring diagram, and wiring should comply with national and local electrical codes. **DO NOT wire motors in parallel without written permission from Draper.**
All operating switches should be "off" before power is connected.

Cleaning and Maintenance

Idlers on motorized shades may occasionally need lubrication. If lubrication is required, apply a small amount of a lithium based grease direct to the idler pin.

Most of Draper's standard fabrics may be cleaned at the window by vacuuming with a soft brush attachment. They may also be cleaned by using a sponge or soft cloth and mild solution of warm soapy water. A dishwashing liquid, such as Ivory liquid, is recommended. A clean dry cloth is recommended for the metal finish. ***Exceptions are Flocké and Roc-Rol fabrics, which must be cleaned with a dry art sponge.***

Single Shade Wiring Diagram

For multiple shade or low voltage wiring consult diagrams provided with control.



NOTE: Test shade operation. If shade direction does not correspond with the switch orientation, ***turn power back off then*** *switch the red and black wires from the motor to the switch.*

Limit Switch Adjustments

CAUTION: Be sure all switches are in "off" position before adjusting limit switches. Always be prepared to shut off manually when new adjustment is being tested. ***Do not allow the shade roller to become exposed by running the shade fabric too far down.*** Shade may be severely damaged if allowed to run too far up or down. *Each shade's limit switch must be set if using group control system.*

Push Button Limits

① Fully depress both limit switch push buttons, then operate wall switch to make sure system works properly.
② Raise shade to desired "up" stop position.
③ Set upper limit by depressing and releasing the proper (back) push button.
④ Lower shade to desired "down" stop position.
⑤ Set lower limit by depressing and releasing the proper (front) push button.

Screw-Type Limits

① Determine which direction of fabric travel corresponds with arrows on motor.
② Operate shade to desired "down" stop position. Set limit by turning the proper socket toward the "+" to lower the limit, and "-" to raise it.
③ Operate shade to desired "up" stopping position. Set limit by turning the proper screw toward the "-" to raise the limit, and "+" to lower it.

Installation Instructions
FlexShade 2 by Draper

Caution

① Inspect all boxes to make sure you have received the proper shades and parts. Controls may be shipped separately, or in same carton as shades.
② Open cartons lengthwise.
③ All brackets, fascia, headboxes, pockets, wall clips and other hardware must be installed level. Shades must be level and square.
④ Before connecting switches, controls, or electrical, make sure power is off. Wiring indicated in diagram by dashed lines *must be completed by an electrician.* Do not wire motors in parallel.
⑤ Installation of this product requires two people.
⑥ It is the installer's responsibility to make sure appropriate fasteners are used for mounting surface.
⑦ Please follow installation guidelines carefully. Failure to do so invalidates warranty.

Mounting Brackets and Endcaps

① Mark wall, jamb or ceiling for placement of mounting brackets or endcaps.
② Drill small starter hole in mounting surface (if necessary).
③ Mount brackets using appropriate fasteners for surface (see Fig. 1 for bracket and endcap types). Centers of mounting holes are approximately $^{13}/_{16}$" in from outer edge of endcap/bracket.

Please Note: *It is the responsibility of the installer to ensure the mounting surface and mounting hardware are of appropriate type and strength.*

Mounting Brackets



Pin End (Left Standard)



Motor End (Right Standard)

Endcaps for Headbox or Fascia



Pin End (Left Standard)



Motor End (Right Standard)

Figure 1

Shade Installation

Please Note: Installation of Shade Assembly requires two people.

① Remove screw from the motor retainer ring.
② Install the motor retainer ring into the groove in the motor end bracket (see Fig. 2). Do not re-install the screw yet.

Caution: Be sure motor is fully re-seated in the bracket, and re-secured carefully with the motor retaining spring.



Figure 2

③ Rotate the roller assembly idler pin so that the ¼" hole in the shaft is aligned with the ¼" hole in the idler end bracket (see Fig. 3).
④ Place idler pin into the idler end bracket.
⑤ Insert the cotter pin through the idler end bracket and shaft.
⑥ Insert the motor end of the roller assembly into the motor end bracket (see Fig. 3).



Figure 3

Caution: *The cotter pin must be correctly installed to insure safe operation of the shade. If misalignment of the holes in the idler shaft and bracket prevent the cotter pin from being installed, then the roller assembly must be completely removed and re-installed.*

⑦ Ensure that the motor retainer ring is properly installed around the grooves in the motor and the motor end bracket.
⑧ Install the motor retainer ring screw and tighten.

Please note: Maximum torque for tightening screw is 5 lb-inches.

⑨ Use the cable strap with self-adhesive attachment pads to secure the motor cable to the endcap (see Fig. 4). This will prevent possible damage to the cable by the roller during shade operation.



Figure 4

⑩ Run electrical wiring (see "Electrical Connections," page 2), and set limits (see "Adjustments," page 2).

Headbox

① Remove headbox cover (see Fig. 5).



Figure 5

② Remove shade and roller from headbox/endcaps.
③ Mount headbox and endcaps in desired location.
④ Re-install shade roller (see "Shade Installation" section).
⑤ Run electrical wiring (see "Electrical Connections," page 2).
⑥ Set limits (see "Adjustments," page 2).
⑦ Re-install headbox cover.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright © 2007 Draper Inc. FormFlexShade2_Inst07-R2 Printed in U.S.A.

If you encounter any difficulties installing or servicing your FlexShade 2, call your dealer or Draper, Inc., Spiceland, Ind., (765) 987-7999, or fax (765) 987-7142.

Fascia

① Mount endcaps and follow steps outlined in "Shade Installation" section to assemble shade.
② Run electrical wiring (see "Electrical Connections").
③ Set limits (see "Adjustments").
④ Install fascia (see Fig. 6).



Figure 6

Adjustments

Your shade motor will feature either push-button or setscrew limit switches. Use appropriate steps below for your type of motor. At no time should viewing surface be unrolled enough to expose any part of shade roller.

These instructions are for right-hand motor, fabric from rear of roller. For left-hand motor, fabric from rear of roller, directions noted below should be reversed.

Push-Button Limit Switches:

① Fully depress both limit switch push buttons, then operate wall switch to make sure system works properly.
② Raise shade to desired "up" stop position.
③ Set upper limit by depressing and releasing the proper (back) push button (See Fig. 7).
④ Lower shade to desired "down" stop position.
⑤ Set lower limit by depressing and releasing the proper (front) push button (see Fig. 7).

NOTE: Each shade's limits must be set if using group control.



Figure 7

Setscrew/Socket Limit Switches:

Adjusting Back (White) Socket—White socket is located on the motor end of roller (see Fig. 8) and is accessible to a small flat screwdriver or $^{5}/_{32}$" hex key. Turning the socket counterclockwise will allow the roller to run farther up or down (as appropriate). Turning it clockwise will shorten operation, causing it to stop sooner. A full revolution of the socket will alter the stopping position of the shade by approximately $1^{1}/_{4}$".



Figure 8

Adjusting Front (Yellow) Socket—Yellow socket is located on the motor end of roller (see Fig. 8) and is accessible to a small flat screwdriver. Turning the socket counterclockwise will allow the roller to run farther up or down (as appropriate). Turning it clockwise will shorten operation, causing it to stop sooner. A full revolution of the socket will alter the stopping position of the shade by approximately $1^{1}/_{4}$".

Please Note: *Each shade's limits must be set if using group control.*

Electrical Connections

Shade operates on 110-120v, 60 Hz. current. Shade is shipped with internal wiring complete and control switch (es) fully boxed, and standardly supplied with a 6' cable lead. Longer lead can be substituted by removing two screws in motor end of roller, removing lead, plugging new lead in, and replacing screws. Wire to connect shade to switch (es) and switch (es) to power supply should be furnished by installer. Connections should be made in accordance with attached wiring diagram, and wiring should comply with national and local electrical codes. **DO NOT wire motors in parallel.**

All operating switches should be "off" before power is connected.

Single Shade Wiring Diagram

For multiple shades or low voltage wiring consult diagrams provided with control.



NOTE: Wiring diagram for standard right-hand motor placement with fabric from rear of roller, or left-hand motor placement with fabric from front of roller. For left hand motor placement with fabric from rear of roller or right hand motor placement with fabric from front of roller, Red is "Up" and Black is "Down."

Dimensions



Centers of mounting holes in endcaps and brackets are located approximately $^{13}/_{16}$" in from the outer edge of the endcap/bracket.

	Headbox with Endcaps	Fascia with Endcaps	Brackets Only
A	$6^{5}/_{8}$"	$6^{1}/_{2}$"	$5^{7}/_{16}$"
B	$6^{5}/_{8}$"	$6^{1}/_{2}$"	$5^{7}/_{16}$"
C	N/A	N/A	$3^{1}/_{4}$"
D	N/A	N/A	$3^{1}/_{4}$"
E	1"	1"	$^{15}/_{16}$"

Please Note: Maximum bundle diameter is $5^{1}/_{4}$" (for Headbox, Fascia or Brackets)

Cleaning and Maintenance

Idlers on motorized shades may occasionally need lubrication. If lubrication is required, apply a small amount of a lithium based grease direct to the idler pin.

Most of Draper's standard fabrics may be cleaned at the window by vacuuming with a soft brush attachment. They may also be cleaned by using a sponge or soft cloth and mild solution of warm soapy water. A dishwashing liquid, such as Ivory liquid, is recommended. A clean dry cloth is recommended for the metal finish. ***Exceptions are Flocké and Roc-Rol fabrics, which must be cleaned with a dry art sponge.***

Installation/Operating Instructions
Colossal FlexShade by Draper

Caution

① Read instructions through completely before proceeding.

② Follow instructions carefully. Installation contrary to instructions invalidates warranty.

③ Pick up shade from ***ends only***. Picking headbox up at other points ***will damage case*** and ***may damage fabric***.

④ Entire bottom of shade headbox should be unobstructed to permit access to bottom panel for making electrical connections or servicing.

⑤ Shade should be installed level (using a carpenter's level).

⑥ Operating switch(es) packed separately in shade carton. Do not discard with packing material.

⑦ Shade operates on 110-120V, 60 Hz. current.

NOTE*: Shade has been thoroughly inspected and tested at factory and found to be operating properly prior to shipment.*

Mounting Shade

Regardless of mounting method used, the following points apply:

① Shade should be lifted into position ***only by the end mounting brackets. Draper provides eyebolts to use in hoisting the shade. Never attempt to lift shade along its length.***

② Shade should be positively and securely supported so that vibration or even abusive pulling will not weaken installation.

③ Installer must insure that fasteners used are of adequate strength and suitable for the mounting surface chosen. ***Installer must also insure that wall or ceiling structure are of adequate strength.*** Supporting hardware (chains, cables, rods, etc.) must be essentially vertical.

④ Entire bottom of headbox must be readily accessible after installation is complete.

⑤ Front, back and top of case must be straight—not forced to warp or bow. Adjust spreader bars to keep large cases from warping.

⑥ Do not use headbox to support adjacent sections of ceiling.

⑦ If optional ceiling flange trim kits are attached, use hardware provided.

⑧ If headbox is painted, slots on bottom of case should be shielded to protect viewing surface from paint splatters or overspray.

⑨ After the headbox is mounted, and before the shade is operated, you will need to remove the shipping brackets from inside the headbox. First, remove the closure panel (see instructions on page 2). You will find the shipping brackets on the motor-end endcap—one in front of the roller and one behind (see Fig. 1). Remove the black hexagonal brackets with a wrench, taking care not to damage the fabric or loosen the wiring (see caution note below). Replace the closure panel.

Caution*: Shade is shipped with motor wiring mounted to the headbox. Be careful not to pull the wiring loose from the headbox while removing the brackets—if wiring is loose, it could be damaged during shade operation. If wiring does come loose, re-mount as it was.*

⑩ Do not seal unit in ceiling until electrical connections have been made and shade has been operated successfully.

Figure 1 (roller and fabric removed for clarity)

Electrical Connections

Shade operates on 110-120V, 60 Hz. current.

Junction box is located just above the closure panel, at the motor end of shade. To properly remove closure panel, two people should follow the steps on page two of these instructions. The junction box access plate is held closed with pan head screws and may be opened with a Phillips screwdriver. Removal of access plate exposes red, black and white pigtail leads and green internal ground wire per wiring diagram attached.

Shade is shipped with internal wiring complete and control switch(es) fully boxed. Wire connecting shade to switch(es) and switch(es) to power supply should be furnished by installer. Connections should be made in accordance with attached wiring diagram, and wiring should comply with national and local electrical codes.

All operating switches should be "off" before power is connected.

Operation

When shade is first operated, **be cautious!** Cycle unit down and up several times to confirm satisfactory operation.

Adjustments

Shade has been factory set and should not normally require further adjustment. However, if you desire to change the "up" and "down" stopping positions, proceed as follows:

CAUTION: Be sure all switches are in "off" position before adjusting limit switches. Always be prepared to shut shade off manually when new adjustment is being tested. Shade may be severely damaged if allowed to run too far up or too far down.

ADJUSTING "FULLY UP" POSITION—Put a small screw driver in the groove of the yellow button on the motor and press vertically until hearing a "click". Raise the shade by pressing the "up" switch on unit. Press the "stop" switch when the shade is at the desired position. Then press the yellow button on motor until you hear a "click", then release.

ADJUSTING "FULLY DOWN" POSITION—Put a small screw driver in the groove of the white button on the motor and press vertically until hearing a "click". Lower the shade by pressing the "down" switch on unit. Press the "stop" switch when the shade is at the desired position. Then press the white button on motor until you hear a "click", then release.

AT NO TIME SHOULD SHADE BE UNROLLED ENOUGH TO EXPOSE ANY PART OF SHADE ROLLER.

Please Note: *The above instructions affect only the limits on the motors. For adjustment procedures using Draper's IntelliFlex Control Systems, please consult the installation information for the appropriate control.*


1/2" threaded rod (for suspending shade) by others.
3/8" -16 threaded rod (use for adjusting deflection in extremely long units) by others.
8"
Eyebolts for hoisting shade (do not lift shade by center of case).
Headbox support brackets.
13 1/4"
12"
Knockouts for electrical connections (two per end) with plastic plugs

Caution: Do not remove the roller assembly from the case unless necessary for repairs. If the roller assembly is removed, be sure motor is fully re-seated in the bracket, and re-secure it carefully with the motor retaining spring and screw (see diagram below).



Please note: Maximum torque for tightening screw is 5 lb-inches.

Please see back page for dimensional diagrams of case and optional wall mounting bracket, wiring diagrams and instructions on removing and replacing the bottom closure.

If you encounter any difficulties installing or servicing your Colossal FlexShade, call your dealer or Draper, Inc., Spiceland, Indiana, (765) 987-7999 or fax (765) 987-7142.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142

Copyright © 2007 Draper Inc. Form ColossalFlexShade_Inst07-R Printed in U.S.A.

Colossal FlexShade by Draper

Optional Wall Mounting Bracket



Dimensions*



Bottom Closure Removal/Replacement

Removal and replacement of the bottom closure panel requires two people. Closure should be handled as shown in Step 5 below to prevent bowing of the closure during handling.

Before removing bottom closure, you must first remove brackets at each end of case (see drawing at right).











Please Note: Optional wall brackets add 1¾" per bracket to case length. Wall mounting bracket hole location is 1" from end of case.

Wiring Diagrams



NOTE: Test shade operation. If shade direction does not correspond with the switch orientation, turn power back off and switch the red and black wires from the motor to the switch.



Wiring by Installer

Tolerance		Draper, Inc. 411 S. Pearl St. Spiceland, IN 47385	
Down	Title: GCS & Control by Modified VIC-12		
	Scale: None	By: TDC	Date: 11-17-08	DWG No.: GCSIIVIC12-Shades



Tolerance	DRAPER	Draper, Inc. 411 S. Pearl St. Spiceland, IN 47385		
Down	Title: GCS & Control by Nurse Call			
	Scale: None	By: TDC	Date: 11-17-08	DWG No.: GCSIINC-Shades





Wiring by Installer

Tolerance	DRAPER	Draper, Inc. 411 S. Pearl St. Spiceland, IN 47385	
Down	Title: Multiple-Station Control		
	Scale: None	By: TDC	Date: 11-17-08	DWG No.: MS4R-Shades



Tolerance	DRAPER	Draper, Inc. 411 S. Pearl St. Spiceland, IN 47385		
Down	Title: IntelliFlex & Home Automation			
	Scale: None	By: TDC	Date: 11-17-08	DWG No.: IntelliFlex-HomeAuto

Universal
RS 232

Home
Automation
System

OR


To Bus System 7 (or to RF Transmitter)
To Bus System 6
To Bus System 5
To Bus System 4
R2D7
To RS232 Port:
Yellow = Rx (Receive data from control system)
Green = Tx (Transmit data to control system)
Red = Unused
Black = Gnd (Signal Ground)
To Bus System 1
To Bus System 2
To Bus System 3

SC1,
SGC4,
SPGC4

Home
Automation
System

Tolerance	DRAPER	Draper, Inc. 411 S. Pearl St. Spiceland, IN 47385		
Down	Title: RS232 and Home Automation			
	Scale: None	By: TDC	Date: 11-17-08	DWG No.: RS232-HomeAuto

SolarFlex—Sun Tracking Automation

SolarFlex is a sun tracking automation software which takes your buildings floor plan and runs the shades accordingly. Shades will run up and down based on the sun's intensity, azimuth, and light penetration needs. SolarFlex can work with other switching devices or alarm systems as well.

Benefits of SolarFlex are:

1. Maximum light and glare control
2. Energy Efficiency
3. Daylighting Autonomy is maximized.
4. User records are kept
5. System can be manipulated or reprogrammed easily to account for changing exterior conditions.
6. Remote management of system is possible.

To install this system, one will need to dedicate a control closet to locate a PC with the software loaded on it. A small weather station will also need to exist on the roof. All controls on the job will need to be addressed and those addresses must be recorded for programming the SolarFlex.

The dedicated PC will be provided by Draper, and it will be programmed with the building floor plan. Floor plans must be provided to Draper.

The weather station on the roof will let the PC know if it is sunny or not. If it is not sunny then the shades will not deploy. If it is, then the PC using the GPS of the building, time, and date will know the position of the sun and run the shades.

The PC will need to reach out an obtain time in order to operate. If it does not then the time might get off and actions will not be correct.

This system is designed to give the user the most energy efficient operation of their shades, but people will sometimes not want this type of operation. The system can have wall switches or other devices to override the sun sensors.

The system will recalibrate every few hours to correct any overrides, and the system can be set not to respond to override commands if desired.

The PC with the SolarFlex software must not be a work station PC. The shades can be run from the PC.

Solarflex is programming will require a lot of planning and coordination with Draper to ensure the system is correct. Please contact Draper when planning to use this system so a series of steps for creating the system can be established for a job.

See other side for diagram.

Below is a picture of what the PC will be showing.



Contacting Draper

Telephone (U.S. and Canada)—800-989-0126

Fax—866-637-5611

Faxed/e-mailed purchase orders are processed directly. However, incomplete orders will be placed on hold until questions are answered. Draper will default to standards when applicable—see page 4. To ensure complete and accurate orders are received, please use Draper order forms.

Order forms are available online at www.draperinc.com/go/ShadeOrderForm.htm

Internet

Our Web site, *www.draperinc.com*, is a convenient, 24-hour source for product information.
Email addresses are available below and in the Contact Us section of our Web site.

Key Contacts

Region	Regional Manager	Shade Region	Shade Sales Specialist
CT, NH, ME, MA, RI, VT, Eastern Canada (NB, NF, NS, PE, ON, QC)	**Eric Guffey, LEED® AP, CTS** — *ext. 300* *eguffey@draperinc.com*	CT, NH, ME, MA, RI, VT, Eastern Canada (NB, NF, NS, PE, ON, PQ)	**Karen Reno** — *ext. 359* *kreno@draperinc.com*
NJ, NY, PA	**Todd Garner, CSI** — *ext. 303* *tgarner@draperinc.com*	NY	**Karen Reno** — *ext. 359* *kreno@draperinc.com*
		PA, NJ	**Teri Boxell** — *ext. 524* *teriboxell@draperinc.com*
DC, DE, KY, MD, VA, WV	**Stuart Milligan, CTS, LEED® AP** — *ext. 215* *smilligan@draperinc.com*	DC, DE, MD	**Teri Boxell** — *ext. 524* *teriboxell@draperinc.com*
		KY, VA, WV	**Dan Turner** — *ext. 620* *dturner@draperinc.com*
FL, GA, NC, SC	**Matt Schultz, CSI, CDT, LEED® AP** *770-562-4757* *mschultz@draperinc.com*	FL GA, NC, SC	**Tracy Linville, CTS** — *ext. 519* *tlinville@draperinc.com*
IL, IN, MI, OH, KY (Cincinnati area only)	**Art Tober, CSI, CDT** *586-416-0829* *atober@draperinc.com*	MI, OH, KY (Cincinnati area only)	**Lana Mathews** — *ext. 239* *lmathews@draperinc.com*
		IN, IL	**Dan Turner** — *ext. 620* *dturner@draperinc.com*
TX	**Chad Tabor, CTS** — *ext. 255* *ctabor@draperinc.com*	TX	**Lana Byrket** — *ext. 462* *lbyrket@draperinc.com*
IA, MN, MT, NE, ND, SD, WI, Central Canada (AB, MB, SK)	**Brian Kunz, LEED® AP, CTS** — *ext. 214* *bkunz@draperinc.com*	IA, MN, MT, NE, ND, SD, WI, Central Canada (AB, MB, SK)	**Doug Ross** — *ext. 281* *dross@draperinc.com*
AZ, CA (Southern), NV (Southern), HI	**Kathy Greenway, CSI** *951-600-9056* *kgreenway@draperinc.com*	AZ, CA (Southern), NV (Southern), HI	**Lana Byrket** — *ext. 462* *lbyrket@draperinc.com*
AL, AR, LA, MS, MO, TN	**Kylee Whistler, CTS** — *ext. 358* *kwhistler@draperinc.com*	AL, AR, LA, MS, MO, TN	**Tracy Linville, CTS** — *ext. 519* *tlinville@draperinc.com*
AK, CA (Northern), NV (Northern), OR, WA, Western Canada (BC)	**Vicki Long** *714-447-4383* *vlong@draperinc.com*	AK, CA (Northern), NV (Northern), OR, WA, Western Canada (BC)	**Lana Byrket** — *ext. 462* *lbyrket@draperinc.com*
CO, ID, KS, NM, OK, UT, WY, Kansas City (MO)	**Jeff Broome**—*ext. 270* *jbroome@draperinc.com*	CO, ID, KS, NM, OK, UT, WY	**Doug Ross** — *ext. 281* *dross@draperinc.com*
		Kansas City (KS), Kansas City (MO)	**Tracy Linville, CTS** — *ext. 519* *tlinville@draperinc.com*

Sales/Marketing Management	ext.	E-mail address
Chris Broome, CSI, LEED® AP	205	*cbroome@draperinc.com*
Window Coverings Manager		
Jeff Miller, LEED® AP	533	*jmiller@draperinc.com*
Green Buildings Specialist		
Clint Childress, LEED® AP	450	*cchildress@draperinc.com*

Special Assistance	Name	Ext.	Email Address
Technical Support			
Mike Oldham	304		*coldham@draperinc.com*
Clint Childress, LEED® AP	450		*cchildress@draperinc.com*
Ryan Carmony	621		*rcarmony@draperinc.com*
Customer Service			
Manager			
Beverly Ferguson	206		*bferguson@draperinc.com*
Returns			
Amy Denney	293		*adenney@draperinc.com*
Traffic Support			
Tina Loveless	468		*tloveless@draperinc.com*
Order Status			
Debbie Spera	301		*dspera@draperinc.com*
Customer Service Support			
Carol McLemore	253		*cmclemore@draperinc.com*

DRAPER®

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142